


Radio Shack®
**DISK SYSTEM
OWNER'S
MANUAL**

TRS-80® Model 4/4P



Custom Manufactured in USA by RADIO SHACK, A Division of TANDY CORPORATION

TERMS AND CONDITIONS OF SALE AND LICENSE OF RADIO SHACK COMPUTER EQUIPMENT AND SOFTWARE
PURCHASED FROM A RADIO SHACK COMPANY-OWNED COMPUTER CENTER, RETAIL STORE OR FROM A
RADIO SHACK FRANCHISEE OR DEALER AT ITS AUTHORIZED LOCATION

LIMITED WARRANTY

I. CUSTOMER OBLIGATIONS

- A. CUSTOMER assumes full responsibility that this Radio Shack computer hardware purchased (the "Equipment"), and any copies of Radio Shack software included with the Equipment or licensed separately (the "Software") meets the specifications, capacity, capabilities, versatility, and other requirements of CUSTOMER.
- B. CUSTOMER assumes full responsibility for the condition and effectiveness of the operating environment in which the Equipment and Software are to function, and for its installation.

II. RADIO SHACK LIMITED WARRANTIES AND CONDITIONS OF SALE

- A. For a period of ninety (90) calendar days from the date of the Radio Shack sales document received upon purchase of the Equipment, RADIO SHACK warrants to the original CUSTOMER that the Equipment and the medium upon which the Software is stored is free from manufacturing defects. THIS WARRANTY IS ONLY APPLICABLE TO PURCHASES OF RADIO SHACK EQUIPMENT BY THE ORIGINAL CUSTOMER FROM RADIO SHACK COMPANY-OWNED COMPUTER CENTERS, RETAIL STORES AND FROM RADIO SHACK FRANCHISEES AND DEALERS AT ITS AUTHORIZED LOCATION. The warranty is void if the Equipment's case or cabinet has been opened, or if the Equipment or Software has been subjected to improper or abnormal use. If a manufacturing defect is discovered during the stated warranty period, the defective Equipment must be returned to a Radio Shack Computer Center, a Radio Shack retail store, participating Radio Shack franchisee or Radio Shack dealer for repair, along with a copy of the sales document or lease agreement. The original CUSTOMER'S sole and exclusive remedy in the event of a defect is limited to the correction of the defect by repair, replacement, or refund of the purchase price, at RADIO SHACK'S election and sole expense. RADIO SHACK has no obligation to replace or repair expendable items.
- B. RADIO SHACK makes no warranty as to the design, capability, capacity, or suitability for use of the Software, except as provided in this paragraph. Software is licensed on an "AS IS" basis, without warranty. The original CUSTOMER'S exclusive remedy, in the event of a Software manufacturing defect, is its repair or replacement within thirty (30) calendar days of the date of the Radio Shack sales document received upon license of the Software. The defective Software shall be returned to a Radio Shack Computer Center, a Radio Shack retail store, participating Radio Shack franchisee or Radio Shack dealer along with the sales document.
- C. Except as provided herein no employee, agent, franchisee, dealer or other person is authorized to give any warranties of any nature on behalf of RADIO SHACK.
- D. Except as provided herein, **RADIO SHACK MAKES NO WARRANTIES, INCLUDING WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.**
- E. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation(s) may not apply to CUSTOMER.

III. LIMITATION OF LIABILITY

- A. EXCEPT AS PROVIDED HEREIN, RADIO SHACK SHALL HAVE NO LIABILITY OR RESPONSIBILITY TO CUSTOMER OR ANY OTHER PERSON OR ENTITY WITH RESPECT TO ANY LIABILITY, LOSS OR DAMAGE CAUSED OR ALLEGED TO BE CAUSED DIRECTLY OR INDIRECTLY BY "EQUIPMENT" OR "SOFTWARE" SOLD, LEASED, LICENSED OR FURNISHED BY RADIO SHACK, INCLUDING, BUT NOT LIMITED TO, ANY INTERRUPTION OF SERVICE, LOSS OF BUSINESS OR ANTICIPATORY PROFITS OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OR OPERATION OF THE "EQUIPMENT" OR "SOFTWARE". IN NO EVENT SHALL RADIO SHACK BE LIABLE FOR LOSS OF PROFITS, OR ANY INDIRECT, SPECIAL, OR CONSEQUENTIAL DAMAGES ARISING OUT OF ANY BREACH OF THIS WARRANTY OR IN ANY MANNER ARISING OUT OF OR CONNECTED WITH THE SALE, LEASE, LICENSE, USE OR ANTICIPATED USE OF THE "EQUIPMENT" OR "SOFTWARE".
NOTWITHSTANDING THE ABOVE LIMITATIONS AND WARRANTIES, RADIO SHACK'S LIABILITY HEREUNDER FOR DAMAGES INCURRED BY CUSTOMER OR OTHERS SHALL NOT EXCEED THE AMOUNT PAID BY CUSTOMER FOR THE PARTICULAR "EQUIPMENT" OR "SOFTWARE" INVOLVED.
- B. RADIO SHACK shall not be liable for any damages caused by delay in delivering or furnishing Equipment and/or Software.
- C. No action arising out of any claimed breach of this Warranty or transactions under this Warranty may be brought more than two (2) years after the cause of action has accrued or more than four (4) years after the date of the Radio Shack sales document for the Equipment or Software, whichever first occurs.
- D. Some states do not allow the limitation or exclusion of incidental or consequential damages, so the above limitation(s) or exclusion(s) may not apply to CUSTOMER.

IV. RADIO SHACK SOFTWARE LICENSE

RADIO SHACK grants to CUSTOMER a non-exclusive, paid-up license to use the RADIO SHACK Software on **one** computer, subject to the following provisions:

- A. Except as otherwise provided in this Software License, applicable copyright laws shall apply to the Software.
- B. Title to the medium on which the Software is recorded (cassette and/or diskette) or stored (ROM) is transferred to CUSTOMER, but not title to the Software.
- C. CUSTOMER may use Software on one host computer and access that Software through one or more terminals if the Software permits this function.
- D. CUSTOMER shall not use, make, manufacture, or reproduce copies of Software except for use on **one** computer and as is specifically provided in this Software License. Customer is expressly prohibited from disassembling the Software.
- E. CUSTOMER is permitted to make additional copies of the Software **only** for backup or archival purposes or if additional copies are required in the operation of **one** computer with the Software, but only to the extent the Software allows a backup copy to be made. However, for TRSDOS Software, CUSTOMER is permitted to make a limited number of additional copies for CUSTOMER'S own use.
- F. CUSTOMER may sell or distribute unmodified copies of the Software provided CUSTOMER has purchased one copy of the Software for each one sold or distributed. The provisions of this Software License shall also be applicable to third parties receiving copies of the Software from CUSTOMER.
- G. All copyright notices shall be retained on all copies of the Software.

V. APPLICABILITY OF WARRANTY

- A. The terms and conditions of this Warranty are applicable as between RADIO SHACK and CUSTOMER to either a sale of the Equipment and/or Software License to CUSTOMER or to a transaction whereby RADIO SHACK sells or conveys such Equipment to a third party for lease to CUSTOMER.
- B. The limitations of liability and Warranty provisions herein shall inure to the benefit of RADIO SHACK, the author, owner and/or licensor of the Software and any manufacturer of the Equipment sold by RADIO SHACK.

VI. STATE LAW RIGHTS

The warranties granted herein give the **original** CUSTOMER specific legal rights, and the **original** CUSTOMER may have other rights which vary from state to state.

TRS-80® Model 4/4P
Disk System Owner's Manual

The FCC Wants You to Know . . .

This equipment generates and uses radio frequency energy. If not installed and used properly, that is, in strict accordance with the manufacturer's instructions, it may cause interference to radio and television reception.

It has been type tested and found to comply with the limits for a Class B computing device in accordance with the specifications in Subpart J of Part 15 of FCC Rules, which are designed to provide reasonable protection against such interference in a residential installation. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient the receiving antenna
- Relocate the computer with respect to the receiver
- Move the computer away from the receiver
- Plug the computer into a different outlet so that computer and receiver are on different branch circuits.

If necessary, you should consult the dealer or an experienced radio/television technician for additional suggestions. You may find the following booklet prepared by the Federal Communications Commission helpful: *How to Identify and Resolve Radio-TV Interference Problems*.

This booklet is available from the US Government Printing Office, Washington, DC 20402, Stock No. 004-000-00345-4.

Warning

This equipment has been certified to comply with the limits for a Class B computing device, pursuant to Subpart J of Part 15 of FCC Rules. Only peripherals (computer input/output devices, terminals, printers, etc.) certified to comply with the Class B limits may be attached to this computer. Operation with non-certified peripherals is likely to result in interference to radio and TV reception.

Model 4P Only

The TRS-80 Model 4P Computer (Catalog Number 26-1080) is equipped with an external I/O bus to enable connection of a Radio Shack TRS-80 Five Meg Disk System (Catalog Number 26-1130). If you wish to connect the Five Meg Disk System to this I/O bus, the classification of the Model 4P is changed to Class A and the following warning applies:

Warning

This equipment generates, uses, and can radiate radio frequency energy and if not installed and used in accordance with the instructions manual, may cause interference to radio communications. It has been tested and found to comply with the limits for a Class A computing device pursuant to Subpart J of Part 15 of FCC Rules, which are designed to provide reasonable protection against such interference when operated in a commercial environment. Operation of this equipment in a residential area is likely to cause interference in which case the user at his own expense will be required to take whatever measures may be required to correct the interferences.

TRSDOS® Version 6 Operating System: © 1983 Logical Systems.
All Right Reserved. Licensed to Tandy Corporation.

BASIC: © 1983 Microsoft.
All Rights Reserved. Licensed to Tandy Corporation.

Disk System Owner's Manual TRSDOS Section:
© 1983 Tandy Corporation and Logical Systems. All Rights Reserved.

Disk System Owner's Manual BASIC Section:
©1983 Tandy Corporation. All Rights Reserved.

Reproduction or use, without express written permission from Tandy Corporation or Logical Systems of any portion of this manual is prohibited. While reasonable efforts have been taken in the preparation of this manual to assure its accuracy, Tandy Corporation and Logical Systems assumes no liability resulting from any errors or omissions in this manual, or from the use of the information contained herein.

TRSDOS is a registered trademark of Tandy Corporation.

Introduction

About the Model 4/4P

Congratulations on the purchase of your TRS-80 Model 4 or Model 4P Disk System. Your new Model 4 or Model 4P is a compact computer that is perfect for business needs, as well as personal use. You will find it to be a valuable tool which will save you work as well as give you hours of enjoyment. Its basic features include:

- 64K (65536 characters) of random access memory, expandable to 128K
- High-speed Z-80A microprocessor, the “brains” of the computer
- Upper and lower case text display of 80 characters by 24 lines or 64 by 16 (software selectable)
- Compatible with Radio Shack's Model III Software Library.
- One or two built-in drives that let you use single-sided, double-density floppy disks.
- Sound generation.
- 70-key console keyboard which includes three function keys and numeric keypad.
- Built-in printer interface.

As your needs grow — you can expand your Model 4 or Model 4P to include hard disks, external floppy disk drives (Model 4 only), high-resolution graphics, printers, RS-232C communications and more.

About This Manual

This manual shows how you can use your disk system to:

- Store, retrieve or manipulate information on disk (using TRSDOS).
- Write programs for Model 4 and Model 4P (using BASIC).

The Model 4/4P's operating system is TRSDOS Version 6. Throughout this manual, we refer to this system simply as TRSDOS.

In the *Introduction To Your Disk System* manual, we covered all the essential information to get you started. As you learn more about TRSDOS and programming, you can take advantage of its many features explained in this manual.

Since this is a reference manual, you don't have to read it from front to back. If you are a programmer, you'll find a lot of useful information in this manual. If you are an advanced programmer, you'll find additional "advanced" information included for you in this manual. Additional technical information is available in *The Technical Reference Manual* (Cat. No. 26-2110). This manual is available at your local Radio Shack store.

Part I/ TRSDOS

Section I/ Using TRSDOS describes how to start up TRSDOS, what TRSDOS Ready means, and some general information on how TRSDOS works.

Section II/ TRSDOS Commands contains a number of commands and utilities you will find helpful.

PART II/ BASIC

Section III/ Operations explains how to start up and operate BASIC.

Section IV/ BASIC Language describes (1) BASIC concepts, (2) how to store data on disks, and (3) each BASIC statement and function.

Table of Contents

	Page
Introduction	
About The Model 4/4P	i
About This Manual	ii
Part I/ TRSDOS	
Section I/ Using TRSDOS	1-3
How the Computer Uses TRSDOS	1-5
TRSDOS Notations	1-5
TRSDOS Terms	1-5
TRSDOS Abbreviations	1-6
Loading TRSDOS	1-6
TRSDOS Ready	1-6
Executing a Command	1-7
Disk Files	1-7
Devices	1-10
Section II/ TRSDOS Commands	1-11
Introduction	1-13
How to Use This Section	1-14
Syntax	1-15
Part II/ Basic	
Introduction to BASIC	
About This Manual	2-3
Notations	2-3
Terms	2-4
Terms Used in Chapter 7 for Brevity	2-4
Section III/ Operations	2-7
Chapter 1/ Sample Session	2-9
Chapter 2/ Command And Execution Section	2-13
Chapter 3/ Line Edit Mode	2-17
Section IV/ BASIC Language	2-23
Chapter 4/ BASIC Concepts	2-25
Chapter 5/ Disk Files	2-51
Chapter 6/ Introduction To BASIC Statements And Functions	2-59
Chapter 7/ BASIC Statements And Functions	2-65
Part III/ Appendices	A-1
Appendix A/ Job Control Language	A-3
Simple JCL Execution	A-4
Simple JCL Compiling	A-12
Advanced JCL Compiling	A-25
Using TRSDOS JCL To Interface With Applications Programs	A-30
Practical Examples Of TRSDOS JCL Files	A-33
Appendix B/ Model 4/4P Hardware	
Keyboard Code Map	A-35
Specifications	A-39

Appendix C/ Character Codes.....	A-45
Appendix D/ Error Messages and Problems	
In Case Of Difficulty.....	A-61
TRSDOS.....	A-63
BASIC.....	A-69
Appendix E/ Converting TRSDOS Version 1 BASIC Programs to	
TRSDOS Version 6 BASIC Programs.....	A-75
Appendix F/ BASIC Keywords and Derived Functions	
Reserved BASIC Words	A-79
Internal Codes for BASIC Keywords.....	A-80
Derived BASIC Functions	A-82
Appendix G/ BASIC Worksheet	
Video.....	A-83
Appendix H/ Glossary.....	A-85
Appendix I/ TRSDOS Programs	A-91
Appendix J/ BASIC Memory Map	A-101
Appendix K/ Using The Device-Related Commands	A-103
Appendix L/ HERZ50	A-107
Appendix M/ Backup Limited Diskettes	A-109

Part I/TRSDOS Version 6

Section I/ Using TRSDOS

Section I/ Using TRSDOS

How The Computer Uses TRSDOS

Whenever you are using a program which runs under TRSDOS, your computer will, from time to time, need to reference TRSDOS. It always looks for TRSDOS on Drive 0.

For this reason, you must at all times have TRSDOS in Drive 0.

TRSDOS Notations

For clarity and brevity, we use some special notations and type styles in this section.

CAPITALS and punctuation
indicates material that you must enter exactly as it appears or material that you see on your computer's video display.

KEYBOARD CHARACTER

indicates key you press.

italics

represents words, letters, characters, or values that you supply.

TRSDOS Terms

Below is a listing of terms which we use frequently in this section. The italicized words represent variable information which you must supply.

<i>command</i>	represents the TRSDOS command you want to execute. <i>command</i> can be in upper or lowercase letters.
<i>(parameters)</i>	is a list of one or more values that may be needed by the command. Some commands have no parameters. Most parameters are optional. Brackets [] around any word in a command line indicate that it is optional.
<i>filespec</i>	is a standard TRSDOS file specification having the general form: <i>filename/ext.password:drive</i>
<i>devspec</i>	is (1) one of six standard TRSDOS device specifications, or (2) a user created device specification having the general form: <i>*two-letter abbreviation</i>
diskette	refers exclusively to a floppy diskette.
disk	refers to a floppy diskette.

disk ID	refers to the disk NAME, creation date, and Master Password.
---------	--

I/O	refers to a transfer of data (Input/Output).
-----	--

TRSDOS Abbreviations

You can abbreviate a *parameter* to its first letter (unless otherwise stated in the *command* explanation). You can also abbreviate YES to Y and NO to N.

Loading TRSDOS

When you install and power up your system, you'll see the TRSDOS start-up logo. This means you're in the TRSDOS Version 6 Operating System. You then need to enter the current date in the form *mm/dd/yy*. For example, for June, 14, 1983, type:

06/14/83 **(ENTER)**

The system displays the date in expanded form (for example, Tue, Jun 14, 1983).

TRSDOS Ready

Whenever you see the TRSDOS Ready prompt you know that you are in control of TRSDOS — not COBOL, PAYROLL, or any of your application programs. Being in control of TRSDOS allows you to do one of these operations:

- execute a TRSDOS system command or utility program
- execute an application program

When an error occurs, it came from one of two places: TRSDOS or the application program that you are running. If it came from TRSDOS, look in Appendix D or the TRSDOS command section for an explanation of the error message. If it came from the application program that is running, you'll need to see the manual which came with the application program for an explanation of the error message.

Executing A Command

You can execute a TRSDOS system command whenever you see the TRSDOS Ready prompt. The command you type can consist of up to 79 upper or lower case characters. You must enter the command by pressing **(ENTER)**.

For example, if you want to see the TRSDOS system commands, type:

LIB **(ENTER)**

TRSDOS displays a list of all the available system commands and returns to TRSDOS Ready:

Library <A>

Append	Copy	Device	Dir	Do	Filter	Lib
Link	List	Load	Memory	Remove	Rename	Reset
Route	Run	Set				

Library

Attrib	Auto	Build	Create	Date	Debug	Dump
Free	Purge	Time	Verify			

Library <C>

Forms	Setcom	Setki	Spool	Sysgen	System
-------	--------	-------	-------	--------	--------

If you wanted this display to print on the printer, type **(CTRL):**. Whenever you press this key sequence, what is displayed on the screen is printed on the printer.

Disk Files

You can keep a record of anything you type into your Model 4 by storing it on disk in a "disk file." A disk file can contain a program, a collection of data, a project report you intend to make, or almost anything you want it to contain. But whatever it is, if you want to keep it permanently, you'll have to store it in a disk file.

When the computer stores the file, it records the name of the file and its disk location in a special place on the disk called the disk's directory. Whenever you want to access the file, the computer can immediately find its location by using this directory.

Filespec

Whenever you create a disk file, you need to give it a name. This name is just one part of a file specification — filespec, for short. The filespec is the standard TRSDOS format you'll use every time you reference your file:

filename/ext.password:drive

filename

The name of your file can be most anything you like, as long as it is one to eight alphanumeric characters, the first of which must be a letter. (The only names you cannot use are TO, ON, USING and OVER.)

/extension

If you want to further identify your file, you can give it a second name by adding an extension. An extension (indicated by */ext* on our filespec) is a sequence of one to three alphanumeric characters (the first of which must be a letter) with a preceding slash (/).

You can use an extension to provide additional information on a file, or you can use an extension to indicate the type of file you have.

.password

A password protects a file by limiting access to it. You can accomplish this protection via a password either when you create the file or with the ATTRIB command.

A password is a sequence of up to eight alphanumeric characters, the first of which must be a letter.

:drive

Often when you're using your computer, you'll have more than one disk drive in use. You can speed up the file access time by specifying the drive the desired file is on.

If you omit a drive number on the filespec, your computer automatically starts looking for the file on all available drives, beginning with Drive 0.

Here are some examples of valid TRSDOS filespecs:

```
DOPROG.OPEN
CLR/BAS:1
MOD16:4
STL12/TXT.ARCH:1
GAME1
THESIS/OLD:2
CONTEMP:3
```

You cannot use TO, ON, OVER, or USING as TRSDOS filespecs.

Partspecs

Certain system commands and utilities allow you to specify a collection of files by using a "partspec." A partspec is used with a "wildcard" mask (\$). When you use a wildcard in a partspec, it represents a wildcard field and means "any character." For example, suppose the following files exist on a disk in Drive 1:

A	ACORN
ADVANCE/DAT	ADVISE/DAT
BILLING/CMD	BILLING
BILLING/BAK	BILLING/DAT

If you issue the command:

DIR A:1 **(ENTER)**

TRSDOS displays these files:

A	ACORN
ADVANCE/DAT	ADVISE/DAT

All files on the disk that begin with the letter A are displayed because when you specify a partspec, TRSDOS treats the command as "DIR of all files that begin with 'A'."

If you issue the command:

DIR BILLING:1 **(ENTER)**

TRSDOS displays:

BILLING	BILLING/CMD
BILLING/DAT	BILLING/BAK

Because you did not specify an extension, TRSDOS assumed that all extensions are acceptable.

If you issue the command:

DIR /\$A:1 **(ENTER)**

TRSDOS displays the files on the disk which have an A as the second character in their extension:

ADVANCE/DAT	ADVISE/DAT
BILLING/DAT	BILLING/BAK

Because you did not specify a filename, TRSDOS assumed that all filenames are acceptable.

A wildcard character must always have at least one character to its right. The following partspecs are identical:

A	A\$
A\$\$\$	A\$/\$
A\$/\$\$\$	

Devices

There are two kinds of TRSDOS devices: physical and logical.

A physical device is a piece of your computer hardware: the video display, the keyboard, the printer, etc.

A logical device (devspec) is a connection between TRSDOS and a physical device.

TRSDOS lets you treat your devices independently, which means you can sometimes substitute a device for another one. You can also substitute a file for a device. See the LINK, ROUTE, and SET library commands.

Devspec

When you want to access a device, you use its device specification or *devspec*.

TRSDOS devices already have devspecs assigned to them. You assign devspecs to devices that you create. The devspec is the standard TRSDOS format you'll use every time you reference your device:

**two-letter abbreviation*

Your original TRSDOS master diskette is configured with six devices. They are:

Devspec	Device
*KI	Keyboard Input
*DO	Display Output (Video)
*PR	Printer
*SI	Standard Input
*SO	Standard Output
*JL	Job Log

Drivers And Filters

Each device is controlled by its own driver program, filter program, or both. You can change a device's I/O by manipulating its driver or filter program. For more information on drivers and filters see the SET and FILTER commands; see also Appendices I and K.

Section II/ TRSDOS Commands

Section II/ TRSDOS Commands

TRSDOS commands and utilities (typed in at the TRSDOS Ready level) perform a variety of helpful operations:

Diskette Handling commands allow you to prepare your blank diskettes for use or make copies of existing diskettes. Any time you use a blank diskette, you should use this command:

FORMAT

If you want to change the way your computer system starts up and initializes its parameters, you can use *Initialization* commands. For example, you can use the FORMS commands to set your printer's parameters; or you can use the AUTO command to set your computer to AUTOMatically perform a particular function at start-up. The Initialization commands are:

AUTO	BOOT
DATE	FORMS
SETCOM	SETKI
SYSGEN	SYSTEM
TIME	

You might find the *Auxiliary* commands helpful for such functions as seeing what is on your disk or simply seeing what system commands are available. They include:

DEVICE	DIR
DO	FREE
LIB	LIST
LOG	SPOOL
VERIFY	

The *File Handling* commands and utilities allow you to copy, rename, delete, or convert your disk files. These commands include:

APPEND	ATTRIB
BACKUP	BUILD
COMM	CONV
COPY	CREATE
DEBUG	PATCH
PURGE	REMOVE
RENAME	REPAIR
TAPE100	

The *Device Handling* commands allow you to set, filter, route, or reset your devices. Be sure you have a good understanding of devices before you use these commands! These commands include:

FILTER	LINK
MEMDISK	RESET
ROUTE	SET

Machine Language File Handling commands create and execute machine language disk files. These commands include:

DUMP
MEMORY

LOAD
RUN

How to Use This Section

This section contains an alphabetic listing of all TRSDOS commands and utilities. The commands and utilities for advanced programmers are marked as "Advanced Programmer's Utilities" and "Advanced Programmer's Commands."

Commands

Commands are system operations that can be used at TRSDOS Ready.

To see a list of all library commands, use the LIB command. Type:

LIB **(ENTER)**

and the following list is displayed:

Library <A>

Append	Copy	Device	Dir	Do	Filter	Lib
Link	List	Load	Memory	Remove	Rename	Reset
Route	Run	Set				

Library

Attrib	Auto	Build	Create	Date	Debug	Dump
Free	Purge	Time	Verify			

Library <C>

Forms	Setcom	Setki	Spool	Sysgen	System
-------	--------	-------	-------	--------	--------

Utilities

Utilities use some or all of user memory. They return to TRSDOS Ready; under most conditions you cannot use them effectively within programs.

The utilities are:

BACKUP	COMM
CONV	FORMAT
LOG	PATCH
REPAIR	

Entry Organization

Each entry in this section is identified as either a command or a utility.

The command's "syntax" is the first line you see after the keyword. Use it as your guide to type in a command. (See "Syntax" below for details.) If a word or value in the syntax is **highlighted**, you need to type in that word or value for the command to work.

A description of the command or utility follows the syntax. This description tells you what the command or utility does. Next, the entry includes additional information on the parameters of the command. A command may require you to supply some values.

The definition also may offer several "options" that customize the command to your needs. These optional parameters increase the usefulness of the commands but are not necessary for normal operation. Values and options are discussed in the additional parameter information.

Finally, each entry gives examples of the command's use.

Syntax

The command's syntax tells you what format to use when you type the command.

For example, here is the syntax for the REMOVE command:

REMOVE *filespec*, *filespec* . . .

italicized words in a command's syntax indicate values that you supply. In this case, the value that you supply is a filename. Remember that a command's required parameters are **highlighted**, so the beginner can skip values not boldfaced.

If you want to remove the disk file named SAMPLE in Drive 1, type:

```
REMOVE SAMPLE:1 (ENTER)
```

The syntax for the COPY command is:

COPY *source* [TO] *destination* [(parameters)]

Here, you must supply the name of the source filespec you wish to copy and the destination filespec to which you want it copied. Remember that TO is optional and cannot be used as a TRSDOS filespec. For example:

```
COPY NEW/DAT:1 TO NEWDAT/ONE:2 (ENTER)
```

copies the Drive 1 file NEW/DAT onto the diskette in Drive 2 and names the new file NEWDAT/ONE.

The COPY command offers four optional parameters. They are:

LRL
CLONE
ECHO
X

If you need the LRL parameter (the LRL parameter tells TRSDOS to assign a specific record length to a destination filespec), type:

COPY NEW/DAT:1 TO NEWDAT/ONE:2 (LRL=128) **ENTER**

Every command uses some variation of the syntax lines discussed above.

APPEND

APPEND <i>source</i> [TO] <i>destination</i> [(parameters)]	Command
--	----------------

Appends the contents of the *source* onto the end of the contents of the *destination*. (The contents of the source file remain the same.)

You can use APPEND to combine two files on a disk.

The *source* is a valid TRSDOS filespec or input devspec, and *destination* is a valid TRSDOS filespec.

The parameters are:

ECHO echoes the characters to the screen when appending a device to a file.

STRIP backspaces the destination file one byte before the append begins. Use this parameter with files, such as SCRIPSIT files, that have an "internal end of file marker."

Examples

```
APPEND EAST/DAT:1 TO WEST/DAT:0 (ENTER)
```

adds the information in EAST/DAT on Drive 1 onto the end of the information in WEST/DAT on Drive 0.

```
APPEND *KI TO WEST/DAT:0 (ENTER)
```

appends the information that you type on the keyboard to the end of WEST/DAT on Drive 0. Press (CONTROL)(SHIFT)(@) (at the same time) to end the append.

```
APPEND *KI TO WEST/DAT:0 (ECHO) (ENTER)
```

displays what you are appending to WEST/DAT as you type it. Press (CONTROL)(SHIFT)(@) (at the same time) to end the append.

Error Conditions

If the records in *source* and *destination* are not the same length, then an error message appears.

APPEND is mainly for data files since it works only with files containing ASCII text. You cannot APPEND program files that are in the "load module format." **Also, you cannot APPEND BASIC programs unless they are saved in the ASCII format.**

Some programs (such as SCRIPSIT) place a special marker at the end of a file. If this marker is in the file, you must use the STRIP parameter when appending to it. If you do not use the STRIP parameter, the program ignores the appended section of the file. Consider the following example:

APPEND EAST/DAT:1 TO WEST/DAT:0 (STRIP) **ENTER**

copies the information from EAST/DAT to WEST/DAT as in the above example, except that the first byte of EAST/DAT to overwrite the last byte of WEST/DAT.

Error Conditions

When an APPEND aborts with an error, the destination file involved in the APPEND may be left open. Use the RESET library command to close the file.

Sample Uses

Suppose you have two data files, PAYROLL/A and PAYROLL/B.

PAYROLL/A	PAYROLL/B
Atkins, W. R.	Lewis, G. E.
Baker, J. B.	Miller, L. O.
Chambers, C. P.	Peterson, B.
Dodson, M. W.	Rodriguez, F.
Kickamon, T. Y.	

You can combine the two files with the command:

APPEND PAYROLL/B TO PAYROLL/A **ENTER**

PAYROLL/A now looks like this:

PAYROLL/A

Atkins, W. R.
Baker, J. B.
Chambers, C. P.
Dodson, M. W.
Kickamon, T. Y.
Lewis, G. E.
Miller, L. O.
Peterson, B.
Rodriguez, F.

PAYROLL/B is unaffected. To see the APPENDED file, type LIST PAYROLL/A.

ATTRIB

Assigns protection passwords and attributes to a particular file or a group of files.

You can use ATTRIB to protect a file with passwords.

Command
ATTRIB <i>filespec</i> (<i>parameters</i>)

For *filespec* ATTRIBs, the parameters are:

USER = "*password*" sets the user password to *password*. If this parameter is omitted, the user password remains the same. If USER = is specified with no *password*, then any current user password is removed.

OWNER = "*password*" sets the owner password to *password*. If this parameter is omitted, the owner password remains the same. If OWNER = is specified with no *password*, then any current owner password is removed.

PROT = *level* specifies the protection level that is enforced if the user password is specified. If this parameter is omitted, the level is unchanged. You have to give a file an OWNER password before you can set PROT. The optional levels for access to a file are:

EXEC	Execute only
READ	Read and execute
UPDATE	Update, read, and execute
WRITE	Write, update, read, and execute
RENAME	Rename, write, update, read, and execute
REMOVE	Remove, rename, write, update, read, and execute (allows total access except for changing attributes with the ATTRIB command.
FULL	Allows total access

VIS specifies the *filespec* as visible in the directory

INV specifies the *filespec* as invisible in the directory. Use the INV parameter to reduce the number of files that TRSDOS displays when you issue a DIR command.

You can abbreviate the levels of PROTection to their first two letters except for RENAME and REMOVE, which you can abbreviate to RN and RM respectively.

Command
ATTRIB [<i>:drive</i>] (<i>disk parameters</i>)

For disk ATTRIBs, the parameters are:

LOCK protects all visible files not currently protected by setting their user and owner passwords to the disk master password.

UNLOCK removes the user and owner passwords from visible files if their passwords match the disk master password.

MPW = "*password*" states the disk's current master password. If you don't specify this option, TRSDOS prompts you for it, if the password is not PASSWORD.

NAME[= "*disk name*"] specifies the new disk name. If this parameter is omitted, the disk name remains the same.

PW[= "*password*"] sets the new disk master password to *password*. If this parameter is omitted, the disk master password remains the same.

PW cannot be abbreviated.

drive defaults to Drive 0.

Assigning Protection Attributes To a File

Using the Owner and User Passwords. Passwords are first assigned when the file is created. At that time, the **owner** and **user passwords** are set at the same value (either the password you specified, or a blank password if you did not specify one).

ATTRIB allows you to assign a file two different passwords. The user password could be for the operator. It protects a file's contents at a certain protection level (set by PROT). For example, if you want an operator to have limited access to a file, you can set the PROTECTION level to READ. Then, using the user password, the operator will be able only to read (list) and execute the file, not change, rename, re-attrb, or remove it.

In the same manner, the owner password could be for the programmer. Using the owner password, the programmer could change, remove, re-attrb, or rename the same file. (When you use the owner password to access a file, TRSDOS ignores the PROTECTION level.)

In short, the user password allows limited access to a file and the owner password allows total access.

Examples

```
ATTRIB CUSTFILE/DAT:1  
(USER=,OWNER="BOSSMAN",PROT=READ) ENTER
```

sets the user password blank (so no password is necessary to access the file), sets the owner password to BOSSMAN, sets the protection level to read and execute only.

```
ATTRIB CUSTFILE/DAT,BOSSMAN  
(USER="SECRET",PROT=EXEC,INV) (ENTER)
```

re-attribs CUSTFILE/DAT. Note that the owner password BOSSMAN was required to re-attrib the file. Now, CUSTFILE/DAT has the user password SECRET, keeps owner password BOSSMAN, has the protection level of execute only, and is invisible in the directory.

Assigning Protection Attributes To a Disk

The ATTRIB command also allows you to change the disk name, the disk master password, and the password protection of all visible filespecs.

Examples

```
ATTRIB (UNLOCK,NAME="MYDISK") (ENTER)
```

removes all user and owner passwords from the visible filespecs on Drive 0 if the filespecs' current password matches the disk master password. It also changes the disk name to MYDISK. Since the current master password was not specified with the MPW parameter, your computer asks you for it (if it is other than PASSWORD) before it executes this command.

```
ATTRIB :1  
(NAME="DATA",PW="SECRET",MPW="BOSSMAN") (ENTER)
```

sets the disk name in Drive 1 to DATA, changes the master password to SECRET if the current disk master password is BOSSMAN.

```
ATTRIB (LOCK) (ENTER)
```

prompts you for the disk's master password (if other than PASSWORD) and changes the user and owner passwords of all visible, non-password protected files to the disk's current master password. Since no drive was specified, the command is carried out on Drive 0.

```
ATTRIB :1 (NAME) (ENTER)
```

prompts you for Drive 1's disk master password (unless it is PASSWORD). It then prompts you for the new disk name.

Sample Uses

Suppose you have a data file, PAYROLL, and you want an employee to use the file in preparing paychecks. You want the employee to be able to read the file but not to change it. Then use a command like:

```
ATTRIB PAYROLL (I,USER="PAYDAY",OWNER="BANANA"  
PROT=READ) (ENTER)
```

Now tell the clerk to use the password PAYDAY (which allows read only); while only you know the password, BANANA, which grants total access to the file.

AUTO

AUTO [*parameters*] [*][*command line*]

Command

Stores an *AUTO command line*. This *command line* automatically executes whenever you start up or reset TRSDOS. (That is, after you enter the date and time, TRSDOS loads, executes the command line, and displays the TRSDOS Ready or BASIC prompt.)

You can use AUTO to automatically run a program after you type in the date.

command line is limited to 74 characters in length.

The *parameters* are:

:drive specifies which drive to store the AUTO command line on.

?[:*drive*] displays any AUTO command line stored on *drive*. (The default is Drive 0.)

=[:*drive*] executes any AUTO command line stored on *drive*. (The default is Drive 0.)

In most cases, you can override the AUTO command during start-up or reset by (1) holding down the **(ENTER)** key, or (2) pressing **(BREAK)** while the auto command is executing.

The exception to this is when you store the AUTO command with the * parameter (which disables the **(BREAK)** key and the ability of the **(ENTER)** key to override AUTO).

If the AUTO command disables the **(BREAK)** key and the program is non-functional, gaining control of the disk requires several steps. To regain control:

1. Start up the system with another non-AUTOed disk in Drive 0.
2. When TRSDOS Ready appears, place the non-functional disk in Drive 0.
3. Type AUTO and press **(ENTER)**, and the runaway AUTO command is removed from the disk.

Use the *:drive* parameter to place an AUTO command on a drive other than Drive 0.

Examples

AUTO BASIC **(ENTER)**

loads the BASIC program whenever you start up or reset on Drive 0.

AUTO **(ENTER)**

Turns off the AUTO function currently stored on Drive 0.

AUTO *DO INIT/JCL:1 **(ENTER)**

executes the DO file on Drive 1 named INIT/JCL whenever you start up or reset. Notice that the * parameter is used. This means the operator cannot use **(ENTER)** to halt the auto command; **(BREAK)** is also disabled.

AUTO :1 DEVICE **(ENTER)**

places the AUTO command DEVICE on Drive 1.

AUTO ?:1 **(ENTER)**

displays the AUTO command on Drive 1.

AUTO =:1 **(ENTER)**

executes the AUTO command on Drive 1.

Error Conditions

To place an AUTO command on a disk, it must be write-enabled.

The system does not check the command line for errors when you first enter the AUTO command line. Errors are detected when the command is executed.

Sample Use

Suppose you want the DEVICE library command to execute automatically when you restart your computer.

Do this by issuing the command:

AUTO DEVICE **(ENTER)**

BACKUP

Utility

BACKUP [*partspec*][:*source drive*][TO][:*destination drive*]
[(*parameters*)]

Duplicates (backs up) all or some of the files from *source drive* to *destination drive*.

You can use BACKUP to copy the contents of one disk to another.

Use the *parameters* to tell the system which group of files to duplicate. Use the *partspec* option to choose a group of files by name or extension. (See the Examples.) If no *parameters* or *partspec* are specified, all visible files are duplicated (unless the diskette types are the same, in which case TRSDOS performs a mirror-image backup).

Note: In most cases, you can see which files a BACKUP command would duplicate by issuing a DIR command of *source drive* using the same *partspec* and *parameters* as the BACKUP command.

If you do not specify *source drive* and *destination drive*, the system prompts you for them. If the source disk has a Master Password other than PASSWORD, and you do not state it with the MPW = parameter, the system prompts for it as well.

If the destination drive is not ready, the message "Insert DESTINATION disk <ENTER>" is displayed. Insert the destination disk and press **ENTER** to continue, or press **BREAK** to return to TRSDOS Ready.

The destination disk must be formatted before the backup begins. To format a disk, see the FORMAT command.

The parameters are:

MPW = "*password*" specifies the source disk's Master Password

SYS backs up system files as well as the visible files

INV backs up invisible files as well as the visible files

MOD backs up files that have been modified since the last backup

QUERY = YES questions you about each file before it is backed up

OLD backs up only those files that already exist on the destination disk

NEW backs up only those files that do not already exist on the destination disk

X allows backups with no system disk in Drive 0

DATE = "*M1/D1/Y1-M2/D2/Y2*" backs up files with modify dates between the two specified dates, inclusive. *M1/D1/Y1* must be before *M2/D2/Y2*.

-
- = "M1/D1/Y1" backs up files with modify dates equal to the specified date
 - = "-M1/D1/Y1" backs up files with modify dates before or equal to the specified date
 - = "M1/D1/Y1-" backs up files with modify dates after or equal to the specified date

MPW cannot be abbreviated.

When you specify QUERY = YES, the system questions you for each file before it is copied. Answer by pressing:

- ☐ **Y** to copy the file.
- ☐ **N** or **ENTER** to bypass the file and move on to the next one.
- ☐ **C** to copy the file, turn off the Query function, and automatically copy all remaining files.

After you type the BACKUP command, TRSDOS automatically performs one of the three types of backups: "mirror image," "backup by class," and "backup reconstruct." The difference between the three is of technical interest and is discussed in "General Information."

NOTE: A backup by class and backup reconstruct require two disk drives.

For information on backing up "backup limited" diskettes, see Appendix M, "Backup Limited Diskettes."

Backups With the (X) Parameter

When you specify the (X) parameter, you do not have to have a system disk in Drive 0 when you back up a disk. TRSDOS prompts you to insert the proper disks in the proper drive.

Examples

```
BACKUP $:0 :1 (SYS,INV) ENTER
```

examines all files on the disk in Drive 0 and copies all files to Drive 1, because all files match the \$ partspec. The partspec causes a backup by class.

NOTE: You can use this command to force a backup by class in situations where a mirror image would normally be performed. For example, it reduces fragmentation of files on the source disk by copying them in a more contiguous manner onto a newly formatted destination disk.

```
BACKUP :0 :1 (MOD,QUERY=YES,MPW="SECRET") ENTER
```

copies all visible files from Drive 0 to Drive 1 that have been modified (written to) since the last backup. It questions you for each file before it is copied, showing the file's mod date and flag. The (MPW=) parameter states the Master Password, so the system does not prompt you for it.

BACKUP \$/CMD:0 :1 (ENTER)

copies all visible files with the extension /CMD from Drive 0 to Drive 1. If the file already exists on Drive 1 it is overwritten. No other files on Drive 1 are touched. A backup by class is performed.

BACKUP /\$S:1 :2 (ENTER)

backs up all files whose extensions are three characters long and end with the letter S. The \$ wildcard masks the first two characters of the extension, so extensions such as /BAS, /TSS, and /TRS form a match. A backup by class is performed.

BACKUP :1 :1 (ENTER)

backs up between two disks in Drive 1. You are prompted to switch the source disk and destination disk at the appropriate times.

The disks used in this type of backup must allow a mirror image backup, or the backup aborts.

This command and the following command could be used to back up a data disk.

BACKUP :0 :1 (X) (ENTER)

backs up the disk in Drive 0 to the disk in Drive 1. Its main use is to back up non-system disks, such as data disks, in a two-drive system.

When you use this parameter, you are prompted to insert the proper disk in Drive 0. You may be prompted to re-insert a system disk into Drive 0 during certain backups.

When the backup is complete, you are prompted to insert a system disk back in Drive 0.

BACKUP -/CMD:0 :1 (ENTER)

backs up all visible files from Drive 0 to Drive 1, EXCEPT those files that have a /CMD extension. A backup by class is performed.

BACKUP :1 :2 (NEW,QUERY=YES) (ENTER)

backs up only those visible files from Drive 1 that do not already exist on Drive 2. You are prompted before each file is moved.

BACKUP /ASM:3 :2 (DATE="05/06/82-05/10/82")
(ENTER)

backs up all visible files with the extension /ASM, whose modify dates fall on or between the specified dates.

Error Conditions

The destination disk must be formatted before the backup begins. To format a disk, see the FORMAT command.

For a backup by class, if the backup is to include system files, the destination disk must be newly formatted. BACKUP can't create a system disk if the destination disk contains data files. (Existing files may be using certain areas needed by the system.)

If you are backing up the entire disk, TRSDOS compares the source and destination disk Disk ID's to make sure they are identical. If the master passwords or disk names differ, you see the following message:

```
Destination disk ID is different --
NAME=disk name
DATE=mm/dd/yy
Are you sure you want to backup to it <Y,N>?
```

Press **(N)** to abort the BACKUP or **(Y)** to continue.

If the disks' master passwords differ, the following message appears:

```
Destination disk ID is different -- NAME=disk
name
DATE=mm/dd/yy
Enter its Master Password or <Break> to abort:
```

Press **(BREAK)** to abort the BACKUP or enter the password to continue.

If the source and destination disks have a different number of cylinders, the following message appears:

```
Cylinder counts differ - Attempt mirror-image
backup ?
```

Answer this question with **(Y)** to attempt a mirror image backup or with **(N)** to force a backup reconstruct.

If a mirror image backup is not possible, you get the error:

```
Backup aborted, destination not mirror-image
```

This appears if the destination disk is missing a cylinder that contains information on the source disk. This might be the case if the destination disk was formatted with fewer cylinders than the source disk, or if cylinders were locked out on the destination disk when it was formatted. You can use the FREE library command to check the destination disk for locked out cylinders.

After all the cylinders that contain data are copied to the destination disk, BACKUP attempts to remove the modification flags from the files on the source disk. If the disk is write protected, the following message appears:

```
Source disk is write protected; MOD flags not
updated
```

Backup by class may NOT be done on a single drive.

General Information

Mirror Image Backup. A mirror image backup is basically a cylinder-for-cylinder copy from the source to the destination disk. (Only those cylinders that actually contain data are copied.) When the backup is complete, the destination disk is an exact copy, or mirror image, of the source disk.

Backup By Class. A backup by class takes place if you specify a partspec or any parameter except X or MPW in the command line.

Backup Reconstruct. A backup by class and a backup reconstruct function identically. The only difference is that while **you** initiate a backup by class, the **system** initiates a backup reconstruct.

On certain TRSDOS application programs, you can only make a limited number of backups. And, when you make a backup on one of these programs, the source disk has to be write-enabled during the backup or the backup fails.

Backups With the (X) Parameter. This parameter allows you to back up data disks of different sizes or capacities on a two-drive system (using backup reconstruct). One-drive system can perform mirror-image backups only. When you use the (X) parameter to backup non-system disks of different sizes or capacities, system modules 2, 3 and 10 must first be put into memory with the SYSTEM (SYSRES=*number*) command. Remember that the (X) parameter is used only when there is a non-system disk in Drive 0.

Mirror Image Backup. TRSDOS makes a mirror image backup if the source and destination disks' size and density are identical, and if you specify no partspec or parameters (except X or MPW) in the command line. The number of cylinders doesn't need to be identical as long as the destination disk has at least as many cylinders as the source disk.

The date on the destination disk shown with the DIR or FREE library commands is changed to the current system date.

After the backup, the destination disk has its directory on the same track as the source disk regardless of where it was before the backup. The information on the destination disk is updated to reflect its true cylinder count and available free space.

Backup By Class. This type of backup does a file-for-file copy from the source to the destination disk. Files that are fragmented (spread over more than one extent) on the source disk are consolidated (if possible) on the destination disk.

Unlike a mirror image backup, files that exist on the destination disk but are not on the source disk are not touched in the backup. When the backup is complete, the destination disk contains all files moved from the source disk plus any other files that existed on the destination disk before the backup began.

-
- The destination Disk ID is not changed by the backup.

When the file SYS0/SYS is included in a backup by class, the destination disk is configured in the following manner:

1. The state of the SYSGEN (on or off) is changed to match that of the source disk.
2. The initial date and time prompts (on or off) on power-up are set to match those of the source disk.
3. The default drive configurations match those of the source disk.

Backup Reconstruct. The system performs a backup reconstruct when the size or the density differs between the source and destination disks.

DIR/SYS and BOOT/SYS are not moved to the destination disk in this type of backup.

When a backup by class or a backup reconstruct occurs, only the type of files specified will be moved. (This is a departure from the Model III hard disk operating system LDOS 5.1.3.) For example, if you are moving files to a hard disk with the command `BACKUP :5 :2`, a backup reconstruct is invoked because the two disks are of different sizes. This command moves only the visible files.

If you want all of the files to be moved, then you must use the command `BACKUP :5 :2 (SYS,INV)`. This moves visible, invisible, and system files to the destination disk.

Hard disk users should note that system files are stored in specific places in the directory. If you use `BACKUP` to move the visible files and then repeat the command with the `SYS` option, the backup aborts if the directory positions required for the system files are already in use. If this happens, you can use the `PURGE` command to delete the files that were moved to the disk, and then give the `BACKUP` command with the `SYS` option.

Sample Use

Suppose you have a payroll disk where all of the new employees have a file with an extension of `/NEW` and all of the old employees have a file with an extension of `/OLD`.

Now suppose you want to have two separate disks: one with old employee files and one with new employee files. You could issue the command:

```
BACKUP /NEW:0 :1 ENTER
```

to move all of the files of new employees from the master disk in Drive 0 to another disk in Drive 1.

BOOT

	Command
BOOT [<i>keys</i>]	

Resets (boots) TRSDOS by returning it to its original start-up condition.

You can use BOOT to return your computer to the TRSDOS copyright and startup message.

The keys are:

(CLEAR) allows no sysgened configuration to take place.

(ENTER) allows no breakable AUTO commands to occur.

(D) enters the system debug. No sysgened configuration is loaded.

Note: When you use one or more of these keys, you must press and hold them down when the screen is erased and keep them down until the TRSDOS Ready message or the DEBUG display appears. If you are prompted for the date, you must hold down the keys as soon as you type the date and press **(ENTER)**. If you don't press the keys in time, simply reset and hold the keys down as soon as the screen clears.

BOOT loads the TRSDOS system in floppy Drive 0 back into the computer. It returns the computer back to its normal power-up configuration as if the system had been turned off and then turned on again.

Examples

Remember to hold down the key after you press **(ENTER)** until you see TRSDOS Ready or the debug display.

BOOT **(ENTER)**

resets the system.

BOOT **(ENTER) (CLEAR)**

returns the system to its original start-up condition and ignores any sysgened configuration.

BOOT **(ENTER) (ENTER)**

returns the system to its original start-up condition and ignores any breakable AUTO commands.

BOOT **(ENTER) (D)**

returns the system to its original start-up condition and enters the system debug. No sysgened configuration is loaded, and any AUTOed command is not executed. Note: If the AUTOed command is unbreakable, **(D)** is ignored.

BUILD

BUILD *filespec* [(parameters)]

Command

Lets you enter data (such as commands) and save it on disk as *filespec*. If you do not specify an extension to *filespec*, it defaults to *JCL*.

You can use BUILD to make a file on a disk.

The parameters are:

HEX accepts data in hexadecimal format only.

APPEND appends the BUILD data to the end of *filespec*.

Although you can build any type of data file with this command, it is mainly for creating files to be executed with the DO command, KSM/FLT, or the PATCH utility.

The HEX parameter lets you input data in hexadecimal form (see Appendix C for a listing of hexadecimal characters). You can use hex to generate control characters and graphics symbols which are not available from the keyboard.

The APPEND parameter lets you add data to the end of an existing file.

Some programs (such as SCRIPSIT) place their own marker at the end of a file. If this marker is in the file, you cannot append BUILD data to it unless you:

- Use the BUILD command to create a new file containing the information you wish to append.
- Use the APPEND library command with the STRIP parameter to properly append the new information to the existing file.

Building a File

When you enter the BUILD command with a non-existing *filespec*, BUILD creates the file and then allows you to insert lines.

You can enter a command line of up to 255 characters. JCL files are limited to 79 characters per line. To end a line, press **(ENTER)**.

To end the file, press **(CONTROL)(SHIFT)(@)** at the beginning of a new line. The system returns you to TRSDOS Ready.

Examples

BUILD DISPLAY:2 **(ENTER)**

creates a new file named DISPLAY/JCL on Drive 2. TRSDOS allows you to insert lines. Type:

```
DEVICE (ENTER)
FREE :0 (ENTER)
FREE (ENTER)
(CONTROL)(SHIFT)@
```

The first three lines insert the DEVICE, and FREE :0 and FREE commands into the "DISPLAY" file. Pressing (CONTROL)(SHIFT)@ tells TRSDOS that you are finished entering command lines. The system returns to TRSDOS Ready.

Now, whenever you type:

```
DO DISPLAY (ENTER)
```

TRSDOS executes the file by displaying the device table, the free space map of Drive 0, and the free space information for all enabled drives.

```
BUILD MYKEYS/KSM (ENTER)
```

builds MYKEYS on the first available drive. Since the /KSM extension was used, a KSM file is built. See the KSM/FLT filter in Appendix I for more information.

```
BUILD SPECIAL/:0 (ENTER)
```

builds SPECIAL on Drive 0. Adding the "/" allows SPECIAL to be built without an extension.

```
BUILD MYJOBS/JCL (APPEND) (ENTER)
```

searches all available drives for MYJOBS/JCL (until it is found) and adds the information from this build to the end of the file. If MYJOBS/JCL is not found, the file is built on the first available drive.

```
BUILD MYPROGA/FIX:0 (ENTER)
```

builds MYPROGA/FIX, which is to be used with PATCH. See the PATCH utility for more information.

```
BUILD DISPLAY/BLD (HEX) (ENTER)
```

builds a file on the first available drive, allowing data to be entered in hexadecimal format. Information is entered into this file as hexadecimal bytes (with no spaces or other delimiters between them).

The HEX parameter allows you to enter characters not directly available from the keyboard, such as control, printer control, and graphics characters. You can enter any one-byte character value.

A hex build allows 127 hex byte representations (254 characters) per logical line. Logical lines may continue on more than one physical line

as long as a "0D" logical line terminator does not appear. Also, more than one logical line can appear on one physical line.

To create a character string containing graphics characters, type:

```
B1BA90A10D (ENTER)
```

This line contains the hexadecimal bytes 81, 8A, 90, and A1. Notice that the byte values are packed together. "0D" ends a logical line, and (ENTER) ends a physical line.

If a non-hex digit is entered, the error message "Bad hex digit encountered" is displayed and the build aborts.

Error Conditions

If the filespec you specify already exists, you will get the error message "File already exists" (unless you specify the APPEND parameter).

Sample Use

Suppose you want to build a file to be used with the PATCH command. Issue the command:

```
BUILD PROG/FIX (ENTER)
```

and enter the patch lines.

COMM devspec [(parameters)]

Utility

Lets two computers communicate via a device, usually the RS-232 communications line.

You can use COMM to let your computer talk with another computer.

COMM lets your computer:

- be used as a terminal in communicating with another computer.
- transfer files to and from another computer.
- spool output from the other computer to your printer.

Using COMM, you can access:

- Bulletin Board Systems
- News and Information Systems
- Timesharing Systems
- Electronic Mail Services

COMM can also communicate with systems that support XON/XOFF (Proceed/Pause) protocol. This is a protocol that uses two control codes named Device Control 1 and Device Control 3. (The Device Control codes are discussed in the **CLEAR** **SHIFT** ***** command section.)

devspec is usually *CL, the RS-232C communications line.

Note: Before you can use *CL, you have to SET it to its driver program COM/DVR. See Appendix I.

The *parameters* are:

XLATES = X'aabb' translates a character being sent.

XLATER = X'aabb' translates a character being received.

XON = X'cc' changes the XON code.

XOFF = X'cc' changes the XOFF code.

aa is the character to be translated.

bb is the character aa is translated into.

cc is the new value of XON or XOFF.

Enter hexadecimal values in the format X'nnnn'.

NULL = OFF prevents any nulls (ASCII value 0) from being received.

XLATES and XLATER can be abbreviated to XS and XR.

XLATES and XLATER let you translate a character that you send and a character that you receive from another computer. (Only one character can be translated in each direction at any one time.)

Example

Suppose you are using COMM as a terminal to communicate with another computer, and you want to print a right bracket (]). It appears that you can't because there is no key on your keyboard that produces this character.

Use the XLATES parameter to produce a (]) by entering another character from the keyboard. Type:

```
XLATES=X'025D'
```

Now when you press **CTRL B** (hexadecimal 02), your computer sends the code for a right bracket (hexadecimal 5D) to the other computer. Since the Model 4 can display a right bracket when it receives a hex 5D, there is no need to use XLATER to translate the received character.

Characters that you receive from another computer can be translated to a different symbol using XLATER. Use the same method that we used for XLATES.

See Appendix C for a list of characters and their hex values.

The Function Keys

The Function Keys are used to:

1. Direct the flow of data (text or software) from device to device.
2. Enable and disable certain functions of COMM, including XON/XOFF and full/half duplex operation.

The Function Keys are divided into two groups: (1) the Application keys and (2) the Action keys.

The Application and Action keys are achieved by holding down all of the keys in the sequence, such as **CLEAR 6** (hold down **CLEAR** and then press **6**).

The Application Keys

The Function Keys **CLEAR 1** through **CLEAR 6** designate what device an action applies to.

Function Key	Device	Abbreviation
CLEAR 1	Keyboard Device	(*KI)
CLEAR 2	Display Device	(*DO)
CLEAR 3	Printer Device	(*PR)
CLEAR 4	Communications Line Device	(*CL)
CLEAR 5	"Data Send" Device	(*FS)
CLEAR 6	"Data Receive" Device	(*FR)

Action Keys

The remaining Function Keys perform an action. Some action keys require you to specify an application key (**CLEAR** 1 through **CLEAR** 6) before you can perform the action.

CLEAR 7

Causes the contents of the "Data Received" (*FR) area in memory to be written to disk. This is called "Dump-To-Disk" or DTD. DTD may be turned ON before or after a file is received. (You must turn DTD ON if a file will exceed the size of the *FR memory area.)

When you start COMM, DTD is ON. When you perform an *FR RESET (**CLEAR** 6 **CLEAR** 0), DTD is turned OFF. To turn it ON again, press **CLEAR** 7 followed by **CLEAR** :


If you are writing data to floppy disks and the RS-232 port is running at a speed higher than 300 baud, you have to wait until you receive an entire file before turning DTD ON.

CLEAR 8

Displays the MENU of Function Keys on the display. You can use this command any time.

The display goes from left to right. This is not intended to be a complete menu, but a built-in "quick reference" card.

The screen display is altered to display the menu. Any data you receive while the menu is displayed is not lost because COMM saves the data in a special area of memory. This data appears on the screen after the menu is displayed.



-
1. The devices and functions. (The asterisks above and below the function keys indicate that the function is active.)
 2. The amount of available memory.
 3. Asterisks for the shifted function keys.
 4. Asterisks for the unshifted functions keys.
 5. Two asterisks denote a device capable of both input and output.
 6. One asterisk denotes a device capable of either input or output.
 7. If HANDSHAKE is active, the auto XOFF character selected is shown in hex.
 8. Displayed filespec of any *FS or *FR filespec.

CLEAR **9**

Specifies what file to use when you send or receive data. After you specify the file, your computer opens it. If you specify a file that does not exist, COMM creates it.

To specify the name of a receiving file, press **CLEAR** **6** followed by **CLEAR** **9** and answer the following prompt:

File Name:

COMM opens the file but does not set aside an area of memory to receive the data, so any incoming data is ignored.

To save incoming data, enter the command **CLEAR** **6** followed by **CLEAR** **:**. Now, data received is placed in the "Data Received" (*FR) area of memory, and the data is eventually placed in the file you specified. (See **CLEAR** **:** for more information on activating devices.)

If a file is already open, the system aborts your **CLEAR** **9** command and prints the warning message:

File Already Open

This warning prevents you from opening another file before closing this one. This protection also applies to files associated with the "Data Send" (*FS) area of memory.

CLEAR **0**

Closes either a receive file or a send file. You must close a receive file so its directory can be updated, and so you can receive another file. If you reset a device, its buffer is cleared.

You must turn OFF the *FR or *FS device before you can close the associated file. (See **CLEAR** **-** for information on turning OFF devices.)

CLEAR **:**

Turns ON a device. This is the second command of a two-command sequence.

For example, if you want to turn ON the printer, first press **CLEAR** **3** to indicate that you want to do something with the printer, and then press **CLEAR** **:** to indicate that you want to turn it ON. Press **CLEAR** **3** followed by **CLEAR** **-** to turn the printer OFF.

CLEAR **-**

Turns OFF a device. This is the second command of a two-command sequence.

For example, if you want to turn the printer OFF, first press **CLEAR** **3** to indicate that you want to do something with the printer, and then press **CLEAR** **-** to indicate that you want to turn it OFF. Press **CLEAR** **3** followed by **CLEAR** **:** to turn the printer ON.

CLEAR **SHIFT** **!**

This is the DUPLEX control, which allows you to select Full-Duplex or Half-Duplex.

Full-Duplex and Half-Duplex indicate how data is sent from one computer to another on an RS-232C line.

- Half-Duplex is used with a computer that cannot read data while it is sending it or send data while it is receiving it. A **CLEAR** **SHIFT** **!** followed by a **CLEAR** **:** indicates Half-Duplex.
- Full-Duplex is used with a computer that can read data while it is sending it or send data while it is receiving it. A **CLEAR** **SHIFT** **!** followed by a **CLEAR** **-** indicates Full-Duplex operation.

When you start COMM, it is set to Full-Duplex (Duplex off).

Some computers and terminals combine Duplex and Echo functions, so you should know something about the computer or terminal you are communicating with.

CLEAR **SHIFT** **"**

Controls character "Echo"ing. Press **CLEAR** **SHIFT** **"** followed by **CLEAR** **:** to turn Echo ON.

You should turn Echo ON if you are communicating with a computer or terminal that is operating in full-duplex, but does not display a copy of characters it is transmitting to you (called Local Copy).

Turning Echo ON causes your computer to transmit each character it receives back to the computer that sent it. This lets the person operating the other computer see what is being transmitted.

Caution: If both ends are set for Echo ON, then the first character sent is echoed back and forth indefinitely — or until one end turns Echo OFF.

(CLEAR)(SHIFT)(#)

This command controls Echoing linefeeds. When enabled, any carriage return your computer receives causes a linefeed character to be transmitted back to the other computer.

This command is useful since there are a large number of terminals and computers that treat a carriage return (ASCII 13) and linefeed (ASCII 10) as separate functions.

When you are communicating with another TRS-80 computer, you can turn OFF this function by pressing **(CLEAR)(SHIFT)(#)** followed by **(CLEAR)(-)**.

(CLEAR)(SHIFT)(S)

Controls the ability of your computer to accept a linefeed. COMM usually ignores the first linefeed after a carriage return, since most computers send both a carriage return and a linefeed.

In most cases, this command is not necessary on TRS-80's where an **(ENTER)** is treated as both a carriage return and linefeed.

(CLEAR)(SHIFT)(%)

Positions to the start of an *FR or *FS file, so you can start again. For example, if you are receiving a file and it aborts with an error, you can startover by pressing **(CLEAR)(6)** followed by **(CLEAR)(SHIFT)(%)**. Then you can attempt to receive the file again.

(CLEAR)(SHIFT)(&)

Appends new data to the end of a file. This command applies to the "Data Received" (*FR) area of memory only. If you open an existing file and then press **(CLEAR)(6)** followed by **(CLEAR)(SHIFT)(&)**, you can append new data to the end of the file.

(CLEAR)(SHIFT)(')

Displays control characters that are being received or sent. You can use this command to detect if you are receiving unwanted control characters. If you are receiving unwanted control characters, you can use the XLATER to translate them.

(CLEAR)(SHIFT)(I)

Erases the contents of the screen and places the cursor in the upper left corner. No data is transmitted.

(CLEAR)(SHIFT)(J)

When followed by an ON command (**(CLEAR)(:)**), your computer uses all 8 bits of a character it receives. Normally, bit 8 is either not present or invalid, so COMM removes it from each character it receives.

Do not turn this option ON unless the RS-232C word length is set to 8. You can use the SETCOM library command to set the word length before you enter COMM.

CLEAR SHIFT 0

Allows you to enter a TRSDOS **library command** from COMM.

For example, when you type:

DEVICE **ENTER**

the device table is displayed on your screen. The message "Command complete" is displayed below the device table.

NOTE: If the specified library command attempts to change HIGH\$, the command aborts and TRSDOS returns you to COMM.

CLEAR SHIFT *

This command controls the handshaking on the data line.

Handshaking is the agreed-upon method that two communicating computers use to control the flow of data between them. If this option is turned ON, COMM responds to the following codes when your computer receives them from the communications line:

Symbol	Value	Description
DC1	17 X'11'	— Resume transmission (XON or Proceed character)
DC2	18 X'12'	— Turns the *FR device ON
DC3	19 X'13'	— Pause transmission (XOFF or Pause character)
DC4	20 X'14'	— Turns the *FR device OFF

NOTE: You can use the XON and XOFF parameters to change the codes to other values when entering COMM.

The above codes are part of the ASCII standard. DC1 and DC3 control the device that is transmitting data. They tell it when to start and stop transmitting.

DC2 and DC4 control the recording device. They tell it when to start and stop recording. These codes use the "Received Data" device (*FR) to accumulate the received data. If you use DC2 and DC4, be sure you have created an *FR file with **CLEAR 6** and **CLEAR 9**.

When a DC3 is received, it suspends transmission through the *CL device until a DC1 is received. Any characters that are received are accepted, but none are transmitted. You can override a received DC3 with the *CL ON command (**CLEAR 4** **CLEAR :**).

Handshaking can also be activated when a given character is transmitted. Do this by pressing **CLEAR** **SHIFT** ***** followed by the character you want to pause on.

Typically, the **ENTER** key is specified so that line-at-a-time transmission occurs with automatic pausing at the end of each line.

When handshaking is ON, COMM pauses transmission whenever the specified character is transmitted until it (1) receives a DC1 from the other system, or (2) receives a *CL ON command from the keyboard.

CLEAR **SHIFT** **=**

Exits to TRSDOS Ready. It does not require any ON or OFF code.

Before COMM stops running, it checks the "Data Received" device (*FR) to see if any open files exist. If there is an open file, COMM closes it before it exits to TRSDOS. This feature prevents you from having unclosed files in your system.

Quick Reference Label

If you are a beginning COMM user, you may find it helpful to make a label containing each key's function and place the labels directly above the keyboard. Label the keys as follows:

Key	Unshifted	SHIFTed
1	*KI	Duplex
2	*DO	Echo
3	*PR	Echo-Linefeed
4	*CL	Accept-Linefeed
5	*FS	Rewind File
6	*FR	Position @ EOF
7	DTD	DCC
8	Menu	Clear Screen
9	ID	8-bit mode
0	Reset	Command
:	On	Handshaking
-	Off	Exit

Logging-On to CompuServe

You can use your Model 4 and COMM to log-on to CompuServe. To log on to CompuServe, you must first buy a Universal Sign-Up Kit (Radio Shack Cat. No. 26-2224). Next, follow these steps:

1. First, use the SET command to SET *CL to COM/DVR (see Appendix I). Then issue the command:

SETCOM (WORD=8,PARITY=OFF,STOP=1) **ENTER**

2. Type:

COMM *CL **ENTER**

-
3. Now you need to dial CompuServe's number that comes in the Universal Sign-Up Kit. Depending on which modem you are using, you either dial the number on a phone or you must enter the commands that cause the modem you are connected to dials the number for you. See your modem manual for the correct procedure.
 4. After the number is dialed, wait for a "carrier tone" that CompuServe sends to tell you that you are connected.
 5. Now press **CONTROL C** to send a hexadecimal value of 03 to CompuServe.
 6. CompuServe prompts you on your video display with:

User ID:
Password:

Answer each prompt with the numbers supplied in the Universal Sign-Up Kit and **ENTER**.

7. You are now logged-on to CompuServe.

COMMunicating with Bulletin Board Systems

A Bulletin Board System (BBS) is typically a small computer used by individuals, schools, or companies that provides a communication link between its users.

With some TRS-80 Bulletin Board Systems, you can receive graphics characters. For you to be able to accept these graphics, the COM/DVR driver has to be initialized at 8 bits per word (see the SETCOM library command) and you have to use 8-bit mode in COMM (**CLEAR SHIFT**) followed by **CLEAR :**).

COMMunicating with Other Computers

This section shows you how to use COMM to communicate with other computers. The first example describes how a TRS-80 communicates with a mainframe computer. The second example describes how two TRS-80's can communicate.

COMMunicating with a Mainframe

When a TRS-80 communicates with a mainframe computer, in most cases it is not necessary to change the default device or function settings when you enter COMM. Most mainframes operate as the host computer while you operate as a terminal, and the mainframe provides echo functions for you. You must be sure to specify the RS-232C parameters when setting up the COM/DVR driver to match those expected by the mainframe.

To transfer a file from a mainframe to your TRS-80 computer, use the following procedure:

-
1. Type in the command which causes the mainframe to list the file, but do not press **ENTER**.
 2. Specify your receive file by pressing **CLEAR** **6** followed by **CLEAR** **9**. Type in the filename in response to the prompt.
 3. Press **CLEAR** **6** followed by **CLEAR** **:** to open the receive area of memory. If the file you wish to receive is larger than your available area of memory, you should then press **CLEAR** **7** followed by **CLEAR** **:**. This causes the file to be written to the disk as it is being received.
 4. Press **ENTER** to start the file listing.
 5. When the listing is complete, press **CLEAR** **6** followed by **CLEAR** **-** to turn OFF the *FR and if you have not already done so, press **CLEAR** **7** followed by **CLEAR** **:** to write the file to disk.
 6. When the disk write is complete, type **CLEAR** **6** followed by **CLEAR** **0** to turn off DTD and to close the receive file.

To transfer a file from your TRS-80 computer to a mainframe, use the following procedure:

1. Designate the file that you want to send by pressing **CLEAR** **5** followed by **CLEAR** **9** and entering the name of the file in response to the prompt.
2. Turn on the handshake mode by pressing **CLEAR** **SHIFT** ***** followed by **ENTER** (assuming that the line terminating character in your file is **ENTER**).

If the mainframe does not support handshaking, first try to transfer the file without the handshake mode. If this doesn't work, contact the mainframe's computer site and find out how to send files to that mainframe.

3. Open the file at the host end and ready it for receiving information by whatever command process your host requires.
4. Turn on your file send by pressing **CLEAR** **5** followed by **CLEAR** **:**.

Note that one line of your file is transmitted and then your machine pauses. Once the host sends you the XON, the next line of the file is automatically transmitted.

If you are operating in half-duplex, you may see the entire file displayed without any pauses. The file is being read from your disk and put in an area of memory where it waits to be transmitted.

5. When the transmission is complete, turn off the handshake mode by pressing **CLEAR** **SHIFT** ***** followed by **CLEAR** **-**.

-
6. Close the file at the host end by whatever command process the host accepts. You may then close your file send by pressing **CLEAR** **5** followed by **CLEAR** **0** (which turns off the *FS and closes the file).

If you want to force the transmission to resume after a line is ended, you may turn the *CL back on by pressing **CLEAR** **4** followed by **CLEAR** **:**.

COMMunicating Between Two TRS-80's

When you use COMM to communicate between two TRS-80's, one end has to run on half-duplex (**CLEAR** **SHIFT** **!** followed by **CLEAR** **:**) and echo (**CLEAR** **SHIFT** **"** followed by **CLEAR** **:**). If files are to be sent and received, the RECEIVING end should run half-duplex and echo.

To transfer files between two TRS-80's, use one of the following two methods. Use Method A if you are operating above 300 baud. Use Method B if you are operating at 300 baud.

Method A

1. The sending end presses **CLEAR** **5** followed by **CLEAR** **9** and enters the name of the file to be sent.
2. The receiving end presses **CLEAR** **6** followed by **CLEAR** **9** and enters in the name of the file to be received. Turn the dump-to-disk (DTD) OFF by pressing **CLEAR** **7** followed by **CLEAR** **-**. This stores the file in memory as it is received.

If the sending end supports XON/XOFF handshaking, then you should turn HANDSHAKE ON by pressing **CLEAR** **SHIFT** ***** followed by **CLEAR** **:**.

3. When both ends are ready, the receiving end presses **CLEAR** **6** followed by **CLEAR** **:**, after which the sending end presses **CLEAR** **5** followed by **CLEAR** **:**.

If your free area of memory decreases to less than 2K during receipt of the file, a warning message is issued and an XOFF is automatically sent to the sending end.

Transmission from the sender should cease. Once it does, dump the receive area of memory to disk by turning on DTD by pressing **CLEAR** **7** followed by **CLEAR** **:**.

You can observe the increase in available memory space by displaying a menu as the area of memory is written to disk. Once ample space is available, turn off the DTD by pressing **CLEAR** **7** followed by **CLEAR** **-**.

You can then manually restart the sender's file by transmitting an XON from your keyboard with **CONTROL** **Q**.

-
4. The receiving end presses **CLEAR** **6** followed by **CLEAR** **—** when it has received all of the file. The last receive area of memory should be dumped to disk by turning on DTD (**CLEAR** **7** followed by **CLEAR** **:**).

The sending end presses **CLEAR** **5** followed by **CLEAR** **—** and then **CLEAR** **5** followed by **CLEAR** **0**.

5. When the receiving end has finished writing the information to the disk, close the file by resetting the *FR (**CLEAR** **6** followed by a **CLEAR** **0**). This performs an *FR OFF and a DTD OFF, and it closes the file just received.

Method B

1. The sending end presses (**CLEAR** **5**) followed by (**CLEAR** **9**) and enters in the name of the file to be sent.
2. The receiving end presses (**CLEAR** **6**) followed by (**CLEAR** **9**) and enters in the name of the file to be received.

The dump-to-disk (DTD) must be turned ON by pressing **CLEAR** **7** followed by **CLEAR** **:**. Check to see if it is already ON by displaying a menu (**CLEAR** **8**) and noting if an asterisk is displayed beneath its key.

3. When both ends are ready, the receiving end presses **CLEAR** **6** followed by **CLEAR** **:**. The sending end then presses **CLEAR** **5** followed by **CLEAR** **:** to turn ON the receive and send files.
4. When the receiving end has received all of the file and it is written to the disk, close the file by resetting the *FR. Press **CLEAR** **6** followed by **CLEAR** **0**. This performs an FR OFF and a DTD OFF, and it closes the file just received. The sending end then presses **CLEAR** **5** followed by **CLEAR** **0**.

Technical Information

This section describes some of the more technical aspects of COMM operation. This information allows you to predict how COMM will perform during higher speed I/O operations.

Main memory usage

COMM uses all available memory below the top of memory mark (HIGH\$) for dynamic buffering of device I/O. You can see or set this value with the MEMORY command.

The amount of buffer space devoted to each logical device dynamically expands and shrinks according to how quickly data is sent to a device and how fast the device can process the data it receives. Each buffer is essentially a variable length First-In, First-Out (FIFO) storage compartment.

The amount of free space available for the buffers is noted in the bottom line of the menu display. When this free space shrinks to less than 2K (2048 characters), a warning message is displayed and an XOFF is automatically sent to the communications line (*CL).

This function is useful when you are receiving a file from a system that supports handshaking. (The **CLEAR** **SHIFT** ***** command describes the supported handshaking.)

Break commands

COMM generates a modem break (long space) when you press the **BREAK** key. A modem break is used on many mainframe systems to indicate you want to abort a function that is occurring at the other computer.

However, for small computers, detecting a modem break is more difficult, so you have to select a control character to be treated as a "break" command.

To transmit a break character to another computer, press **CONTROL** **C** if the other computer is a Model II, 12 or 16. Press **CONTROL** **A** if the other computer is a Model I or III.

Escape code sequences

Some systems transmit control codes to indicate that a cursor movement or action is to be performed. Many systems have adapted a two-character sequence, which does not perform the intended function in COMM.

If you are working with one of these systems, you should contact the operators of the other system and ask if there is a way to prevent these control sequences from being sent to your system.

Some systems support several different types of terminals and computers, so with a little experimenting, you should be able to find a terminal setting that suits your needs.

Receiving large files from another system

If you receive files that won't fit into memory in one piece, you may have to use handshaking to reduce the possibility of losing data.

CONV (CONV/CMD)

CONV [<i>partspec</i>]: source drive [: <i>destination drive</i>] [(<i>parameters</i>)]	Utility
--	----------------

Allows you to move (convert) data files from a TRSDOS 1.3 (Model III) diskette onto a TRSDOS Version 6 formatted diskette.

Use this command with data or BASIC ASCII files. TRSDOS 1.3 application programs will not work on TRSDOS Version 6. To use TRSDOS 1.3 programs on the Model 4, start up your system with a TRSDOS 1.3 system diskette in Drive 0.

The *parameters* are:

VIS moves visible files

INV moves invisible files

SYS moves system files

NEW moves only those files that do not already exist on the destination disk.

OLD moves only those files that already exist on the destination disk.

QUERY = NO specifies that you are not to be questioned before each file is moved to the destination disk.

DIR displays a short directory of a TRSDOS 1.3 disk. If you do not specify *destination drive*, a short directory is displayed. If you specify DIR, no files are moved.

If you don't specify VIS, INV, or SYS, TRSDOS moves all three types of files.

The TRSDOS 1.3 disk must be a non-limited backup disk. Some programs such as SCRIPSIT and VISICALC are limited backup disks.

If you have data files on a TRSDOS 1.3 limited backup disk, you must COPY these files (under TRSDOS 1.3) to a non-limited backup disk before you can CONVert them.

The *source drive* cannot be Drive 0.

When you specify a *partspec*, only those files matching the *partspec* are moved to the destination disk.

When you do not specify the QUERY = NO parameter, you are questioned before each file is moved. Answer the prompt by pressing:

Y

to copy to file.

N or **ENTER**

to bypass the file and show the next one.

Caution: Do Not move BASIC/CMD or any other existing TRSDOS system files.

Examples

CONV :2 :1 **ENTER**

moves all files from Drive 2 onto Drive 1. You are questioned before each file is moved. If the file already exists in Drive 1, you are asked again before it is copied.

CONV :1 :0 (VIS,Q=NO) **ENTER**

moves all visible files from Drive 1 onto Drive 0. You are not questioned before each file is moved.

CONV :2 :0 (NEW) **ENTER**

moves only those files from Drive 2 that do not already exist on Drive 0.

CONV \$\$\$DATA:1 :2 (OLD) **ENTER**

moves any file whose filename is seven or eight characters long, the 4th through 7th characters are DATA, and that already exists on Drive 2. You are questioned before each file is moved.

CONV :1 (DIR) **ENTER**

displays the directory of the TRSDOS 1.3 disk in Drive 1.

CONV :1 (INV,DIR) **ENTER**

displays the invisible files of the TRSDOS 1.3 disk in Drive 1.

COPY

COPY <i>source</i> [TO] <i>destination</i> [(parameters)]	Command
--	----------------

Copies the *source* to the *destination*.

Source and *destination* can be a filespec or a devspec. *Destination* can also be a drive number.

The parameters are:

LRL=*nnn* specifies the logical record length (1 to 256) for *destination*. If omitted, *destination* will have the same LRL as *source*.

CLONE=NO specifies that *destination* is not to have the attributes of *source*.

ECHO causes any character copied from a devspec to be printed on the screen.

X allows a single drive copy.

The LRL parameter lets you restructure files to make them compatible with other programs. It is also useful when converting a source file from one format to another.

If you wish to append two files with different LRLs, this parameter can be used to make the LRLs match. If LRL is not specified, it defaults to the LRL of *source*.

If CLONE is not specified, the directory entry as well as the contents of *source* copies to *destination*. The owner and user passwords are copied, along with the assigned protection level, the visibility in the directory, the create flag, the last written-to date, and the modified status of the file.

If CLONE=NO is specified, the system date becomes the last written-to date for the destination file. If an existing destination file was copied over, the attributes of the destination file (except for the date) are unchanged. If the COPY command creates a new file, any password included becomes both the user and owner password of the destination file and the file's Mod Flag is set. The destination file is visible, even if the source file was invisible. See the ATTRIB library command for more information on file attributes.

Examples

```
COPY TEST/DAT TO :1 ENTER
```

searches the disk drives to find TEST/DAT and copies it to Drive 1.

```
COPY TEST/DAT.PASSWORD:0 TO :1 ENTER
```

copies the protected file TEST/DAT.PASSWORD from Drive 0 to

Drive 1. All parts of the destination file, including the password, are the same as those of the source file.

`COPY TEST/DAT:0 TO MYFILE:1 (ENTER)`

copies TEST/DAT on Drive 0 to MYFILE/DAT on Drive 1. Since the destination filespec does not contain an extension, it defaults to /DAT to match the source.

`COPY DATA/NEW:0 TO /OLD:0 (ENTER)`

copies DATA/NEW on Drive 0 to DATA/OLD on Drive 0. Since the destination filespec does not contain a filename, it defaults to DATA to match the source.

`COPY TEST/DAT:0 TO TEST/DAT.CLOSED:1
(CLONE=NO) (ENTER)`

copies TEST/DAT from Drive 0 to Drive 1 and assigns the user and owner passwords CLOSED. To assign a password to a destination filespec, the CLONE parameter must be turned off.

`COPY DATA/V56:0 TO DATA/V28:1 (LRL=128) (ENTER)`

copies DATA/V56 on Drive 0 to DATA/V28 on Drive 1. The LRL of DATA/V28 is set to 128.

`COPY *KI TO *PR (ECHO) (ENTER)`

copies from the keyboard to the printer. As keys are pressed, they are sent to the line printer. The keystrokes are visible on the video because the ECHO parameter is specified. Pressing **(CONTROL)(SHIFT)@** or **(BREAK)** terminates the copy.

When copying from devspec to devspec, it is very important that all devices specified be assigned and active in the system. Any routing or setting affecting the devices may affect the copy.

It is very important to be aware that you can generate non-ending loops that lock up the system when copying between devices. Be sure to have a good understanding of this type of copy before you use it.

`COPY *KI TO KEYIN/NOW:0 (ENTER)`

sends the keystrokes entered from the keyboard to the file KEYIN/NOW on Drive 0. If the file already exists, it is written over. To view the characters as you type them, use the ECHO parameter. Pressing **(CONTROL)(SHIFT)@** terminates the copy.

`COPY TEST/DAT.SECRET:0 (X) (ENTER)`

copies TEST/DAT.SECRET from one disk to another.

The destination file TEST/DAT.SECRET is visible, and its owner and user passwords are set to SECRET.

When you use the (X) parameter, a TRSDOS system disk is not required in the copy if the proper system modules (1, 2, 3, and 4) are loaded into memory (see the SYSTEM (SYSRES) library command).

During the copy, the following disk swap prompts are repeated until the copy is complete. The prompts are:

Insert SOURCE disk (ENTER)

— Contains the file to be copied.

Insert SYSTEM disk (ENTER)

— Any TRSDOS SYSTEM disk. If system modules 1, 2, 3, and 4 are loaded into memory, press (ENTER) at this prompt.

Insert DESTINATION disk (ENTER)

— Receives the file being copied. May appear twice in a row. The disk must have a different Disk ID (disk name, master password, or date) from the source diskette. (If it is a system disk, use ATTRIB if you need to change its Disk ID.)

You cannot use the (X) parameter in copies involving logical devices.

Sample Use

Whenever a file is updated, use COPY to make a backup file on another disk. You can also use COPY to restructure a file for faster access. Be sure the destination disk is already less segmented than the source disk; otherwise the new file could be more fragmented than the old one. (See FREE for information on file fragmentation.)

To RENAME a file on the same disk, use RENAME, not COPY.

CREATE

Advanced Programmer's Command
CREATE *filespec* [(*parameters*)]

Creates a file named *filespec* and pre-allocates space for its future contents.

You can use CREATE to prepare a file which will contain a known amount of data. This usually speeds up file write operations. File reading is also faster, since pre-allocated files are less segmented or dispersed on the disk — requiring less motion of the read/write mechanism to locate the records.

When a file is CREATED, TRSDOS does not recover unused space at the end of the file (each time you finish using it). If you exceed the created size, TRSDOS allocates extra space for your file as you write to it.

The parameters are:

LRL = *number* assigns *number* as the record length of *filespec*.
number can be from 1 to 256. If you omit this parameter, the record length defaults to 256.

REC = *number* assigns the specified *number* of fixed-length records to the file.

SIZE = *number* allocates disk space to the file as *number* (in K).

You have to specify (1) SIZE or (2) LRL and REC.

(For more information about record lengths and types, see "Disk Files" in the Technical Reference Manual.)

CREATE also lets you permanently assign additional space to a file that already exists. Use the appropriate parameters for the new file size.

Examples

```
CREATE NEWFILE/DAT:0 (LRL=128,REC=100) (ENTER)
```

creates a file named NEWFILE/DAT on Drive 0 and allocates space for one hundred 128-byte records.

```
CREATE GOOD/DAT (REC=50) (ENTER)
```

creates a file named GOOD/DAT on the first available drive and allocates space for fifty 256-byte records.

```
CREATE INVENT/DAT (SIZE=20) (ENTER)
```

takes the already existing file named INVENT/DAT and increases its size to 20K.

Error Conditions

If the specified SIZE (or LRL times REC) would cause an existing file to become smaller than it presently is, the error message "File exists larger" appears.

Sample Use

Suppose you are going to store personnel information on no more than 250 employees, and each data record will look like this:

Name (Up to 25 letters)
Social Security Number (11 characters)
Job Description (Up to 92 characters)

Your records would need to be $25 + 11 + 92 = 128$ bytes long.

You could create an appropriate file with this command:

```
CREATE PERSONNL/TXT (REC=250,LRL=128) ENTER
```

Once created, this pre-allocated file would allow faster writing than would a dynamically allocated file, since TRSDOS would not have to stop writing periodically to allocate more space (unless you exceed the pre-allocated amount by adding more than 250 employees).

DATE

DATE [<i>mm/dd/yy</i>]	Command
---------------------------------	----------------

Resets the date or displays the current system date.

You can use DATE to see today's date. You can also use DATE to change the date that TRSDOS uses.

You first set the date when you start up your computer. DATE lets you change it without turning your computer off and on.

Use *mm/dd/yy* to reset the date. *mm* is a 2-digit month specification; *dd* is a 2-digit day of the month specification; *yy* is a 2-digit year specification. If you omit *mm/dd/yy*, TRSDOS displays the current date.

It is important to set the date because TRSDOS uses the date when creating and accessing files, making backups, and formatting disks.

TRSDOS restricts the date to between 01/01/80 and 12/31/87. If you enter a date outside of this range, an "Illegal date" error results.

Examples

DATE **(ENTER)**

displays the current date, such as:

Fri, Oct 8, 1982

for Friday, October 8, 1982.

DATE 10/09/82 **(ENTER)**

resets the date to October 9, 1982 and displays the new date.

DEBUG

Advanced Programmer's Command

DEBUG [[*switch*] [,] [*parameter*]]

The DEBUG command sets up the debug monitor, which allows you to enter, test, and debug machine-language programs.

The *switches* are:

ON	turns on DEBUG
OFF	turns off DEBUG

If *switch* is not specified, ON is assumed.

The *parameter* is:

EXT	specifies the extended debugger
-----	---------------------------------

EXT, ON, and OFF can be abbreviated to E, Y, and N.

Once you have turned on DEBUG, you automatically enter the debug monitor whenever you do one of the following:

1. Press the **BREAK** key (provided **BREAK** is enabled)
2. Load and execute a user program (as long as the file's protection is not execute only)

You can also automatically activate the debugger by holding down the **D** key while the system is booting.

While in the DEBUG monitor, you can enter any of a special set of single-key commands to study how your program is working (as detailed under Command Description below).

EXT loads a separate block of the system debugger into high memory. While DEBUG is on, TRSDOS automatically protects this area of memory from being overlaid by BASIC or other user programs.

If you execute a program with execute only protection, DEBUG turns off.

Examples

DEBUG **ENTER**

turns on the standard DEBUG and waits for it to be activated.

DEBUG (EXT) **ENTER**

turns on extended DEBUG (loads it into high memory) and waits for it to be activated.

DEBUG (OFF) **ENTER**

turns off standard or extended DEBUG.

DEBUG (OFF,EXT) **(ENTER)**

Turns off DEBUG and attempts to reclaim the high memory occupied by the extended debugger. (If anything is loaded in high memory below the extended debugger, this area is not reclaimed.)

To enter the monitor when DEBUG is on, type:

filespec **(ENTER)**

TRSDOS loads the program (as long as the file's protection level is not execute only) and transfers control to DEBUG. (You can also enter the monitor by pressing **(BREAK)**.)

Following is a sample display of the debugger screen.

```
af = 01 93 S--H--NC
bc = 01 07 => FC 1B 13 06 2D 06 23 06 30 06 0E 06 28 06 7B 19 .....*. 0...(.
de = 02 08 => 05 68 08 00 00 00 4B 49 07 60 0B 00 00 00 44 4F .h....KI .e....DD
hl = 0A DD => FF 19 19 2D 2D 2D 2D 2D 2D 2D 2D 2D 2D 2D 0A 0A .....
af' = FF FF SZ1H1PNC
bc' = 00 10 => C9 00 00 FF 00 FF 00 FF C9 00 00 81 FF FF FF 2F ...../
de' = 4A B1 => 03 20 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
hl' = 4D 92 => F7 4E 64 69 72 2F 73 79 73 2C 33 32 0D FF 00 FF .Ndir/sy s,32...
ix = 02 08 => 05 68 08 00 00 00 4B 49 07 60 0B 00 00 00 44 4F .h....KI .e....DD
iv = 00 6A => 00 00 04 02 00 00 00 00 00 00 05 00 78 00 87 00 .....x...
sp = 03 EA => 88 08 50 06 08 02 20 04 4A 2B 4F 4F 16 06 78 05 ..P... J+DD...x.
pc = 0B E1 => 38 07 28 05 79 FE 03 28 6A E5 23 7D 23 BE 28 20 8.(.y.( J.*)*.(
FF00 => 2D 2D 2D 2D 2D 2D 2D 2D 2D 2D 2D 2D 2D 2D 2D 2D -----
FF10 => 2D 2D 2D 2D 2D 2D 2D 2D 2D 2D 2D 2D 2D 2D 2D 2D -----
FF20 => 2D 2D 2D 2D 2D 2D 2D 2D 2D 2D 2D 2D 2D 2D 2D 2D -----
FF30 => 2D 2D 2D 2D 2D 2D 2D 2D 2D 2D 2D 2D 2D 2D 2D 2D -----
```

The debug display contains information about the Z-80 microprocessor registers. The display is set up in the following manner:

The register pairs are shown along the left side of the display, from top to bottom. The current contents of each register pair are shown immediately to the right of the register labels.

The AF and AF' pairs are followed by the current status of the flag registers to the right of the register contents. The other register pairs are followed by the contents of the 16 bytes of memory they are pointing to. The contents are shown in both hexadecimal and ASCII representations. Non-displayable ASCII characters are represented by periods.

The PC register shows the memory address of the next instruction to be executed. The display to the right of that address shows the contents of that address and the next 15 addresses.

The bottom four lines of the screen show the contents of the memory locations indicated by the address at the left of each line. These locations vary depending upon which command is used.

Command Descriptions

When the DEBUG monitor is displayed, you can enter one of the following single-key commands.

Any value entered as an address or a quantity must be entered as a hexadecimal number.

To cancel an incorrect command, press (X).

A (ASCII Modify)

Address

Enter the above command line to modify *address*. If *address* is displayed in the monitor, vertical bars appear around it.

After you enter *address*, it and the current byte appear in the lower left corner of the screen. To modify the byte, type the new ASCII value and press:

- (SPACE BAR) to modify the byte and move to the next address.
- (ENTER) to modify the byte and exit from the A command.

If you do not specify *address*, TRSDOS uses the current "memory modification address" (shown by the vertical bars).

Example:

AD004 (SPACE BAR)

causes address D004 and the current byte value to appear in the lower left corner of the screen. TRSDOS allows you to enter the new byte value. Then press (SPACE BAR) to continue, or (ENTER) to end.

B (Move Block of Memory)

Bstarting address,destination address,number of bytes

Enter the above command line to move a block of memory from *starting address* to *destination address*.

Always specify a non-zero *number of bytes*. If you enter *number of bytes* as 0, TRSDOS moves a block of 65,535 bytes to *destination address*, causing the extended debugger to function improperly.

Example:

B3E04,4E34,14E (ENTER)

moves the 14E-byte block of memory from 3E04 to 4E34.

C (Call Instruction)

Press **C** to single-step through the instructions pointed to by the PC register. If a call instruction is encountered, the routine that it calls is executed.

D (Display)

Daddress

Enter the above command line to display memory beginning at *address*.

Example:

DE404 **ENTER**

displays memory beginning at address E404.

F (Fill Memory)

Ffirst address,last address,byte

Enter the above command line to fill the block of memory from *first address* to *last address* with the value *byte*.

Example:

F3D08,3E14,00 **ENTER**

fills the block of memory from 3D08 to 3E14 with the value 00.

G (Go to an Address and Execute)

Gaddress,breakpoint1,breakpoint2

Enter the above command line to begin execution at *address*. If *address* is omitted, execution begins at the PC address.

breakpoint1 and *breakpoint2* are optional breakpoint addresses where execution stops. The breakpoints must be in memory. The system removes them when you return to debug.

Example:

GE0FF,F001,F201 **ENTER**

begins execution at E0FF. Stops execution at breakpoint addresses F001 and F201.

H (Hex Modify)

Haddress

Enter the above command line to modify *address*. If *address* is displayed in the monitor, vertical bars appear around it.

After you enter *address*, it and the current byte appear in the lower left corner of the screen. To modify the byte, type the new hexadecimal value and press:

- **(SPACE BAR)** to modify the byte and move to the next address.
- **(ENTER)** to modify the byte and exit from the H command.
- **(X)** to exit from the H command without modifying the byte.

If you do not specify *address*, TRSDOS uses the current “memory modification address” (shown by the vertical bars).

Example:

HD004 **(SPACE BAR)**

causes address D004 and the current byte value to appear in the lower left corner of the screen. TRSDOS allows you to enter the new byte value. Then press **(SPACE BAR)**, **(ENTER)**, or **(X)** to continue.

I (Single-Step Execution)

Press **(I)** to single-step through the instructions pointed to by the PC register. This command is identical to the C command except that any calls encountered are stepped through instruction by instruction. (Note that RST 28H, RST 30H, and RST 38H instructions automatically convert the I command to a C command.)

J (Jump)

Press **(J)** to increment the program counter (PC) by 1.

O (Return to TRSDOS Ready)

Press **(O)** to return to TRSDOS. DEBUG is not turned off. (Use the DEBUG (OFF) command to turn DEBUG off.)

Q (Port)

There are two kinds of ports — input and output. You read an input port and you write to an output port.

Qport

Enter the above command line to read the byte at *port* and display its value. There are 256 input ports (00 - FF).

Example:

Q45 **(ENTER)**

displays the value of port 45 in the lower left corner of the screen.

Qport,byte

Enter the above command line to write the value of *byte* to *port*. There are 256 output ports.

Example:

Q45,04

writes the byte value of 04 to port 45.

R (Register Pair)

R register pair code contents

Enter the above command line to change the specified register pair's contents to the new *contents*. There must be a space between *register pair code* and *contents*.

The *register pair codes* are:

AF	for	AF	AF'	for	AF'
BC	for	BC	BC'	for	BC'
HL	for	HL	HL'	for	HL'
DE	for	DE	DE'	for	DE'
IX	for	IX			
IY	for	IY			
SP	for	SP			

Example:

RBC 3D01

changes the contents of register pair BC to the value 3D01.

S (Full Screen Mode)

Press **[S]** to change the monitor format from the register display mode to full screen mode. The full screen mode displays a page of memory (256 bytes) beginning with the current display address (see the D command).

U (Update)

Press **[U]** to constantly update the display and to show any active background tasks. To cancel this command, hold down any key for several seconds.

X (Return)

Press **[X]** to return the display to the normal register display mode.

; (Advance Memory)

Press **[;]** to advance the memory display 64 bytes in the register mode and 256 bytes in the full screen mode.

- (Decrement Memory)

Press **[-]** to decrement the memory display by 64 bytes in the register mode and 256 bytes in the full screen mode.

Disk Read/Write Utility

Lets you read or write to a specified block of memory. The command line is:

disk drive,cylinder,starting sector,operation,address,number of sectors

address is the starting address in memory where the information read from the disk is to be placed, or where information written to the disk is to be taken from.

Specify operation as: R for Read, W for Write, or * for a Directory Write.

If you do not specify *cylinder*, the system uses the directory track. If you do not specify *starting sector*, the system starts with sector 0. If you do not specify *number of sectors*, the system reads the whole cylinder.

If an error occurs during a disk function, the error number appears on the screen surrounded by asterisks. Hold down the **(ENTER)** key to abort the disk function.

Example:

2,0,0,R,6000,2 **(ENTER)**

reads into memory (beginning at address X'6000') sectors 0 and 1 of cylinder 0 from the disk in Drive 2. This block of memory is displayed on the monitor in the full screen mode.

Extended Command Descriptions

The following commands are available only with the extended debugger.

E (Enter Data)

Eaddress

Enter the above command to enter data directly into memory beginning at *address*. The contents of *address* are displayed and you can then type in two hex characters to replace the current contents. After typing the byte, press:

- **(SPACE BAR)** to modify the byte and move to the next address.
- **(ENTER)** to modify the byte and exit from the E command.
- **(X)** to exit from the E command without modifying the byte.

If you do not specify *address*, TRSDOS uses the current memory modification address (shown by the vertical bars).

L (Locate)

L *address,byte*

Enter the above command to locate the first occurrence of *byte*, starting the search at *address*.

If you don't specify *address*, DEBUG uses the current memory modification address (shown by the vertical bars). If you don't specify *byte*, DEBUG uses the last byte given in a previous L command.

Example:

```
L470E,0D (ENTER)
```

searches for the first occurrence of 0D after address 470E.

N (Next Load Block)

Enter the above command to position the vertical bars to the next load block. This command is used to move logically through a block of memory that has been loaded directly from disk using DEBUG.

To use this command, position the vertical bars over the file type byte at the beginning of any block. Press (N)(ENTER) and DEBUG advances to the next load block header.

Example:

Position the vertical location bars over the beginning byte of a load block and type:

```
N (ENTER)
```

DEBUG advances to the beginning byte of the next load block.

P (Print)

P *first address,last address*

Enter the above command line to print out the block of memory from *first address* to *last address*.

Example:

```
PFC80,FC90 (ENTER)
```

prints out the block of memory from FC80 to FC90 in the following format:

```
aaaa  bb bb ... bb  ccccccccccccccc
```

aaaa	represents the current address
bb bb ... bb	represents 16 locations in hex notation
cccc	represents the ASCII equivalents of the 16 hex locations

T (Type ASCII)

T address

Enter the above command line to type ASCII characters directly into memory, starting at *address*. If you omit *address*, DEBUG uses the current memory modification address (shown by the vertical bars).

Example:

TCB01 (SPACE BAR)

displays the address CB01 and its current contents in ASCII code. If the contents of the address are out of the ASCII character range, then a period is displayed.

DEBUG then prompts you to enter the new ASCII contents for CB01.
Type:

A

to enter the hex value for A, which is 41, in address CB01.

Pressing (SPACE BAR) advances memory one byte without changing its contents. DEBUG continues to prompt you to add ASCII values until you press (ENTER) to exit the command.

V (Compare)

V first address, second address, length

Enter the above command line to compare a block of memory beginning at *first address* to the block of memory beginning at *second address*. The compare is for the specified *length* in bytes (X'0001' – X'FFFF').

Example

VCB00,EF02,45 (ENTER)

compares a 45-byte long block of memory beginning at CB00 to a 45-byte long block of memory beginning at EF02. The first byte of the block of memory beginning at CB00 that does not match is displayed as the first byte of memory in the DEBUG monitor. The corresponding byte in the block of memory beginning at EF02 becomes the current memory modification address that is used by the H, A, E, and T commands.

W (Word)

W address, word

Enter the above command to search memory for *word*, beginning at *address*. *word* must be in the least significant byte, most significant byte format.

If you do not specify *address*, DEBUG uses the current memory modification address. If you do not specify *word*, DEBUG uses the last word given in a previous W command.

Example:

WAB06,3412 **ENTER**

searches memory for word (1234) beginning at address AB06. The address where *word* is found is displayed in the DEBUG monitor with the vertical location bars positioned one byte before it.

DEVICE

Advanced Programmer's Command DEVICE [(parameters)]


Displays the status of the drives, the options selected, and the data paths for the logical devices that have been set, routed, or linked.

It also logs in disks in the available disk drives.


The parameters are:

- D=NO suppresses the drive portion of the display. Any new drives or disks are not detected.
- B=YES enables the logical device portion of the display.
- S=NO suppresses the options status portion of the display.
- P=YES duplicates the display to the printer.

```
:0WP [TRSDOS60] 5" Floppy #1, Cyls= 40, Dden, Sides=1, Step=12ms, Dly=.5s
:1 [TRSDOS60] 5" Floppy #2, Cyls= 40, Dden, Sides=1, Step=12ms, Dly=.5s
:2 [No Disk ] 5" Floppy #4, Cyls= 40, Dden, Sides=1, Step=12ms, Dly=.5s
:3 [No Disk ] 5" Floppy #8, Cyls= 40, Dden, Sides=1, Step=12ms, Dly=.5s
*KI <= X'08C3'
*DO <=> X'08D0'
*PR => X'0E2E'
*SI <= *KI
*SO <=> *DO
*JL => Nil
Options: Type
```



1. The DRIVE section shows the current configuration of the disk drives.
2. The DEVICE section shows the devices (displayed when B= YES).
3. The STATUS section displays the status of some user selected options.



```
:0WP [TRSDOS60] 5" Floppy #1, Cyls= 40, Dden, Sides=1, Step=12ms, Dly=.5s
:1 [TRSDOS60] 5" Floppy #2, Cyls= 40, Dden, Sides=1, Step=12ms, Dly=.5s
:2 [No Disk ] 5" Floppy #4, Cyls= 40, Dden, Sides=1, Step=12ms, Dly=.5s
:3 [No Disk ] 5" Floppy #8, Cyls= 40, Dden, Sides=1, Step=12ms, Dly=.5s
```

1. Logical drive number — The number of the drive accessed. (See the SYSTEM command.)
2. Disk write protect status — The write protect status assigned to the drive by the SYSTEM (DRIVE=,WP=) command. A disk can also be write protected by placing a foil tab over the write-protect notch on the diskette.
WP=Write Protected
3. Disk name — The name of the disk accessed in the drive.

-
4. Disk size — The size of the floppy or hard disk.
 5. Type of drive — Either floppy or hard.
 6. For floppy disk systems, the physical location of the drive.
 - 1 - lower
 - 2 - upper
 - 4 - middle of the disk expansion cable
 - 8 - end of cable
 7. Number of cylinders — The number of cylinders available in the drive.
 8. Density — The data density of the disk accessed in the drive.
Dden= Double density
Sden= Single density
 9. Number of sides — The number of sides the disk being accessed has.
 - 1 = One side
 - 2 = Two sides
 10. Step rate — The step rate of the drive in milliseconds. Step rate is the speed at which the disk drive head is moved from cylinder to cylinder.
 11. Delay time — The delay time when accessing a 5" floppy disk. Delay time is the amount of time the system waits after starting the drive motor before it attempts to access the disk.

NOTE: The Step rate and Delay time are preset for this system. Information needed to change these settings can be found in the *Technical Reference Manual* (Cat. No. 26-2110).

```
*KI <= X'0893'  
*DO <=> X'0B8A'  
*PR => *L0: *TD & => X'0DE8'  
*SI <= Nil  
*SO <=> Nil  
*JL => Nil  
*FF <#> [Inactive] X'0FD4'  
*TD <=> PRINT/TXT: 0  
*L0 => X''0DE8'
```

In the logical device portion of the device table:

>=	indicates an input device
=>	indicates an output device
<=>	indicates a device capable of input and output
#	indicates a filter
	indicates a link

If you add a driver or filter to the default system, the DEVICE command shows the address where a device transfers control to its driver or filter. If more than one filter or driver is associated with the same device, the first driver's address is displayed. It also shows the interaction between devices and/or files.

Options: Type

System modules resident: 1, 2, 4,

The options line shows you the active system parameters. These parameters are usually established with the FILTER, LINK, ROUTE, SET, SPOOL, and SYSTEM library commands.

It also shows the resident system overlays. (See the SYSTEM (SYSRES=) library command.)

Examples

DEVICE (ENTER)

displays the device table.

DEVICE (D=NO) (ENTER)

displays the TRSDOS options, and turns the drive portion of the display off. Any new drives or disks are not detected.

DEVICE (B=YES) (ENTER)

enables the device portion of the device table, and displays the entire table.

DEVICE (S=NO) (ENTER)

displays the drive table, and turns the options status portion of the display off.

DEVICE (P) (ENTER)

displays the device table, and sends it to the printer.

DIR

Command

DIR [*partspec*] [:*drive*] [(*parameters*)]

Displays the specified disk's directory.

You can use DIR to see the files on a disk.

When you specify a *partspec*, only those files matching the *partspec* are displayed.

If you omit the drive number, TRSDOS displays the directories of all enabled drives.

The parameters are:

ALL displays all directory information for the specified files, including space used on the disk.

INV displays the non-system, invisible files along with the non-system visible files.

MOD displays the files modified since the last backup.

NON enables the non-stop display mode.

PRT outputs the directory display to the printer.

SYS displays the system files along with the visible files.

DATE displays the files with today's date.

DATE = "M1/D1/Y1-M2/D2/Y2" displays the files with modify dates between the two specified dates, inclusive.


= "M1/D1/Y1" displays the files with modify dates equal to the specified date.

= "-M1/D1/Y1" displays the files with modify dates before or equal to the specified date.

= "M1/D1/Y1-" displays the files with modify dates after or equal to the specified date.

SORT=NO specifies that the directory entries are not to be sorted alphabetically.

SORT can be abbreviated to O.



1. Drive number.
2. Disk name.

3. Number of cylinders on the disk.
4. Density of the disk.
DDEN = double density
SDEN = single density
5. Free space — The amount of space on the disk currently available to the user.
6. Total free space — The total amount of space (used and unused) on the disk.
7. Creation date — The date on which the disk was created.
8. Disk files — The disk files are sorted alphabetically.

1	2	3	4	5	6	7	8	9	10
Filespec	MOD	Attr	Prot	LRL	#Recs	EOF	File Size	Ext	Mod Date
COMM/DVR		P	EXEC	256	3	182	1.50K	1	01-Feb-83
COMM/CMD		P	EXEC	256	11	228	3.00K	1	01-Feb-83
CONV/CMD		P	EXEC	256	6	196	1.50K	1	01-Feb-83
FORMS/FLT		P	EXEC	256	3	135	1.50K	1	01-Feb-83
KSM/FLT		P	EXEC	256	3	234	1.50K	1	01-Feb-83
LOG/CMD		P	EXEC	256	1	237	1.50K	1	01-Feb-83
MEMDISK/DCT		P	READ	256	12	62	3.00K	1	01-Feb-83
MONITOR/CMD			FULL	256	1	19	1.50K	1	02-Feb-83
PATCH/CMD		P	EXEC	256	10780	247	3.00K	1	01-Feb-83
PRINT/DAT		?	FULL	256	1	37	1.50K	1	16-Feb-83
PRINT/TXT			FULL	256	0	0	0.00K	0	
TAMMY/JCL			FULL	256	1	111	1.50K	1	15-Feb-83
TESTFILE			FULL	256	0	0	0.00K	0	

13 files out of 31 selected, Space = 21.00K

11 12 13

1. Filespec — The name and extension assigned to a file when it is created.
2. Modification Status — The modification status of the file.
+ indicates the file was modified since it was last backed up.
3. Attribute — The file's attributes.
I indicates an invisible file.
P indicates the file has an owner password.
S indicates a system file.
C indicates the file was created with the CREATE library command.
? indicates an open file (see RESET library command)
4. Protection Level — The level of access assigned to the user password. See the ATTRIB library command for a list of these levels.
5. Logical Record Length (LRL) — The length of each logical record in the file.
6. Number of Records — The number of logical records in the file.

-
7. End of File (EOF) — Shows the last byte number of the file.
 8. File Size — The amount of space in K (1K=1024 bytes) that the file takes up on the disk.
 9. Extents — The number of extents (blocks of space) that the file is stored in. The higher the number, the more fragmented the file is on the disk.
 10. Modify Date — The date that the file was created or last written to. Since the system uses the date you enter at start-up, we recommend that you do not disable the start-up DATE prompt.
 11. Specified Files — The number of files on the disk that match the parameters you specify in the command line.
 12. Total Files — The total number of files on the disk.
 13. Space — The amount of space used by the specified files.

Examples

DIR (ENTER)

displays the visible files of all enabled drives.

DIR :1 (I,S) (ENTER)

displays all files (visible, invisible, and system) on Drive 1. Specifying a drive that is not enabled or ready causes an "Illegal drive number" error message or a [No Disk] message to appear.

DIR :1 (I,S,P) (ENTER)

sends the directory display of Drive 1 to the printer as well as the screen. The NON parameter is automatically set to YES and the entire directory prints without pause. Pressing the (SHIFT)@ keys pauses the display. Press any key to continue.

DIR :2 (A) (ENTER)

displays the directory of Drive 2 in the allocation format. The display pauses after every 24 lines. Pressing (BREAK) terminates the display, while pressing any other key displays the next 24 lines.

DIR (DATE="10/01/82-") (ENTER)

displays the files modified on or after October 1, 1982.

DIR (M, SORT=NO) (ENTER)

displays the files modified since the last backup in an unsorted order.

DIR B:0 (ENTER)

displays the files that begin with the letter B on Drive 0.

DIR T\$T/CMD:1 (ENTER)

displays any file that matches partspec T\$\$T/CMD on Drive 1.

DIR -/CMD:Ø **ENTER**

displays all visible files on Drive Ø except for those that have a CMD extension.

DO [<i>control character</i>] filespec [(<i>parameters</i>)] [;]	Command
--	----------------

Compiles and executes a DO file.

You can use DO to run a file of commands each time TRSDOS starts up.

A DO file is a user created Job Control Language (JCL) file that contains one or more library commands. TRSDOS executes the commands as if you had typed them in from the keyboard.

In addition to executing TRSDOS commands, you can load and execute user programs from a DO file.

You can create a DO file with the BUILD command. Command lines in this file can include library commands or filespecs. See the Job Control Language section for more information on DO files.

The *control characters* are:

- \$ compiles your DO file without actually executing the commands.
- = executes your DO file without compiling it.
- * reruns the last DO command that was compiled.

When you specify a control character, you must leave a space between DO and the character or TRSDOS ignores the character.

The *parameters* are:

- @*label* lets you create JCL files with multiple entry points (an entry point is the place where processing begins). A label consists of the @ symbol followed by one to eight alphanumeric characters.
- parm[=*value*] lets you pass *value* to *filespec* during execution.

When you specify the @*label* parameter, *filespec* does not execute until the label is reached. Execution continues until it reaches the next label or the end of the JCL file.

The @*label* parameter, by building many different functions into one file, reduces the number of individual files on the disk (conserving space in the directory).

Use the semicolon (;) parameter when you need to specify a command line longer than 79 characters.

When a DO command line exceeds 79 characters:

1. Enclose as many parameters as will fit on one line in parentheses. Close the parentheses, insert a (;), and press **ENTER**.

-
2. When a question mark appears on the screen, enter the remaining parameters (enclosed in parentheses).

Examples

```
DO DRIVE/JCL (ENTER)
```

compiles and executes the file named DRIVE/JCL.

```
DO = DRIVE/JCL (ENTER)
```

executes the file named DRIVE/JCL without compiling it.

```
DO $ DRIVE (ENTER)
```

compiles the file named DRIVE/JCL without executing it. Since you did not specify an extension to DRIVE, it defaulted to JCL. You can LIST the SYSTEM/JCL file to see if the JCL compiled properly.

```
DO MY/JCL (@THIRD) (ENTER)
```

compiles and executes the program named MY/JCL. All instructions in the program are ignored up to the label (@THIRD). Compilation begins at the line following the label and continues until the next label or the end of the file is reached.

```
DO * (ENTER)
```

executes SYSTEM/JCL, which contains the last DO file that was compiled.

```
DO TEST/NEW:2 (D=5,E=6) (ENTER)
```

compiles and executes the file TEST/NEW on Drive 2. The variable parameters D=5 and E=6 are passed as needed during compilation.

Error Conditions

If you specify *@label*, you must compile the DO file, or an error is generated.

The occurrence of any error aborts the DO execution.

When you specify the ** control character*, a "File not in directory" error occurs if there is no previously compiled DO file to rerun.

When you specify the *\$ control character*, the system compiles the JCL file and informs you of any errors that occur. This lets you see if the file compiles properly before you actually execute it. When you compile a JCL file, a disk in your system must be write-enabled, so the system can write the compiled information to a file named SYSTEM/JCL.

When you use the *= character*, you cannot use some of the JCL features. See the JCL section of this manual.

Sample Uses

Suppose you want to set up the following TRSDOS functions to execute by typing one command:

FORMS (MARGIN = 8)
TIME (CLOCK = ON)

Use BUILD to create such a file. If you called the file BEGIN, then use the command:

DO BEGIN **(ENTER)**

to perform the commands.

DUMP

Advanced Programmer's Command
DUMP *filespec* (*parameters*)

Copies an area of memory to a disk file named *filespec*.

You can use DUMP to store a machine-language program from memory to a file.

DUMP can produce a program or a core ASCII file. A program produced with DUMP can then be loaded or executed at any time. (An ASCII file cannot be loaded with the LOAD command or executed with the RUN command.)

The default extension for program dumps is /LMF, and the default extension for ASCII dumps is /TXT.

You can use some or all of the following *parameters*:

START=*address* starts the dump at *address*. You must include this parameter. The address must be above 2FFF hexadecimal or 12287 decimal.

END=*address* ends the dump at *address*. You must include this parameter. END must be greater than or equal to START, and can be either a hexadecimal or decimal number.

TRA=*address* sets the address at which your program begins executing after you load it. If you omit this parameter, any subsequent run of the file will only load the program and return you to TRSDOS Ready. TRA can be either a hexadecimal or a decimal number.

ASCII specifies that the dump is to an ASCII file. ASCII files contain program code only. No system loading information is written to *filespec*.

ETX=*value* specifies that the character at the end of an ASCII file is equal to *value*. *value* is a hexadecimal number in the format x'nn'. When you specify ETX, you must also specify ASCII.

ETX cannot be abbreviated.

When you DUMP to an ASCII file, you create a file that has the identical file structure as a SCRIPSIT file. The system writes a special character at the end of the file which can be changed with the ETX parameter.

Examples

```
DUMP ROUTINE/CMD (START=X'7000',END=X'8000',TRA=X'7000') ENTER
```

dumps the area of memory starting at hexadecimal 7000 and ending at hexadecimal 8000. This block of memory is written to a disk file

named ROUTINE/CMD. If the file already exists, it is overwritten. If it does not exist, it is created on the first available drive. The transfer address (starting address for execution) of ROUTINE/CMD is hexadecimal 7000.

```
DUMP ROUTINE/CMD (START=28672,END=32768,TRA=
28672) (ENTER)
```

is identical to the above command except that START, END, and TRA have decimal values.

```
DUMP TEST:1 (S=X'9000',E=X'BC0F') (ENTER)
```

dumps the specified block of memory to a disk file named TEST/LMF on Drive 1. Since you did not specify a file extension to TEST, it defaulted to /LMF. Also, since you did not specify a transfer address, it is written to the file as a return to TRSDOS Ready.

```
DUMP WORD/IMG:0 (S=X'7000',E=X'A000',ASCII)
(ENTER)
```

dumps the specified block of memory to a disk file named WORD/IMG on Drive 0. Since the ASCII parameter is specified, an ASCII file is created.

```
DUMP WORD (S=X'7050',E=X'A000',ETX=X'FF',
ASCII) (ENTER)
```

dumps the specified block of memory to a disk file named WORD/TXT. An ASCII file is created, and the special character at the end of the text (end of text marker) is written as hexadecimal FF. Since you did not specify an extension for WORD, it defaulted to /TXT.

FILTER

Advanced Programmer's Command

FILTER *devspec* [USING] *phantom devspec*

Connects a filter program to *devspec* which modifies or "filters" data as it is read from or written to *devspec*.

You can use a filter to change data as it passes from *devspec* to *phantom devspec* (and vice versa).

A filter is a program that controls the flow of data to or from any device or file.

devspec is any valid, active TRSDOS device. *phantom devspec* is the name of a device which is connected to the filter program established in memory with the SET command.

You can apply as many filter programs to *devspec* as you want to. If there is not any more space in memory for the filter connection, the error message "No device space available" appears.

*See the SET command for more information on FILTER.

Example

Suppose you create a filter program named CONVERT/FLT that converts a linefeed character to a "null", and you establish it in memory with the SET library command to a device, *LF.

```
FILTER *PR USING *LF (ENTER)
```

filters I/O directed to the line printer through the CONVERT/FLT program. As a result of this filter program, all linefeed characters in output directed to the printer are converted to the null character (ASCII 0).

Sample Use

You can use a filter to control a printer working with non-standard size paper (see Appendix I and the FORMS library command).

FORMAT

Utility

FORMAT [:*drive* [(*parameters*)]]

Prepares a blank or old disk for use by defining the tracks and sectors and writing system information onto it. (For more information, see "Diskette Organization" in the *Technical Reference Manual* (Cat. No. 26-2110).)

You can use FORMAT to organize a disk so you can store information on it.

drive specifies the drive in which the blank or old disk is to be formatted. If you omit the *drive*, TRSDOS prompts you for it.

The *parameters* are:

ABS overwrites any existing data without prompting. The ABS parameter is used primarily when you execute a FORMAT from a JCL file. See the JCL section for more information.

NAME = "*disk name*" assigns a name to the disk being formatted.

MPW = "*password*" assigns the master password to the disk.

The master password allows limited access to all user files.

SDEN specifies the density of the disk as single.

DDEN specifies the density of the disk as double.

CYL = *number* specifies the number of cylinders (tracks) for the disk. *number* can be 35 to 96.

QUERY = NO turns off the prompts for density, number of cylinders, name, and password.

QUERY is the only parameter that can be abbreviated.

When to Format

To prepare a new disk. Before you can use a new disk, you must format it. After formatting, record the disk name, date of creation, and password. Store this information in a safe place. It helps you estimate how long a diskette has been in use. And, if you forget the master password, it ensures continued access.

To erase all data from a disk. To "start over" with a disk, you can reformat it. This erases all old information and locks out all flawed sectors which have developed. It puts the system information back on the disk and leaves the "good" sectors available for information storage.

The Format Prompts

If the destination drive is not ready, the following message is displayed:

Load destination diskette <ENTER>

Insert the destination diskette and press **(ENTER)** to continue, or press **(BREAK)** to return to TRSDOS Ready.

If you specify the drive number, disk name, or master password in the command line, you are not prompted for them.

If you specify either the DEN or CYL parameters, the system uses the default values for the other parameters.

If you enter a FORMAT command without specifying any parameters, you are prompted for them in the following order:

Which drive is to be used?

Enter the number of the drive you are formatting in.

Diskette name?

Enter any name with up to eight alphanumeric characters. The first character must be a letter. Press **(ENTER)** and the disk name defaults to DATADISK.

Master Password?

Enter any password with up to eight alphanumeric characters. The first character must be a letter. Pressing **(ENTER)** causes the master password to default to PASSWORD.

The remaining prompts concern the type of diskette you are using. Press **(ENTER)** in answer to each of them if you are using standard Radio Shack diskettes.

Single or Double density <S,D>?

Enter **(S)** for single density or **(D)** for double density. Press **(ENTER)** and the value defaults to double density.

Number of cylinders?

Enter any number from 35 to 40 on TRS-80 hardware. Pressing **(ENTER)** causes the system to default to the value set with the SYSTEM (CYL=) command. If this value is not set, the default is 40 cylinders.

If you are formatting in Drive 0, the following prompt appears after you answer the cylinders question:

Load destination disk **(ENTER)**

It is important that you do not remove the system disk and insert the disk to be formatted until this prompt appears. Several seconds after you swap disks, you are prompted to put the system disk back in Drive 0 with the message:

Load SYSTEM disk **(ENTER)**

The format is now complete.

Examples

FORMAT (ENTER)

prompts you for the drive number, the diskette name, the master password, the density, and number of cylinders, and checks to see if the destination disk is already formatted.

FORMAT :1 (NAME="DATA3",MPW="SECRET") (ENTER)

prompts you for the DEN and CYL parameters, and checks to see if the disk in Drive 1 is already formatted. The disk in Drive 1 is assigned the name DATA3 and the master password SECRET.

FORMAT :0 (NAME="FILES", MPW="FILE01", Q=N)
(ENTER)

displays the message:

Load destination disk (ENTER)

When you insert the destination disk in Drive 0, the system checks to see if the disk is already formatted. When the message:

Load SYSTEM disk (ENTER)

appears, insert the system disk in Drive 0 and the format is completed.

FORMAT :1 (QUERY=NO,ABS) (ENTER)

formats the disk in Drive 1 (with the default options) even if the disk already contains data. Because you specified the ABS parameter, you don't have the opportunity to abort the FORMAT (if the disk is already formatted and its master password is PASSWORD).

Error Conditions

After you enter a format command and before the actual formatting begins, the system checks the destination diskette to see if it is already formatted.

If the disk is formatted and its MPW is PASSWORD, the following message appears:

```
Disk contains data -- NAME=disk name
DATE=mm/dd/yy
Are you sure you want to format it?
```

Press (N) to abort the FORMAT or (Y) to continue. If you specified the ABS parameter in the command line, you see the DISK CONTAINS DATA message, but you are not prompted to abort the format.

If the disk is formatted and the master password of the destination disk is not **PASSWORD**, the following message appears:

```
Disk contains data -- NAME=disk name
DATE=mm/dd/yy
Enter its Master Password or <BREAK> to abort:
```

Press **BREAK** to abort the format or enter the master password to continue.

If the disk contains an incomplete or non-standard format, one of the following messages may appear in place of *NAME = disk name*:

```
Unreadable directory
Non-standard format
Non-initialized directory
```

When the format begins, you see the cylinder numbers appear as the necessary information is written to them. After all cylinders are written, **FORMAT** verifies that the proper information is actually on each cylinder.

If the verify procedure detects an error, an asterisk and the cylinder number are shown on the screen. That cylinder is locked out, so that no files can be written to the defective area. Use the **FREE** library command to see the locked out cylinders on a diskette.

During parts of the format operations, the system real time clock is turned off.

If you are formatting in Drive 0, the following prompt appears after you answer the cylinders question:

FORMS

FORMS [(parameters)]

Command

Sets up forms filter (*FF) parameters.

You can use FORMS to print a form larger or smaller than a standard-size page.

Before you can use FORMS, you have to SET *FF to its filter program FORMS/FLT and FILTER the printer to *FF. See Appendix I.

The *parameters* are:

DEFAULT returns all parameters to their start-up values.

ADDLF issues a linefeed after every carriage return.

CHARS=*number* sets the number of characters per printed line.
number is 1 - 255.

FFHARD issues a form feed (Top of Form) character instead of a series of linefeeds.

INDENT=*number* sets the number of spaces a line is to be indented if the line length exceeds CHARS. The default value for *number* is 0.

LINES=*number* sets the number of lines to be printed per page.
The default value for *number* is 66.

MARGIN=*number* sets the left margin.

PAGE=*number* sets the physical page size as *number* of lines.
The default value for *number* is 66.

QUERY prompts you for each parameter.

TAB specifies that tab characters are to be translated into the appropriate number of spaces.

XLATE=*X'aabb'* specifies a one-character translation to be performed by the filter.

aa is the character in hex format to be translated.

bb is the character in hex format *aa* is translated to.

To determine the parameters to set for:

page size	multiply form length in inches by the number of lines per inch.
-----------	---

lines per page	determine the number of blank lines at the bottom of every page. The default number of blank lines is 0. If LINES = PAGE, then text can be written on every line of each page. LINES cannot exceed PAGE.
----------------	--

characters per line	multiply form width in inches by the number of characters per inch (10 or 12). Use CHARS to set the maximum number of printable characters per line. If a line is greater than CHARS, then TRSDOS
---------------------	---

automatically breaks the line at the maximum length, and continues printing at the next line. The line is indented if you have specified INDENT.

Examples

Be sure that you have SET *FF to its filter program FORMS/FLT and you have FILTERed the printer to *FF with the commands:

```
SET *FF TO FORMS/FLT (ENTER)
FILTER *PR *FF (ENTER)
```

```
FORMS (ENTER)
```

displays the current parameter values.

```
FORMS (CHARS=80,INDENT=6,PAGE=51,
      LINES=45,FFHARD) (ENTER)
```

allows a maximum of 80 characters per printed line. If a line contains more than 80 characters, the excess is printed on the next line and indented 6 spaces. The physical page size is set to 51 lines, and 45 lines can be printed on a page.

FFHARD causes the printer to advance 6 linefeeds continuously rather than individually when the line count reaches 45. Be aware that certain printers cannot respond to FFHARD.

```
FORMS (MARGIN=10,CHARS=80,INDENT=16) (ENTER)
```

causes all lines to start 10 spaces in from the normal left-hand starting position. Any line longer than 80 characters is indented 16 spaces (6 spaces after the margin) when wrapped around, so it is printed starting at position 16.

```
FORMS (TAB,ADDLF) (ENTER)
```

specifies that tab characters are to be translated into the appropriate number of spaces. Also, a linefeed is sent to the printer every time a carriage return is sent.

```
FORMS (XLATE=X'2A2E') (ENTER)
```

translates all hexadecimal 2A characters (asterisks) to hexadecimal 2E characters (periods).

Sample Uses

Suppose you have a payroll program that contains all of your employees' payroll information, and that prints checks of the size 4" × 7".

To instruct your computer to print a form 4" × 7", issue the following commands:

SET *FF TO FORMS/FLT (ENTER)

FILTER *PR *FF (ENTER)

FORMS (CHARS=55,LINES=20,PAGE=24) (ENTER)

Now when you run your payroll program, you can print the checks on the proper size form.

FREE

FREE [:*drive*] [(*parameter*)]

Command

Lists the amount of space that is free (available for use) and the number of files on each drive, if no *drive* is specified. If *drive* is specified, displays a free-space map of the disk in that drive.

You can use FREE to see how many files are on a disk. You can also use FREE to see a table containing information about each disk in your computer.

The parameter is:

PRT sends output to the printer.

FREE displays free-space information about each enabled disk in the following format:

```
Drive :0  TRSDOS60  02/02/83  Free Space =  94,50K / 180,00K  Files =  96/128
Drive :1  TRSDOS60  02/17/83  Free Space =  91,50K / 180,00K  Files =  97/128
Drive :2  [No Disk ]
Drive :3  [No Disk ]
```

1. Drive number — The number of the drive whose free space map is displayed.
2. Disk name — The name of the disk.
3. Date — Creation date.
4. Free space in K — The amount of space (in K) that is available for use. 1K = 1024 bytes.
5. Total space in K — The total amount of space (in K) on the disk.
6. Number of files — The number of directory entries you have available. Each file uses one or more directory slots.
7. Total number of files — The total number of directory slots available on the disk.

FREE displays a free space map of the specified disk in the format shown below.

```

Drive :0 TRSDOS60 02/02/83 Free Space = 94.50K/ 180.00K Files = 96/128
-----
0- 7 xxx   ...   ...   ...   ...   ...   ...   ...
8- 15 ...   x..   ...   ...   ...   xxx   xxx   xxx
16- 23 xxx   xxx   xxx   xxx   DDD   xxx   xxx   xxx ← 6
24- 31 xxx   xxx   xxx   xxx   xxx   xxx   x..   ...
32- 39 ...   ...   x..   ...   ...   ...   ...   ...
-----
Type => 5" Floppy Heads = 1 Density = DOUBLE Note - 1 Position = 1.50K
      ↑   ↑   ↑           ↑           ↑
    (1) (2) (3)         (4)         (5)

```

1. Disk size — The size of the floppy or hard disk.
2. Type of drive — Either floppy or hard.
3. Number of heads — The number of surfaces on the disk that contain data for this logical drive.
4. Density — The density of the disk (SINGLE or DOUBLE).
5. Note — 1 Position = 1.50 K. — The minimum allocation of disk space for the disk type (hard or floppy). This value will change depending on the type of drive.
6. Detailed space allocation map — The organization of data on the disk.

The numbers on the left represent the cylinders on the disk, and these cylinders are divided into granules (grans). The grans for the specified cylinders run across each line.

Each gran is represented by one of the following characters:

- . Unused — The gran is available for use.
- * Locked out — The gran is flawed and not available for use.
- X Used — The gran is currently used for system or user files.
- D Directory — The gran is used for the system's directory files.

Examples

```
FREE (ENTER)
```

displays free space information about each enabled disk.

```
FREE :0 (PRT) (ENTER)
```

displays a free space map of the disk in Drive 0. The map is also sent to the printer because you specified the PRT parameter.

LIB

LIB	Command
-----	---------

Displays a listing of all system commands in Libraries <A>, , and <C>.

You can use LIB to see a list of TRSDOS commands.

Library <A> contains the primary TRSDOS commands, Library contains the secondary commands, and Library <C> contains the machine-dependent commands.

Example

LIB **ENTER**

displays a list of the TRSDOS library commands.

Library <A>

Append	Copy	Device	Dir	Do	Filter	Lib
Link	List	Load	Memory	Remove	Rename	Reset
Route	Run	Set				

Library

Attrib	Auto	Build	Create	Date	Debug	Dump
Free	Purge	Time	Verify			

Library <C>

Forms	Setcom	Setki	Spool	Sysgen	System
-------	--------	-------	-------	--------	--------

Technical Information

Library <A> is located in the SYS6/SYS system module, Library is located in the SYS7/SYS system module, and Library <C> is located in the SYS8/SYS system module. You can remove any of the three system modules if you will not be using their commands. (Use the PURGE or REMOVE library commands to delete system modules.)

Advanced Programmer's Command
LINK *devspec1* [TO] *devspec2*

Links together two logical devices; both must be enabled in the system.

You can use LINK to get a printout of the data displayed on your video display. You can also use LINK to write data displayed on the screen to a disk file.

To “unlink” the devices, use the RESET command.

Be careful if you make several links to the same device. You could create an endless loop and hang up the system.

Examples

```
LINK *DO *PR (ENTER)
```

links the video display (*DO) to the line printer (*PR). All output sent to the display (*devspec1*) is also sent to the line printer (*devspec2*).

NOTE: Although all output to the video display is also sent to the printer, any output sent individually to the printer (such as an LPRINT from BASIC) is *not* sent to the video display. This is because the order of the devices in the link command line is important. Once linked, any information sent to *devspec1* is also sent to *devspec2*, and any information requested from *devspec1* can also be supplied by *devspec2*. However, information sent to *devspec2* is not sent to *devspec1*, nor can information requested from *devspec2* be supplied by *devspec1*.

```
LINK *PR *DO (ENTER)
```

links the line printer to the video display. All output sent to the printer (*devspec1*) is also sent to the video display (*devspec2*).

Linking a Device To a File

It is not possible to directly LINK a device to a file. To link a device to a file, follow this procedure:

- Use the ROUTE library command to create a “phantom” device and route it to the file.
- Link the device to the phantom device using the LINK library command.

NOTE: Do not use the SYSGEN library command if you currently have a device linked to a file. The linked file is shown as open every time you power up or reset the system. You can overwrite other files very easily if you switch disks with the linked file open.

The following example shows how to link your line printer to the disk file PRINT/TXT on Drive 0 using a phantom device.

```
ROUTE *DU TO PRINT/TXT:0 (ENTER)
```

creates the phantom device *DU and routes it to the disk file PRINT/TXT on Drive 0. If PRINT/TXT does not exist, it is created. If it already exists, data sent to the file is appended onto its end.

```
LINK *PR *DU (ENTER)
```

links the printer to *DU, which in turn is routed to PRINT/TXT. All output sent to the line printer is also sent to *DU (that is, written to PRINT/TXT).

NOTE: PRINT/TXT remains open until you issue a RESET *DU command. To break the link between the printer and PRINT/TXT without closing the file, use the RESET *PR command. See the ROUTE and RESET library commands; also see the "Using the Device-Related Commands" section.

Sample Use

Suppose you want to use your computer to communicate with another computer. First, set the Communications Line device (*CL) and use SETCOM to specify WORD=8 and PARITY=NO with the commands:

```
SET *CL TO COM/DVR (ENTER)  
SETCOM (WORD=8,PARITY=NO) (ENTER)
```

then issue commands:

```
LINK *DO *CL  
LINK *KI *CL
```

to link the video display and keyboard to the RS-232C interface. This lets your Model 4 act as a "host" and be accessed by a remote terminal via the RS-232C hardware.

LIST

LIST *filespec* [(*parameters*)]

Command

Lists the contents of *filespec*.

You can use LIST to see the contents of a file on a disk.

The parameters are:

ASCII8 displays the graphic characters and special characters in a file, along with the text.

NUM numbers the lines in ASCII text files.

HEX specifies hexadecimal output format. When you specify the HEX parameter, NUM and LINE are ignored.

TAB = *number* specifies that tab stops are to be placed every *number* of spaces apart for ASCII text files. Each tab character (hex 09) encountered causes a jump to the next tab stop. The default value for *number* is 8.

PRT directs output to the printer.

LINE = *number* sets the starting line to *number*. If you omit the LINE = parameter, TRSDOS uses 1. This parameter works only with ASCII files.

REC = *number* sets the starting record number to *number*. If you omit the REC = parameter, TRSDOS uses 0. The REC = parameter is used only with the HEX parameter.

LRL = *number* sets the logical record length to be used to display a file with a record length of *number*. If you omit the LRL = parameter, TRSDOS uses the logical record length of the file. The LRL = parameter is used only with the HEX parameter.

LINE cannot be abbreviated, and the abbreviation for ASCII8 is A8.

When you enter a LIST command, LIST first searches for *filename*/TXT. If it cannot find *filename*/TXT, it searches for *filename*.

Press **SHIFT** **@** to pause a list. Press **ENTER** to continue. Press **BREAK** to abort the list.

When you use the HEX parameter, *filespec* is listed in the following format:

The diagram shows a hex dump with two lines of data. Above the first line, there are four circled numbers: 1, 2, 3, and 4. Arrows point from these numbers to specific parts of the hex dump. Arrow 1 points to the address field '0000:00'. Arrow 2 points to the first byte '41'. Arrow 3 points to the byte '46'. Arrow 4 points to the ASCII string 'ABCDEFGH'. The hex dump itself is as follows:

```
0000:00 = 41 42 43 44 45 46 47 48 49 4A 4B 4C 4D 4E 4F 50 ABCDEFGH IJKLMNOP
0000:10 = 51 52 53 54 55 56 57 58 59 5A 0D QRSTUVWX YZ.
```

1. Current logical record of the file in hex notation, starting with record 0.

-
2. Offset from the first byte of the current logical record (in hex notation).
 3. Hex representation of the byte listed.
 4. ASCII representation of the byte. A period is used for all non-displayable bytes.

Examples

```
LIST TESTFILE:Ø ENTER
```

searches Drive Ø for TESTFILE/TXT. If not found, it searches for TESTFILE.

```
LIST MONITOR/CMD (HEX,LRL=8)
```

lists MONITOR/CMD in the hexadecimal mode using an LRL of 8.

```
LIST REPLY/TXT (NUM,TAB=1Ø,P) ENTER
```

prints a listing of REPLY/TXT on the printer, numbering each line that is printed. Lines are numbered beginning with 00001. Any tab character encountered causes a jump to the next tab position (every 10th column).

```
LIST TESTFILE/OBJ (HEX,REC=5) ENTER
```

list TESTFILE/OBJ in the hex mode, beginning with record 5.

Sample Use

Suppose you used BUILD to create a file named HEXFILE/TXT which contains hexadecimal characters that are not available from the keyboard. Issue the command:

```
LIST HEXFILE/TXT ENTER
```

and the special characters are displayed on the screen.

LOAD

Advanced Programmer's Command

LOAD [(parameter)] filespec

Loads a machine-language program file (without executing it) and then returns to TRSDOS Ready.

You can use LOAD to pre-load assembly language routines that programs written in a language such as BASIC can call.

The parameter is:

X loads a file from a non-system disk.

The file must be in load module format. Do not use it to load BASIC program files. The default file extension for the LOAD command is /CMD.

Programs to be loaded must reside at or above the address X'3000'.

Examples

```
LOAD STATUS/CMD (ENTER)
```

loads the file STATUS/CMD into memory.

```
LOAD (X) PROGRAM/CIM (ENTER)
```

loads PROGRAM/CIM from a non-system disk. The system prompts you to insert the disk with the desired file on it with the message:

```
Insert SOURCE disk (ENTER)
```

After the file is loaded, you are prompted to put the system disk back in Drive 0 with the message:

```
Insert SYSTEM disk (ENTER)
```

The load is now complete.

Sample Use

Often several program modules must be loaded into memory for use by a master program. For example, suppose PAYROLL/PT1 and PAYROLL/PT2 are modules, and MENU/CMD is the master program. Then you could use the commands:

```
LOAD PAYROLL/PT1 (ENTER)  
LOAD PAYROLL/PT2 (ENTER)
```

to get modules into memory, and then type: MENU to load and execute MENU.

LOG/CMD

Utility

LOG/CMD is used in Radio Shack hard disk installations. See your hard disk manual for an explanation on how to use this utility.

MEMORY

<div>Advanced Programmer's Command</div> <div>MEMORY [(parameters)]</div>
--

allows you to reserve a portion of memory, display or change the current HIGH\$ and LOW\$, modify a memory address, or begin executing at a specified memory location. HIGH\$ has to be higher than LOW\$.

You can use MEMORY to find out which area of memory you can use.

The *parameters* are:

CLEAR = *value* fills memory from hex 2600 to HIGH\$ with *value*. *value* in the format X'nn'. If you do not specify *value*, memory is filled with the hexadecimal value 00 (null).

HIGH = *address* sets *address* as HIGH\$. *address* must be less than the current HIGH\$.

LOW = *address* sets *address* as LOW\$. If you specify LOW, the current LOW\$ is displayed.

Note: Subsequent MEMORY commands (and any other system level commands) will reset LOW\$ to its default value.

ADD = *address* displays the word at *address* and specifies the address of WORD and BYTE. If you specify ADD, the current contents of the address are displayed and WORD and BYTE are not necessary.

WORD = *word* changes the contents of ADD and ADD + 1 to *word*.

BYTE = *byte* changes the contents of ADD to *byte*.

GO = *address* transfers control to *address*. If more than one parameter is specified, the GO parameter is always executed last.

address is any memory address in hexadecimal or decimal notation.

word is any value in the range 0000 - FFFF hexadecimal or 0 -

65535 decimal. *byte* is any value in the range 00 - FF hexadecimal or 0 - 255 decimal.

Examples

```
MEMORY (ENTER)
```

displays HIGH\$ (the highest unused memory location) and LOW\$ (the lowest reserved memory location) in the hexadecimal X'nnnn' format.

```
MEMORY (HIGH=X'E100') (ENTER)
```

sets HIGH\$ to hexadecimal memory address E100, as long as the existing HIGH\$ is above X'E100'. The MEMORY command moves HIGH\$ lower in memory.

```
MEMORY (ADD=X'6500') (ENTER)
```

displays the contents of hexadecimal memory addresses 6500 and 6501 in the following format:

```
X'6500' = 25856 (X'6745')
High = X'E100' Low = X'2FFF'
```

- 1 The address specified in hexadecimal notation.
- 2 The decimal equivalent of the address.
- 3 The contents of address and address + 1, in MSB-LSB format.
- 4 The current HIGH\$ address.
- 5 The current LOW\$ address.

```
MEMORY (ADD=X'E100',WORD=X'3E0A') (ENTER)
```

modifies hexadecimal memory locations ADD (E100) and ADD + 1 (E101), changing them to the value of WORD. The following display appears:

```
X'E100' = 57600 (X'0000' => X'3E0A')
High = X'E100' Low = X'2FFF'
```

- 1 The address specified in hexadecimal notation.
- 2 The decimal equivalent of the address.
- 3 The new contents of address and address + 1, in MSB-LSB format.
- 4 The current HIGH\$ address.
- 5 6The current LOW\$ address.

```
MEMORY (ADD=X'E100',BYTE=X'C9') (ENTER)
```

changes the BYTE of memory at hexadecimal address E100 to hexadecimal C9. The display after executing this command is:

```
X'E100' = 57600 (X'00' => X'C9')
High = X'E100' Low = X'2FFF'
```

The display is identical to the last example, except that the modified BYTE is shown instead of the modified WORD.

```
MEMORY (GO"X'E100') (ENTER)
```

transfers control to hexadecimal memory address E100.

Error Conditions

If you set LOW\$ equal to or higher than HIGH\$, you get the error message "Range error."

PATCH

Lets you make minor corrections in any disk file by (1) typing in the patch code directly from the command line (Method A), or (2) creating an ASCII file containing patch information (Method B).

You can use PATCH to make minor corrections in any disk file.

You can use PATCH to make minor changes in your own machine-language programs. You need not change the source code, reassemble it, and recreate the file. You can use PATCH to make minor replacement changes in data files, also.

Method A

Advanced Programmer's Utility
PATCH *filespec* (*patch commands*)

Makes minor corrections in *filespec* by letting you type in the patch code directly from the command line. You can use only the *address* patch command for this type of patch.

Method B

Advanced Programmer's Utility
PATCH *filespec1* USING *filespec2* [(*parameters*)]

Makes minor changes (which are contained in *filespec2*) to *filespec1*.

filespec1 is the file to be changed and /CMD is its default extension. *filespec2* contains the patch commands. *filespec2* can contain only ASCII characters and /FIX is its default extension.

The *patch commands* are:

address = value identifies the PATCH as a patch by "memory load location." It changes the contents of memory beginning with *address* to *value*.

Drecord,byte = value identifies the PATCH as a "direct modify patch." *record* tells which record contains the data to be changed. It is a hexadecimal number from 00 to FF. *byte* specifies the position of the first byte to be changed. It is a hexadecimal number from 00 to FF.

Frecord,byte = value lets you make sure that a patch is applied to the correct place in memory, when used in conjunction with the D *patch command*. *Frecord,byte* follows *Drecord,byte*. If the location specified with the D *patch command* does not contain the data specified with *Frecord,byte*, then the PATCH aborts. *Frecord,byte* is also used with the REMOVE parameter to remove a patch and replace it with the original data.

Lcode identifies the PATCH as a "library mode patch." The PATCH applies to either the SYS6/SYS, SYS7/SYS, or

SYS8/SYS library command module. *code* is the binary coded location in the format *nn* where the change begins.

address is a four-digit hexadecimal value in the format X'*nnnn*' which is the memory load address for the change.

value can be either a series of hexadecimal bytes in the format *nn nn nn...*, or a string of ASCII characters in the format "*string*."

The *parameters* are:

YANK removes the PATCH specified by *filespec2* from *filespec1*.

The specified PATCH contains code in the *address* format.

REMOVE removes the PATCH specified by *filespec2* from *filespec1*. The specified PATCH contains code in the *Drecord,byte* format.

An **address patch command** changes a file by "memory load location." It adds the patch code to the end of the *filespec* and then makes the changes beginning at *address* each time the file is loaded. You can use YANK to remove the added code from *filespec*. This type of patch can be applied only to files that can be loaded with the LOAD or RUN library command.

A **Drecord,byte:Frecord,byte patch command** changes a file by "direct modify patch." It changes a file by directly applying the patch code to the specified record and byte of *filespec*. When you BUILD a file containing *patch commands* in this format, you can REMOVE the patch.

An easy way for you to find the record and byte of *filespec* that you want to patch is to list *filespec* using the LIST library command with the HEX parameter. Remember that the first record in a file is record 0, not record 1.

Lcode patch command patches are supplied by Radio Shack for you to implement changes to TRSDOS. You have to BUILD a patch file to apply this type of PATCH.

You can specify more than one line of patch code from the command line by placing a colon (:) between the lines of patch code.

Examples

These examples are used to show the syntax and development of the PATCH command, so do not execute them.

```
PATCH MONITOR/CMD (X'E100'=C3 66 00 CD 03 40)
ENTER
```

patches the file MONITOR/CMD by the memory load location method. The six bytes beginning at hexadecimal E100 are changed. During the PATCH operation, the following message is displayed:

```
Installing Patch
```

When the operation is completed, this message appears:

```
Patch function completed
x Patch lines installed
```

x is the number of lines of patch code that were installed.

Since there is no filespec used for the patch code, the name CLP (Command Line Patch) is assigned to the patch code. You can use this name to later YANK the patch from MONITOR/CMD.

Error Conditions

It is important that you do not patch a file more than once using the same name for *filespec2* because you cannot YANK the second patch from the file.

We recommend that you name all patch files in a systematic manner and that you use the extension /FIX for all of the files.

Using BUILD To Create a PATCH File

You can use the BUILD library command to create a PATCH file. (See the "Building a File" section of the BUILD library command.) A PATCH file can contain only ASCII characters.

Each line in a patch file is either a *patch command* or a comment. Comment lines begin with a period and are ignored by the patch utility. Use comments in patch files to document the changes that you make. You can append a comment onto the end of a *patch command* by using a semicolon to separate the two parts.

You can also use SCRIPSIT to create a PATCH file. When you create a PATCH file with SCRIPSIT, use the S,A type of save. SCRIPSIT sometimes leaves extra spaces after the last carriage return in a file. To remove the extra spaces, position the cursor just after the last carriage return in the file and do a delete to end of text.

Examples

These examples are used to show the syntax and development of the PATCH command, so do not execute them.

```
PATCH BACKUP/CMD:0 USING SPECIAL/FIX (ENTER)
```

The data in BACKUP/CMD on Drive 0 is changed to 23 3E 87 beginning at hexadecimal 6178. The data beginning at hexadecimal 61A0 is changed to FF 00 00. This is an example of a memory load location patch, and since the patch is added onto the end of BACKUP/CMD, you can use the YANK parameter to remove it.

Use the BUILD library command to create the following PATCH file named TEST/FIX:

```
.This patch modifies the SYS2 module.  
D0B,49 = EF CD 44 65:F0B,49 = DD 3A 33 44  
D0B,55 = C3 00 00:F0B,55 = EF 44 55  
.End of patch
```

Now, type in the command line:

```
PATCH SYS2/SYS.PASSWORD USING TEXT/FIX (ENTER)
```

changes the data specified in SYS2/SYS.PASSWORD to the data in TEST/FIX. Since the data beginning at record 0B, byte 49 and 55 is directly changed on disk, this is an example of a direct disk modify patch. The Find *patch commands* let you make sure you are patching the correct place in memory.

Using PATCH on a TRSDOS System File

When Radio Shack releases a modification to TRSDOS, you receive a printout of the exact *patch commands* that you must use to make the change.

Suppose Radio Shack sends you the patch information for a file named LIB1 that contains the following patch code:

```
.USE LIB1 TO PATCH SYS6/SYS.  
L54  
X'5208' = 32 20 DE AF 00 C3 66 00
```

Use the BUILD library command to create the file LIB1, and type in the lines exactly as they appear on the printout. After you end the file, type in the command line:

```
PATCH SYS6/SYS:1 USING LIB1 ENTER
```

This changes the data specified in SYS6/SYS on Drive 1 to the data in LIB1/FIX. Since you did not specify an extension to LIB1, it defaulted to /FIX. This patch is in the memory load location mode. Library patches can also be done with the direct disk modify mode. To be sure that you do not patch the disk in Drive 0, specify the drive number in the filespec (such as SYS6/SYS:2) or write protect the disk in Drive 0.

PATCH lets you implement any changes to TRSDOS that may be supplied by Radio Shack. This way, you do not have to wait for a new release of TRSDOS.

To make a Radio Shack change, follow these general steps:

1. Make a backup copy of the diskette to be patched.
2. Insert the TRSDOS diskette to be changed into one of the drives. (Make sure the diskette is "write-enabled.")
3. In the TRSDOS mode, use the BUILD library command to create a PATCH file containing the patch commands specified in the information provided by Radio Shack.
4. Issue the appropriate PATCH command.
5. After the patch is complete, test the patched diskette in Drive 0 to see that it is operating as a TRSDOS system diskette. You have to reset the computer before you can test the diskette.

PURGE

PURGE [<i>partspec</i>] : <i>drive</i> [(<i>parameters</i>)]	Command
---	----------------

Quickly deletes files from the disk in *drive*.

You can use PURGE to remove all or some of the files on a disk with one command.

The parameters are:

QUERY=NO automatically removes files without prompting for each one.

MPW="password" states the disk master password

INV removes the invisible files as well as the visible files.

SYS removes the system files as well as the visible files.

DATE="M1/D1/Y1-M2/D2/Y2" removes the files with modify dates between the two specified dates, inclusive.

= "M1/D1/Y1" removes the files with modify dates equal to the specified date.

= "-M1/D1/Y1" removes the files with modify dates before or equal to the specified date.

= "M1/D1/Y1-" removes the files with modify dates after or equal to the specified date.

Once you enter the PURGE command, TRSDOS prompts you for the disk's password (if it is not PASSWORD), unless you specified it with the MPW parameter.

Then, the system displays the files one at a time. It prompts you to remove the file or keep it. Respond with **(Y)** to remove the file or **(N)** to keep it. Pressing **(ENTER)** skips the file.

NOTE: BOOT/SYS and DIR/SYS cannot be purged and do not appear during execution of any PURGE command.

Examples

```
PURGE :0 (MPW="SECRET") (ENTER)
```

purges all visible files on Drive 0 if the master password of the disk is SECRET. If SECRET is not the master password, the purge aborts with an error message. The purge shows each file and waits until **(Y)**, **(N)**, or **(ENTER)** is pressed before displaying the next file.

```
PURGE :1 (QUERY=NO,INV,SYS) (ENTER)
```

purges ALL files from Drive 1. You are not questioned before each file is removed, as QUERY is specified as NO. Be careful with this command because it produces a blank formatted disk.

```
PURGE /BAS:1 (Q=NO) (ENTER)
```

purges all visible files with the extension /BAS. You are not questioned before each file is removed, as QUERY is specified as NO.

PURGE /\$\$S:2 (ENTER)

purges all visible files on Drive 2 whose file extension contains 3 characters and ends in the letter S.

PURGE -/CMD:0 (INV) (ENTER)

purges all non-system files from Drive 0 except those with the extension /CMD.

PURGE :1 (DATE="02/01/81-") (ENTER)

purges all visible files on Drive 1 with modify dates of February 1, 1981 or later. You are questioned before each file is removed.

Sample Use

Refer to the Sample Use example in the BACKUP command section. Now that you have moved all of the new files to the disk in Drive 1, you can remove all the new files on the disk in Drive 0 by issuing the command:

PURGE /NEW:0 (ENTER)

Now you have two separate disks: one with new employee files on it and one with old employee files on it.

REMOVE

REMOVE *filespec* [*filespec* ...]

Command

Deletes *filespec* from the directory and frees the space allocated to it.

REMOVE *devspec* [*devspec* ...]

Command

Removes *devspec* from the device table.

You can use REMOVE to remove a file that you don't need to use anymore. You can also REMOVE a device that is no longer needed.

Examples

```
REMOVE ALPHA/DAT:0 BREAKER/DAT:0 (ENTER)
```

deletes ALPHA/DAT and BREAKER/DAT from the directory on Drive 0 and frees all space allocated to them.

```
REMOVE MIDWEST/DAT,SECRET (ENTER)
```

deletes MIDWEST/DAT. If the file is protected at a level of RENAME or higher, the owner password must be used to remove the file. If you supply the user password, the error message "Illegal access attempted to protected file" is displayed. If you supply the wrong password, the error message "File access denied" is displayed.

```
REMOVE *LU (ENTER)
```

removes the user-created device *LU from the device table.

NOTE: A device can be removed only if it is pointed NIL in the device table. If a device is not pointed to NIL, it must first be reset with the RESET library command before it can be removed.

TRSDOS does not permit the removing of the system devices: *JL, *KI, *DO, *SI, *SO, and *PR. Attempting to remove these devices produces the error message "Protected system device."

Sample Use

Suppose you have a file of temporary employees that you hire for inventory. All of the temporary employees' files are in a file named EMPLOYE/TEM. When you complete inventory, you can remove this file with the command:

```
REMOVE EMPLOYE/TEM (ENTER)
```

RENAME

Command

```
RENAME filespec1 [TO] filespec2  
RENAME devspec1 [TO] devspec2
```

Changes a file's name and/or extension from *filespec1* to *filespec2*. It also changes a device name from *devspec1* to *devspec2*.

You can use RENAME to change the name of a file or a device.

RENAME does not change the file's password, contents, or position on the disk. (See the ATTRIB command to change the password.) If *filespec1* is password protected, the password must be specified or an error message will result.

RENAME does not change a device's routing, filtering, linking, or setting. *devspec1* must be an existing device, and *devspec2* must be an unused device name.

You cannot RENAME the system devices: *KI, *DO, *PR, *SI, *SO, and *JL.

Examples

```
RENAME TEST/DAT:0 TO OLD/DAT (ENTER)
```

renames TEST/DAT on Drive 0 to OLD/DAT.

```
RENAME TEST/DAT:0 TO REAL (ENTER)
```

renames TEST/DAT on Drive 0 to REAL/DAT. Since you did not specify an extension for *filespec2*, it defaulted to the extension on *filespec1* (DAT).

```
RENAME TEST/DAT:0 TO REAL/ (ENTER)
```

renames TEST/DAT on Drive 0 to REAL (without an extension).

```
RENAME DATA/NEW.SECRET:1 TO /OLD (ENTER)
```

renames the password protected DATA/NEW.SECRET on Drive 1 to DATA/OLD.SECRET. Since you did not specify a filename for *filespec2*, it defaulted to that of *filespec1*. RENAME does not change or delete passwords, so the password defaulted also.

```
RENAME *UD TO *TX (ENTER)
```

renames the device *UD to *TX.

Error Conditions:

Suppose you want to rename TESTER/BAS to TESTER (without an extension). Typing:

```
RENAME TESTER/BAS TO TESTER (ENTER)
```

produces the error message "Destination spec required" because you did not add a "/" to TESTER.

Suppose you want to rename TEST/JCL to TEST/ABS, but the file TEST/ABS already exists. Typing:

```
RENAME TEST/JCL TO TEST/ABS (ENTER)
```

produces the error message "Duplicate file name" because TEST/ABS already exists.

REPAIR (REPAIR/CMD)

Utility

REPAIR :*drive*

Updates and modifies information on floppy disks produced on other Radio Shack operating systems and computers so TRSDOS Version 6 can use them.

drive is any floppy drive currently enabled in the system (except Drive 0).

After REPAIR is complete, you should be able to copy any file off the modified diskette.

Use REPAIR to read any disk formatted by any disk operating system other than TRSDOS Version 6, LDOS 5.1.3, or their successors.

Once a disk is modified by TRSDOS, the operating system that created it may not be able to read it.

TRSDOS 1.2 and 1.3 disks should NEVER be repaired. Use the CONV utility to copy programs from them.

Using REPAIR, you can convert the following list of operating system diskettes to TRSDOS Version 6 diskettes:

- Model I TRSDOS 2.0, 2.1, 2.2, 2.3, 2.3a

Examples

REPAIR :1 **(ENTER)**

updates information on the diskette in Drive 1 so that TRSDOS can use it.

RESET

Advanced Programmer's Command

RESET *devspec*
RESET *filespec*

Returns a *devspec* to its original start-up condition. Closes an open *filespec*.

You can use RESET to set a system device to its normal condition in the DEVICE table. You can also use RESET to close a file that has not been properly closed.

Resetting α Device

A RESET *devspec* command removes any filtering, linking, or routing that has been set to the device. Any open disk file that is connected to the device is closed.

If *devspec* is a device you created (see the LINK and ROUTE library commands), it is pointed at NIL when reset.

If *devspec* is a system device (*KI, *DO, *PR, *SI, *SO, and *JL), it returns to its start-up condition when reset.

To see that *devspec* has been pointed at NIL or returned to its start-up condition, issue a DEVICE library command and examine the device table that is displayed.

You can use the REMOVE library command to remove the device from the device table once it points at NIL.

Example

Suppose you have used the FORMS command to specify printer parameters, or you have filtered, linked, or routed *PR.

```
RESET *PR (ENTER)
```

returns *PR to its start-up condition and disconnects the printer filter.

Resetting α Filespec

You can RESET an open *filespec* that has not been properly closed.

Improperly closed files result when (1) your system loses power and files are left open, (2) you remove a disk from a drive and files are left open, or (3) you reset your system while files are open, or (4) a command aborts while files are open.

To see if any files on a disk are not properly closed, issue a DIR library command. Any file that appears with a question mark (?) after it needs to be RESET before you can access it. Receiving the error "File already open" may also indicate a file is not properly closed.

Example

Suppose that your system lost power and there is a file named PRINTER/DAT that is not properly closed.

RESET PRINTER/DAT **ENTER**

closes the file named PRINTER/DAT and lets you access it.

ROUTE

Advanced Programmer's Command

```
ROUTE devspec1 [TO] devspec2
ROUTE devspec1 [TO] filespec [(REWIND)]
ROUTE devspec1 (NIL)
```

Routes *devspec1* to one of the following:

- another device (*devspec2*)
- a disk file (*filespec*)
- nothing (NIL)

You can use ROUTE to create a device. You can also use ROUTE to alter the flow of data from one device to another.

If *devspec1* does not already exist, ROUTE creates it.

To see how your devices are routed, use the DEVICE command. To return the non-system devices to their normal start-up state, use the RESET and REMOVE commands.

Examples

```
ROUTE *PR *DO
```

routes the printer (*PR) to the video display (*DO). All data normally sent to the printer will be displayed on the screen.

```
ROUTE *PR TO PRINTER/DAT
```

routes the printer (*PR) to a disk file (PRINTER/DAT). All data normally sent to the printer will be stored in a disk file named PRINTER/DAT. If PRINTER/DAT already exists, the data is appended to the end of the file.

```
RESET *PR
```

closes the PRINTER/DAT file and any subsequent output to *PR goes to the printer. The PRINTER/DAT remains open until you execute the above command.

```
ROUTE *PR TO PRINTER/DAT (REWIND)
```

routes the printer to PRINTER/DAT. If PRINTER/DAT already exists, the system "rewinds" the file to the beginning. The contents of the file will be replaced with the new printer data.

```
ROUTE *PR (NIL)
```

routes *PR to NIL. TRSDOS ignores all output to the printer.

```
ROUTE *DU TO TEST/TXT:1
```

routes a user device (*DU) to a disk file named TEST/TXT in Drive 1.

Error Condition

If you ROUTE *CL to a file and you are receiving data from a communications line (*CL), you might lose data if it is coming in at a high speed. If so, use CREATE to preallocate file space before using ROUTE. This makes data loss less likely because the system no longer has to spend the time allocating more space.

Sample Use

Suppose you want to route a report-producing program to a file (instead of printing the report). Issue the command:

```
ROUTE *PR TO REPORT/DAT (ENTER)
```

Now you can run the program and the report that it produces is routed to the file REPORT/DAT. This means that you can print the report in the file REPORT/DAT whenever you want by using the LIST command.

NOTE: Remember, you must reset *PR before listing the file so that it will be properly closed.

RUN

[RUN] [(X)] *filespec* [*command text*]

Command

Loads a program named *filespec* into memory and executes it.

You can use RUN to execute a program.

Typing RUN is optional. You can load and execute a program from the TRSDOS Ready prompt by simply typing in the name of the program (without the RUN).

The default extension for *filespec* is CMD.

X executes a program from a non-system disk for the single drive user.

Command text is an optional value which the program you specified may require.

When running a program, observe the following address restrictions:

RUN *filespec* must load above X'2FFF'.

RUN (X) *filespec* must load above X'2FFF'.

Examples

RUN CONTROL/CMD **(ENTER)**

loads a program named CONTROL/CMD and executes it.

CONTROL/CMD **(ENTER)**

loads a program named CONTROL/CMD and executes it.

RUN PROG **(ENTER)**

loads a program named PROG/CMD and executes it. Since you did not supply a file extension, it defaulted to /CMD.

RUN (X) TRADERS/CMD:0 **(ENTER)**

loads TRADERS/CMD from a non-system disk. First you are prompted with the message:

Insert SOURCE disk **(ENTER)**

Insert the disk containing the program into Drive 0 and press **(ENTER)**. After the program is loaded into memory, you are prompted with:

Insert SYSTEM disk **(ENTER)**

Insert the system disk back into Drive 0 and press **(ENTER)**; program execution begins.

SET

Sets a driver or filter program to a device. This command is for advanced programming applications.

You can use SET to tell TRSDOS the name of a filter or driver program that you are going to use.

A driver program channels data to or from a device. If it is outputting to a device, it converts data to the device's format. If it is inputting from a device, it converts the data to the computer's format.

A filter program filters data before it is sent out or after it is received.

Once the device is SET, it remains SET until it is RESET. You cannot SET an active device.

Setting a Driver Program

<p style="text-align: center;">Advanced Programmer's Command</p> <p>SET <i>devspec</i> [TO] <i>driver filespec</i> [<i>parameters</i>]</p>
--

Loads *driver filespec* into memory and sets it to *devspec*. The driver filespec can be one of your own driver programs.

Once you set a system device to a driver, the device is controlled by your own driver program, rather than the TRSDOS driver program.

The parameters are values sent to the driver filespec. These parameters are totally independent of the SET command. They are determined only by the needs of your driver program.

Example

Within TRSDOS is a driver program that sends printer output to the parallel port. Suppose you write a driver program named SERIAL/DVR that sends printer output to the serial port.

```
SET *SP TO SERIAL/DVR (ENTER)
```

loads SERIAL/DVR into memory and sets it to the device *SP.

```
ROUTE *PR TO *SP (ENTER)
```

routes data going to the printer to the device *SP. Now any input to the printer goes to the SERIAL/DVR program. The SERIAL/DVR program, in turn, sends the output to the serial port.

By using a LINK command instead of the ROUTE command, data sent to *PR is sent to the TRSDOS parallel printer driver. It is also sent (via the LINK) to the serial driver and then to the serial printer.

Setting a filter program

<p style="text-align: right;">Advanced Programmer's Command</p> <p>SET <i>phantom devspec</i> [TO] <i>filter filespec</i> [USING] [<i>parameters</i>]</p>

loads the driver or filter specified by *filter filespec* into memory and connects it to *phantom devspec* (a non-existing device). You must then use the FILTER command to connect the phantom device to a real device.

The filter filespec can be the KSM/FLT program (listed in Appendix I) or one of your own filter programs.

Once you have (1) set a phantom device to a filter, and then (2) filtered a device to the phantom device, the device is connected to your filter program. All data input and output to the device is filtered through your program.

The parameters are values sent to the filter program. These parameters are totally independent of the SET command. They are determined only by the needs of your filter program.

Example

Suppose you write a filter program named TRAP/FLT to change some characters sent to *DO, the video display.

First, you need to load your TRAP/FLT program and set it to a phantom device (this example uses *LC as the name of the phantom device):

```
SET *LC TO TRAP/FLT
```

This causes *LC to point to TRAP/FLT.

Then, you need to use *LC (which points to the TRAP/FLT program) to filter the data output to the video display:

```
FILTER *DO *LC (ENTER)
```

Now, all data output to the video display is filtered through your filter program.

```
SET *DU KSM/FLT USING FILEDAT/KSM (ENTER)  
FILTER *KI *DU (ENTER)
```

loads the Keystroke Multiply filter into memory and sets it to the keyboard.

SETCOM

<div>Advanced Programmer's Command</div> <div>SETCOM [(parameters)]</div>

Adjusts the parameter values of the RS-232C driver program COM/DVR. Before you can use SETCOM, you have to install the driver using the SET command (see Appendix I).

You can use SETCOM to adjust your computer so that it can communicate with another computer or a piece of computer equipment.

The RS-232C port lets you communicate with:

- another computer
- a modem
- a serial printer

The *parameters* configure the RS-232C port, and establish line conditions.

The *parameters* are:

DEFAULT returns all parameters to their start-up values.
BAUD = *number* sets the BAUD rate to any supportable rate.
number can be 110, 135, 150, 300, 600, 1200, 2400, 4800, 9600. The default value for BAUD is 300.
WORD = *number* sets the word length to *number*. *number* can be 5, 6, 7, or 8. The default value for *number* is 7.
STOP = *number* sets the *number* of stop bits per word.
number is either 1 or 2. The default value for *number* is 1.
PARITY = *switch* sets the parity switch to either YES or NO. If you specify YES, you can also use EVEN or ODD. The default values for PARITY are YES and EVEN.
QUERY prompts you for each parameter.
BREAK = *value* sets the logical BREAK to *value*. The default value for BREAK is hexadecimal 03 ((CONTROL C)).
EVEN sets parity to even, if parity switch is YES.
ODD sets parity to odd, if parity switch is YES.

BREAK cannot be abbreviated.

Examples

SETCOM (ENTER)

displays the current configuration of the RS-232C port in the following format:

RS232 parameters:

Baud = 300
Word Length = 7
Stop Bits = 1
Parity = ON
Even = ON
Break value = X'03'

Output control line status:

DTR=ON
RTS=OFF

Input control line conditions observed:

RI = IGNORE
DSR = IGNORE
CD = IGNORE
CTS = IGNORE

SETCOM (BAUD=300,WORD=8,STOP=1,PARITY=NO) (ENTER)

configures the RS-232C using the values specified. Notice that PARITY is specified as NO.

Technical Information

This command allows you to set the parameters to values that match any other RS-232C devices. The receiving side of the driver is interrupt driven and contains an internal one-character buffer to prevent loss of characters during disk I/O and other lengthy operations. The system usually uses the *CL devspec to communicate with the RS-232C port.

If you are using a serial printer, (1) use SET to set *CL to COM/DVR (see Appendix I), (2) use SETCOM to set the proper parameters, and (3) use the command:

ROUTE *PR TO *CL (ENTER)

to direct output to the RS-232C (rather than the standard parallel port). Radio Shack printers do not require this procedure since they use the parallel printer port.

The line condition parameters let you set up the conventions required by most communicating devices.

The RS-232C line output *parameters* are:

DTR=*switch* Data Terminal Ready
RTS=*switch* Request To Send

The RS-232C line input *parameters* are:

DSR = *switch* Data Set Ready
CD = *switch* Carrier Detect
CTS = *switch* Clear To Send
RI = *switch* Ring Indicator

switch is either YES or NO. You cannot abbreviate any of the RS-232C line parameters.

As specified by standard RS-232C conventions, a TRUE condition means a logical 0, or positive voltage. A FALSE condition means a logical 1, or negative voltage.

DTR and RTS can be set to a constant TRUE by specifying the YES switch. If DSR, CD, CTS, or RI is specified YES, the driver observes that signal and waits for a TRUE condition before sending each character. If specified NO, the driver waits for a false condition before sending a character. If not specified, that signal is ignored.

The BREAK parameter allows you to set a logical BREAK character.

This is useful in "host" type applications. The BREAK parameter causes the serial driver to set the system break bit whenever a modem break (extended null) or an ASCII logical BREAK is received. The system pause bit is set whenever the hex code 60 is received. The system enter bit is set whenever a carriage return (0D) is received.

The default for BREAK is 3, so a **CONTROL C** sets the break bit. Use BREAK = *value* to set another character as the logical break.

Technical Examples

```
SETCOM (BREAK) ENTER
```

configures the RS-232C port to the default values. Specifying BREAK with no value assigns the default value of 3 as the logical break value.

```
SETCOM (CTS) ENTER
```

configures the RS-232C port to the default values. Because CTS is specified, the driver looks at the CTS line for a TRUE condition before it sends a character.

Sample Use

Suppose you want to log-on to CompuServe. First, you have to SET *CL to COM/DVR, and then you have to use SETCOM to set the parameters of the RS-232C port so that your Model 4 can communicate with CompuServe. See the Logging-On to CompuServe section in the COMM utility description.

SETKI [(parameters)]	Advanced Programmer's Command
-----------------------------	--------------------------------------

Sets keyboard repeat *parameters*. If you do not specify a *parameter*, the current delay and repeat rate settings are displayed.

You can use SETKI to adjust how your keyboard reacts when you press a key.

The parameters are:

DEFAULT returns the parameters to their start-up values.

RATE = *number* sets the repeat rate as *number*. *number* is any number greater than or equal to 1. *number* equals 2 when the system is started or reset.

WAIT = *number* sets the initial delay between the time a key is first pressed and the first repeat of that key as *number*. *number* is any number greater than or equal to 10. *number* equals 22 when the system is started or reset.

QUERY prompts you to enter new values for RATE = *number* and WAIT = *number*.

Examples

```
SETKI (WAIT=15) ENTER
```

sets the delay rate to 15.

```
SETKI ENTER
```

displays the current delay and repeat rate settings in the format:

Wait = 15, Rate = 2

Note: Both the RATE and WAIT parameters use modulo 128. For example, entering 138 has the same effect as entering 10.

SPOOL

SPOOL [<i>devspec</i>] [TO] [<i>filespec</i>] (<i>parameters</i>)	Command
--	----------------

establishes a First-In, First-Out buffer for a specified device (usually a line printer).

You can use SPOOL to print data while you perform other operations on your computer (such as create a BASIC program). However, you can not spool using BANK 1 or 2 when a BASIC program is running.

If you do not specify *devspec*, it defaults to *PR.

The *parameters* are:

NO turns off the spooler and resets *devspec*.

MEM=*number* specifies *number* as the amount of memory buffer (in K) to be used by the spooler. The value of *number* is 1 - 32.

BANK=*number* selects one of three 32K banks of memory to be used as the spool buffer. *number* can be a 0, 1, or 2. The default value of *number* is 0.

DISK=*number* specifies *number* as the amount of disk space (in K) to be used by the spooler. The value of *number* cannot be larger than the amount of available space (in K) on the disk.

PAUSE temporarily suspends output to *devspec*.

RESUME restarts *devspec* after a PAUSE.

CLEAR clears the spool buffer.

How Data Is Spooled To a Device

All data sent to *devspec*, such as a printer, is placed in an output buffer where it waits until the device is again available to accept the data.

There are two kinds of output buffers: memory and disk. You can set up a spooler with both types of buffers. Or, you can set up a spooler with a memory buffer only.

The minimum space allocation for the memory buffer depends on which BANK you select. If you specify BANK 0, a minimum of 1K (1024 bytes) is allocated for the memory buffer. If you specify BANK = 1 or BANK = 2, the entire 32K bank is automatically used for the memory buffer.

If you specify both buffers, data is sent first to the memory buffer. When the memory buffer is full, the data is sent to a disk buffer named *filespec*, where it waits to be sent to the device. If you specify a memory buffer only, data is sent to a memory buffer until the device is ready to accept it.

When you specify *filespec*, you may also use the DISK parameter to specify the amount of disk space to be used by the spooler. TRSDOS creates a file of the size specified. If you do not specify DISK=, approximately 5K of disk space is automatically allocated to *filespec*.

To prevent TRSDOS from allocating any disk space to SPOOL, specify DISK=0.

filespec remains open as long as SPOOL is on. Do not REMOVE this file or remove the disk from the drive without closing the file (by issuing a SPOOL *devspec* (NO) command).

You cannot issue a SYSGEN library command if the spooler is on.

Once the spooler is turned off, you can turn it on again. The same memory locations are used, but the following restrictions apply:

- The original parameters are not affected by turning *devspec* off and then on.
- Any parameter specified the second time cannot exceed the memory or disk parameters originally given. If they do, an error occurs.

Examples

```
SPOOL *PR TO TEXTFILE:0 (MEM=5,DISK=15) (ENTER)
```

allocates 5K of memory and 15K of disk space in a file named TEXTFILE/SPL on Drive 0. Since you did not specify an extension to TEXTFILE, it defaulted to /SPL.

Any output for the printer is buffered and sent to the line printer (*PR) as fast as the printer can accept the characters. If the 5K memory buffer is filled, the data is written to the disk file TEXTFILE/SPL on Drive 0.

```
SPOOL *PR (BANK=1,DISK=0) (ENTER)
```

creates a 32K memory buffer for data sent to *PR. Any output for the printer is sent to the memory buffer and then spooled to *PR when it is available to accept the data. Since the parameter DISK= is specified without any size, none of the spooled data is sent to a disk file.

If the memory buffer is filled, TRSDOS does not process any more printer data until *PR has printed enough data to bring the number of characters waiting to be printed below 32K (the size of the memory buffer).

```
SPOOL (CLEAR) (ENTER)
```

clears the information in the spool buffer.

```
SPOOL *PR (NO) (ENTER)
```

turns off the spooler and closes the associated disk file. Any filtering, linking, setting, or routing done to *PR is reset.

You cannot close the disk file by issuing a RESET or REMOVE library command. SPOOL must be turned off to close the file.

Sample Use

Since most programs produce reports faster than the printer can print the data, you can use SPOOL to let the programs run at top speed without having to stop and wait on the printer. That is, while the first program's report is still printing, you can begin executing the second program.

Advanced Programmer's Command

SYSGEN [(*switch*) [,] [DRIVE = *drive*]]

creates a configuration file on *drive* to store information about your system.

You can use SYSGEN to create a file of current device and driver configurations that you want TRSDOS to execute each time you return your computer to the TRSDOS copyright and start-up message.

If you do not specify *drive*, it defaults to Drive 0.

The *switch* is either YES or NO.

If you specify *switch* as YES, then your system creates a configuration file. If you don't specify *switch*, then YES is assumed.

If you specify *switch* as NO, then your system removes the configuration file. However, your system's current configuration does not change until you reset your computer.

When you issue a SYSGEN command, all current device and driver configurations are stored in a file named CONFIG/SYS. The file is invisible in the directory.

Each time you reset your computer, the configuration stored in this file is loaded into memory. If you don't want this configuration loaded into memory, hold down the **CLEAR** key when you reset the system (see the BOOT command).

When you start up or reset your computer, it is configured before any AUTO command executes.

The configuration file CONFIG/SYS contains:

- All active background tasks (such as CLOCK, DEBUG, TRACE, etc.).
- All filtering, linking, routing, and device setting (including RS-232C and KI settings).
- All programs that were loaded into high memory above HIGH\$. All memory from HIGH\$ to the top of memory is written to CONFIG/SYS. HIGH\$ can be set with the MEMORY command or with the @HIGH\$ supervisor call (see the Technical Reference Manual).
- The present state of the VERIFY library command (YES or NO).
- All Device Control Blocks (see the Technical Reference Manual for more information).

-
- The present state of the CAPS lock for the keyboard.

Any ROUTE or SET involving a file should never be SYSGENed. SYSGENing open files can result in lost data if the disks are switched in the drives without the files being closed. Switching a disk with open files can also cause existing data to be overwritten.

Examples

SYSGEN (YES) **ENTER**

creates a configuration file on Drive 0 and writes the system configuration to it.

SYSGEN (NO) **ENTER**

removes the configuration file from Drive 0.

Sample Use

Suppose you want to create a file of commands that automatically execute each time you startup TRSDOS.

Issue the commands:

TIME (CLOCK=YES) **ENTER**
SYSTEM (TRACE=YES) **ENTER**
SYSGEN (YES) **ENTER**

to create a CONFIG/SYS file that contains CLOCK and TRACE information.

SYSTEM

Advanced Programmer's Command SYSTEM (<i>parameters</i>)

configures certain areas of your TRSDOS system.

You can use SYSTEM to determine some of the commands that are put in the file that SYSGEN creates.

You can see the current configuration of your TRSDOS system by issuing a DEVICE or a MEMORY command.

Using the SYSTEM command, you can set or change the disk drive configuration and turn on or off different keyboard, video, and hardware drivers.

When you configure your system, you can store the configuration on the disk in Drive 0 with the SYSGEN library command.

Certain SYSTEM commands load driver routines into high memory. Be aware that your overall free memory decreases accordingly when you use driver routines.

SYSTEM Commands

```
SYSTEM (ALIVE[=switch]) (ENTER)
```

displays an "alive" character in the upper right corner of the screen.

If the alive bug is moving, the task processor is running. Note that the alive bug may continue moving (indicating an alive system) even when the SYSTEM (TRACE) library command display has stopped.

If the alive bug is not moving, then the system is "hung up." Also, the bug stops during FORMAT operations and disk I/O.

The *switch* is either YES or NO. If you do not specify *switch*, YES is assumed. The ALIVE parameter uses some RAM in high memory.

```
SYSTEM (BLINK=switch) (ENTER)
SYSTEM (BLINK=number) (ENTER)
SYSTEM (BLINK,parameter) (ENTER)
```

controls the TRSDOS cursor character.

switch is either YES or NO. Specifying YES turns the blinking cursor ON. Specifying NO turns the blinking of the cursor OFF.

number is an ASCII value in decimal. For example, if you specify SYSTEM (BLINK=42), the blinking cursor character is an asterisk (character 42).

The *parameters* are:

LARGE turns on a large blinking cursor.
SMALL turns on a small blinking cursor.

Specifying SYSTEM (BLINK) returns the cursor to its start-up character and size.

SYSTEM (BREAK [= *switch*]) (ENTER)

enables or disables the (BREAK) key.

The *switch* is either YES or NO. If you do not specify *switch*, YES is assumed.

Once the (BREAK) key is disabled by issuing a SYSTEM (BREAK = NO) COMMAND, pressing it has no effect.

You can re-enable it at any time by issuing a SYSTEM (BREAK = YES) command. This command also enables the (BREAK) key if it was disabled by the AUTO library command.

If you switch Drive 0 disks or change the logical Drive 0 with the SYSTEM (SYSTEM) command, the default value you select for BSTEP is taken off the new Drive 0 disk.

SYSTEM (DATE [= *switch*]) (ENTER)

enables or disables the prompt for the date when you power up your system.

The *switch* is either YES or NO.

If you specify the *switch* as YES, the system enables the date prompt if it has been disabled with the NO switch. If you do not specify *switch*, YES is assumed.

If you specify the *switch* as NO, the date prompt is disabled when you power up or restart your system.

Since the date is used extensively throughout the TRSDOS system, we recommend that you never disable the initial date prompt.

SYSTEM (DRIVE = *drive*, [*parameters*]) (ENTER)

sets certain parameters for the disk drives in your system.

drive is any valid drive number in your system.

The *parameters* are:

CYL = *number* sets the default number of cylinders that is used with the FORMAT utility. *number* is in the range of 35 to 96.

DELAY = NO/YES sets the DELAY time for floppy disks. DELAY time is the time allowed between the drive motor start-up and the first attempted read of the diskette in that drive. If you specify DELAY = NO, the DELAY time is set to .5 seconds (the standard DELAY time). If you specify DELAY = YES, the DELAY time is set to 1 second.

DISABLE removes access to the specified drive.

ENABLE allows access to a drive that has been disabled.

Error Conditions

CYL is written to the system information sector on Drive 0. If you switch the disk in Drive 0, these values are taken from the new disk in Drive 0 if you format a disk.

If you try to access a disk after you have DISABLEd it, the error "Illegal drive number" appears.

If you ENABLE a drive that is not available on your system or that is not set up with the SYSTEM (DRIVE = ,DRIVER) command, unpredictable results follow.

```
SYSTEM (DRIVE=drive,DRIVER="filespec") (ENTER)
```

To access the disk drives, TRSDOS uses information stored in memory in the Drive Code Table (DCT). Since these drives are preset in your system, no special configuration should have to be done. This command is used for Radio Shack hard disk installation.

```
SYSTEM (DRIVE=drive,WP[=switch]) (ENTER)
```

sets the software Write Protect status for the disk in *drive*.

The *switch* is either YES or NO. If you do not specify either one, YES is assumed.

If you specify WP = YES, you cannot write to the disk, although you can still read from it. If you specify WP = NO, you can write to and read from the disk (assuming the disk is not hardware write protected).

If you do not specify *drive*, the *switch* that you specify applies to all drives enabled in your system.

If there is a write-protect tab on a disk, specifying WP = NO does not allow you to write to the disk.

```
SYSTEM (RESTORE [=switch]) (ENTER)
```

determines whether all drives are to be restored when the system is reset. Drives are restored by moving the drive heads to track 0.

If you specify RESTORE = YES, the drives are restored on reset. If you do not specify *switch*, YES is assumed. If you specify RESTORE = NO, the drives are not restored on reset.

```
SYSTEM (SYSRES=number) (ENTER)
```

adds TRSDOS system "overlays" into high memory. You can load SYS files 1, 2, 3, 4, 5, 9, 10, 11, and 12 with this command.

Adding certain of these SYS overlays to memory speeds up most disk I/O, because these overlays do not have to be loaded from disk every time they are needed. This also allows you to purge these overlays from your system disk using the PURGE library command, providing more room for data and programs.

SYS0 and SYS2 must remain on any booting disk if a configuration file created with the SYSGEN library command is loaded.

To see which overlays are currently resident in high memory, issue a DEVICE library command.

You can add only one system overlay to high memory in a command line.

```
SYSTEM (SYSTEM=drive) (ENTER)
```

assigns a drive other than Drive 0 as your system drive.

drive is any drive currently enabled in your system. There must be a system disk in *drive* when you issue the command. If *drive* is not ready, the message "Insert SYSTEM diskette in drive x!" appears. Insert a system diskette in the indicated drive, or press (BREAK) to abort the command and return to TRSDOS Ready.

Every time you issue this command, the logical drive numbers of the drives change. You can repeat this command as many times as you wish, but be careful not to lose track of which drive is assigned to which logical drive number.

```
SYSTEM (TIME[=switch]) (ENTER)
```

turns on or off the start-up time prompt.

The *switch* is either YES or NO.

If you specify TIME=YES, you enable the start-up time prompt. If you do not specify *switch*, YES is assumed. If you specify TIME=NO, you disable the start-up time prompt.

When you issue this command, you must not have a write-protected disk in Drive 0.

```
SYSTEM (TRACE[=switch]) (ENTER)
```

displays the contents of the Program Counter (PC) in the upper right corner of the video display. The display is a hexadecimal address and is constantly updated as a "low priority background task" (see the explanation of the @ADTSK supervisor call in the Technical Reference Manual).

The *switch* is either YES or NO.

Use the TRACE command to help you debug assembly language programs.

```
SYSTEM (TYPE[=switch]) (ENTER)
```

turns on or off the task processing of the keyboard type-ahead feature. Type-ahead is active when you startup your computer.

The *switch* is either YES or NO.

You can restart the type-ahead task processing with the SYSTEM (TYPE=YES) command.

TAPE100

(Model 4 only)

TAPE100 [<i>file</i>] [(<i>parameters</i>)] TAPE100 [<i>file1</i>] [TO] [<i>file2</i>] [(<i>parameters</i>)]	Utility
---	----------------

Lets TRSDOS (1) read a cassette tape file and write it to a disk file, or (2) read a disk file and write it to a cassette tape.

You can use TAPE100 to read files from cassette tape as well as from Model 4 disks.

The cassette tape must have been made with the Model 100 computer.

file, *file1*, and *file2* are each either a TRSDOS filespec or a Model 100 filename.

A Model 100 filename is 1 - 6 alphanumeric characters long and it must begin with a letter. For example, ACCT61, LETTER, and ABFILE can be Model 100 filenames.

If you do not specify *file* or *file1* and *file2*, you will be prompted to enter the source and destination filespecs if the operation is a WRITE, or just the destination filespec if the operation is a READ.

The *parameters* are:

READ specifies that you want to read a file (*file* or *file1*) from tape and write it to a file (*file* or *file2*) on disk. If you specify READ, you do not have to specify *file1*. TRSDOS simply reads the first text file it sees on the tape.

WRITE specifies that you want to read a disk file (*file* or *file1*) and write it to a tape as *file* or *file2*.

If you do not specify the READ or WRITE parameter, you will be prompted for it.

Examples

```
TAPE100 PRNTER TO PRINT/DAT:0 (READ) (ENTER)
```

TRSDOS reads the Model 100 file PRNTER and writes it to the disk in Drive 0 as PRINT/DAT.

```
TAPE100 ACCTING/TXT:1 (READ) (ENTER)
```

TRSDOS reads the first text file it finds on a Model 100 tape and writes it to the disk in Drive 1 as ACCTING/TXT.

```
TAPE100 WEST/DAT:0 TO WESTRN (WRITE) (ENTER)
```

TRSDOS reads the Drive 0 disk file WEST/DAT and writes it to a file on a Model 100 tape named WESTRN.

Error Conditions

Any file (disk or tape) must fit in available memory or the error message "File too large to fit in available memory" appears.

TIME

TIME [<i>hh:mm:ss</i>] [<i>(parameter)</i>]	Command
--	----------------

You can use TIME to see the current time. You can also use it to reset the time.

If you specify *hh:mm:ss*, TRSDOS resets the time. If you do not specify it, TRSDOS displays the current time.

The parameter is:

CLOCK=YES/NO turns the clock display on or off. YES is the default.

The real time clock turns off while TRSDOS does some of its disk I/O functions, such as BACKUP and FORMAT, so do not depend on the clock for constantly accurate time and date information.

You can enable and disable the prompt for time on power-up or reset with the SYSTEM (TIME =) command.

Examples

TIME (ENTER)

displays the real time of the system. The clock is reset to 00:00:00 every time you power up.

TIME (CLOCK=YES) (ENTER)

displays the real time clock in the upper right corner of the screen. Note: CLOCK will print over whatever TRSDOS attempts to print at the location occupied by the clock display.

TIME 12:29:34 (ENTER)

sets the clock to 12:29:34 p.m. The latest acceptable time is 23:59:59, as the clock runs in the 24-hour mode. When the clock reaches 23:59:59, the date is automatically updated.

The time lag between pressing (ENTER) and the time set on the clock is approximately 2 seconds. So, when setting the clock with the correct time, remember to adjust for the 2-second time lag.

VERIFY

VERIFY [(switch)]

Command

Controls the verify function.

You can use VERIFY to assure you that data was properly written to a disk.

When VERIFY is on, TRSDOS reads the data it writes to the disk to verify that the data is readable.

The *switch* is either ON or OFF.

A TRSDOS floppy disk system starts up with VERIFY off. A hard disk system starts up with VERIFY on.

Although having the VERIFY switch turned on provides a reliability check during disk I/O, it also increases overall processing time when you write to a disk file. You must determine if the increase in reliability warrants the increase in processing time.

All disk writes are automatically verified during any BACKUP utility function, whether or not the VERIFY switch is on.

The state of the VERIFY command can be saved in the configuration file with the SYSGEN library command. (You can check the present status of VERIFY using the DEVICE command.)

Examples

VERIFY (ON) **(ENTER)**

turns on the verify function.

VERIFY (OFF) **(ENTER)**

turns off the verify function.

VERIFY **(ENTER)**

turns on the verify function.

Sample Use

Suppose you are writing a tax file named TAX/TXT to disk and it is extremely important that the information in the file be correct.

Using VERIFY causes TRSDOS to produce an informative message when data written to TAX/TXT is written incorrectly. An informative message could indicate that the disk needs to be replaced or the drives need to be cleaned.

**Part II/ BASIC For TRSDOS Version 6 Reference
Manual**

Introduction

This part of the manual is about the BASIC language. BASIC for TRSDOS Version 6 is an “interpreter.” When you run a program, it executes each statement one at a time. This makes it quick and easy to use. It also allows you to take advantage of many of TRSDOS Version 6’s features, such as:

- Faster running programs
- Better graphics capabilities
- More print positions on the screen

About this Manual

This is a reference manual, not a tutorial. We assume you already know BASIC and are using this manual to quickly find the information you need.

Section III — Operations. This section shows how to load BASIC. It also demonstrates how to write, run and save a BASIC program on disk.

Section IV — The BASIC Language. This section includes a definition for each of BASIC’s keywords (statements and functions) in alphabetical order. In addition, it shows how to write a program to store data on disk.

IMPORTANT NOTE: If you have read “Getting Started with TRS-80 BASIC”, you need to know the differences between TRSDOS Version 1 and TRSDOS Version 6 BASIC. Appendix E shows these differences. These differences will often prevent a BASIC program written for TRSDOS Version 1 from running under TRSDOS Version 6, unless the program is modified. You also need to know how to use “disk files.” This is explained in Chapter 5.

Notations

CAPITALS	material which must be entered exactly as it appears.
<i>italics</i>	words, letters, characters or values you must supply from a set of acceptable entries.
. . . (ellipsis)	items preceding the ellipsis may be repeated.
X’NNNN’	NNNN is a hexadecimal number.
O’NNNNN’	NNNNN is an octal number.
KEYNAME	one of the keys from your keyboard.

b	a blank space character (ASCII code 32). For example, in
	BASICbbPROG
	there are two spaces between BASIC and PROG.

Terms

buffer	a number between 1 and 15. This refers to an area in memory that BASIC uses to create and access a disk file. Once you use a buffer to create a file, you cannot use it to create or access any other files; you must first close the file. You may only access an open file with the buffer used to open it.
[parameters]	information you supply to specify how a command is to operate. Parameters enclosed in brackets are optional.
[expressions]	values you supply for a function to evaluate. Expressions enclosed in brackets are optional.
syntax	a command with its parameter(s), or a function with its argument(s). This shows the format to use for entering a keyword in a program line.

Terms Used in Chapter 7 for Brevity:

line	a numeric value that identifies a BASIC program line. Each line has a number between 0 and 65529.
integer	any integer expression. It may consist of an integer, or several integers joined by operators. Integers are whole numbers between -32768 and 32767.
string	any string expression. It may consist of a string, or several strings joined by operators. A string is a sequence of characters which is to be taken verbatim.
number	any numeric expression. It may consist of a number, or several numbers joined by operators.
dummy number or dummy string	a number (or string) used as a parameter to meet syntactic requirements, but whose value is insignificant.

Part II is organized this way:

Section III. Operations

Chapter 1. Sample Session

Chapter 2. Command Mode
Execution Mode

Chapter 3. Line Edit Mode

Section IV. The BASIC Language

Chapter 4. BASIC Concepts

Chapter 5. Disk Files

Chapter 6. Introduction to BASIC Statements and Functions

Chapter 7. BASIC Statements and Functions

Section III/ Operations

Chapter 1/ Sample Session

The easiest way to learn how BASIC operates is to write and run a program. This chapter provides sample statements and instructions to help familiarize you with the way BASIC works.

The main steps in running a program are:

- A) Loading BASIC
- B) Typing the program
- C) Editing the program
- D) Running the program
- E) Saving the program on disk
- F) Loading the program back into memory

Loading BASIC

After you power up your system and install the diskette, the TRSDOS Version 6 start-up logo is displayed. Then, the following prompt appears: Date?

To answer this prompt, type today's date in this format: DD/MM/YY; then press **(ENTER)**. For example, for December 1, 1983, type:

12/01/83 **(ENTER)**

The computer converts these numbers to: Thu, Dec 1, 1983 and displays the message "TRSDOS Ready". This indicates that you are at the Operating System level. To load BASIC into the system, type:

BASIC **(ENTER)**

A paragraph with copyright information appears on your screen, followed by: Ready

You may now begin using BASIC.

Options for Loading BASIC

When loading BASIC, you can also specify a set of options. They are:

BASIC [program] ([F = number of files] [,M = highest memory location])

Program specifies a program to run immediately after BASIC is started.

F = specifies the maximum number of data files that may be open at any one time (from 0-15). If you omit this option, the number of files defaults to three. Each file you specify uses 564 bytes of memory.

M = specifies the highest memory location for BASIC to use. Omit this option unless you are going to call assembly-language subroutines. (In that case, you may want to set the amount of memory well below the high-memory modules of TRSDOS.) If you

omit this option, the system allocates all memory up to the HIGH\$ marker to BASIC. HIGH\$ can be adjusted through the MEMORY library command. See the TRSDOS Reference Manual for more details.

Examples

```
TRSDOS Ready  
BASIC PAYROLL (F=5) (ENTER)
```

initializes BASIC, then loads and runs the program PAYROLL; allows five data files to be open; uses all memory available.

```
TRSDOS Ready  
BASIC (M=45056) (ENTER)
```

initializes BASIC; allows three data files to be open; sets the highest memory location to be used by BASIC at 45056.

```
TRSDOS Ready  
BASIC (M=32768, F=6) (ENTER)
```

initializes BASIC; sets the highest memory location at 32768; allows six data files to be open. Notice that the sequence in which the M= and F= options are specified is irrelevant.

```
TRSDOS Ready  
BASIC
```

initializes BASIC; allows three data files to be open; uses all memory available.

Typing the Program

Let's write a small BASIC program. Before pressing (ENTER) after each line, check the spelling. If you have made any mistakes, use the (←) key to correct them.

```
10 A$="WILLIAM SHAKESPEARE WROTE" (ENTER)  
15 B$="THE MERCHANT OF VENICE" (ENTER)  
20 PRINT A$; B$ (ENTER)
```

Check your spelling again. If it is still not perfect, enter the line number where you made the mistake. Then type the entire line again.

For example, suppose you had typed:

```
15 B$="THE VERCHANT OF VENICE"
```

To correct line 15, re-type it:

```
15 B$="THE MERCHANT OF VENICE" (ENTER)
```

Then type:

```
RUN (ENTER)
```

Your screen should display:

```
WILLIAM SHAKESPEARE WROTE THE MERCHANT OF  
VENICE
```

BASIC replaced line 15 in the original program with the most recent line 15.

NOTE: BASIC "reads" your program lines in numerical order. It doesn't matter if you entered line 15 after line 20; it will still read and execute 15 before "looking" at 20.

BASIC has a powerful set of commands which allow you to correct mistakes without having to re-type the entire line. These commands are discussed in Chapter 3, the "Line Edit Mode."

Saving the Program on Disk

You can save any of your BASIC programs on disk. To do this, you assign it a "filespec".

For example, if you wanted to save the program we just wrote, you could assign it the filespec "AUTHOR". Type the following command:

```
SAVE "AUTHOR" (ENTER)
```

It takes a few seconds for the computer to find a place on disk to store our program. When this process is completed, it displays Ready. The program is now saved on disk.

IMPORTANT NOTE: A filespec can have a maximum of eight alphanumeric characters. It can also have an optional extension, up to three characters long. A slash / must be included between the filespec and the extension. The first character of both the filespec and the extension must be a letter.

Example

```
SAVE "AUTHOR/WIL" (ENTER)
```

You may also add a drive number to your filespec by typing a colon : and the drive number.

Example

```
SAVE "AUTHOR:1" (ENTER)
```

tells the computer to save "AUTHOR" on the disk in Drive 1. Otherwise, the computer assumes you to save it on the first available drive. If you do specify a disk drive, make sure you have a disk in that drive.

Loading the Program

If, after writing or running other programs, you wanted to go back and use this program again, you must "load" it back into memory. To do this, type: LOAD "filespec", R

Example

```
LOAD "AUTHOR", R ENTER
```

tells the computer to load the program "AUTHOR" from disk into memory; option R tells the computer to run it.

Another way to load and run a program is to type: RUN "filespec". RUN automatically loads and runs the program specified by "filespec".

The SAVE, LOAD and RUN commands are discussed in more detail in Chapter 7.

Chapter 2/ Command And Execution Modes

This chapter describes BASIC's command and execution modes. The command mode is for typing in program lines and immediate lines. The execution mode is for executing programs and immediate lines.

Command Mode

Whenever you enter the command mode, BASIC displays the prompt:

```
Ready
```

In the command mode, BASIC does not “read” your input until you complete a “logical line” by pressing **ENTER**. This is called “line input”, as opposed to “character input”.

A logical line is a string of up to 255 characters and is always terminated by pressing **ENTER**. Of these 255 characters, 249 are reserved for the line itself; the other six are reserved for the line number and the space following the line number.

A physical line, on the other hand, is one line on the display. It contains a maximum of 80 characters.

For example, if you type 100 R's and then press **ENTER**, you have two physical lines, but only one logical line.

Interpretation of a Line

BASIC always ignores leading spaces in the line — it jumps ahead to the first non-space character. If this character is not a digit, BASIC treats the line as an immediate line. If it is a digit, BASIC treats the line as a program line.

For example, if you type:

```
PRINT "THE TIME IS" TIME$ ENTER
```

BASIC takes this as an immediate line.

But if you type:

```
10 PRINT "THE TIME IS" TIME$ ENTER
```

BASIC takes this as a program line.

Immediate Lines

An immediate line consists of one or more statements separated by colons. The line is executed as soon as you press **ENTER**. For example:

```
Ready  
CLS: PRINT "THE SQUARE ROOT OF 2 IS" SQR(2)
```

is an immediate line. When you press **ENTER**, BASIC executes it.

Program Lines

A program line consists of a line number in the range 0 to 65529, followed by one or more statements separated by colons. When you press **(ENTER)**, the line is stored in memory, along with any other lines you have entered this way. The program is not executed until you type RUN or another execute command. For example:

```
100 CLS: PRINT "THE SQUARE ROOT OF 2 IS"  
SQR(2)
```

is a program line. When you press **(ENTER)**, BASIC stores it in memory. To execute it, type:

```
RUN (ENTER)
```

NOTE: If you include numeric constants in a line, BASIC evaluates them as soon as you press **(ENTER)**; it does not wait until you RUN the program. If any numbers are out of range for their type, BASIC returns an error message immediately after pressing **(ENTER)**.

Special Keys in the Command Mode

(←)
or **(CTRL) (H)**

Backspaces the cursor, erasing the preceding character in the line. Use this to correct typing errors before pressing **(ENTER)**.

(SPACE BAR)

Enters a blank space character and advances the cursor.

(BREAK)

Interrupts line entry and starts over with a new line.

(CTRL) (J)
or **(↓)**

Line feed — starts a new physical line without ending the current logical line.

(CAPS)

Switches the display to either all uppercase or uppercase/lowercase mode.

(ENTER)

Ends the current logical line. BASIC “takes” the line.

(SHIFT) (←)

Deletes the current line.

Execution Mode

When BASIC is executing statements (immediate lines or programs), it is in the execution mode. In this mode, the contents of the video display are under program control.

Special Keys in the Execution Mode

(SHIFT) (@)

Pauses execution. Press any other key (except **(BREAK)**) to continue.

BREAK

Terminates execution and returns you to command mode.

ENTER

Interprets data entered from the keyboard as a response to the INPUT statement.

Chapter 3/ Line Edit Mode

This mode enables you to “debug” (correct) programs quickly and efficiently. It allows you to correct a program line without having to re-type the entire line.

If your computer encounters a syntax error while executing a program, it automatically puts you in the “line edit mode.” The display shows:

```
Syntax error in line number
Ready
line number
```

(line number is the program line in which the error occurred.) In this case, you are ready to use the edit mode commands and subcommands described later in this Chapter.

However, if you wish to activate the line editor yourself (because you have noticed a mistake or wish to make a change in a long program line), type:

```
EDIT line number (ENTER)
```

This lets you edit the specified line number. (If the line number you specify has not been used, an “Undefined line number” error occurs. If you do not have a space after the word EDIT, a “Syntax error” occurs.)

You may also type:

```
EDIT , (ENTER)
```

The period after EDIT means that you want to edit the current program line, the last line entered, the last line altered, or a line in which an error has occurred. Notice that you need to type a blank before the period; otherwise, BASIC gives you a “Syntax error” message.

For example, type the following line and press **(ENTER)**. (To type the exponent sign ^, press **(CLEAR)** **(:)**).

```
100 FOR I = 1 TO 10 STEP .5: PRINT I, I^2, I^3:
NEXT
```

This line will be used in exercising all the edit subcommands described below.

Now type EDIT 100 and press **(ENTER)**. The computer displays:

```
100
```

This starts the editor. You may now begin editing line 100.

Special Keys in the Edit Mode

ENTER

Pressing **ENTER** in the edit mode records all the changes you made in the current line and returns you to the command mode.

Space bar

Pressing the space bar moves the cursor over one space to the right and displays any character stored in the preceding position. For example, using line 100 entered above, put the computer in the edit mode so the display shows:

```
100
```

Now press the space bar. The cursor moves over one space and the first character of the program line is displayed. If this character was a blank, then a blank is displayed. Press the space bar again until you reach the first non-blank character:

```
100 F
```

is displayed. To move over more than one space at a time, type the desired number of spaces first, then press the space bar. For example, type 6 and press the space bar. The display should show something like this (depending on how many blanks you inserted in the line):

```
100 FOR I =
```

Now type 8 and press the space bar. The cursor moves over eight spaces to the right, and eight more characters are displayed.

```
100 FOR I = 1 TO 10
```

L (List Line)

displays the remainder of the program line (unless the computer is under one of the insert subcommands listed below). The cursor drops down to the next line of the display, reprints the current line number, and moves to the first position of the line.

For example, when the display shows

```
100
```

press L (without pressing **ENTER**). Line 100 is displayed:

```
100 FOR I = 1 TO 10 STEP .5: PRINT I, I^2, I^3:
    NEXT 100
```

This lets you look at the line in its current form while you're doing the editing.

Insert Subcommand Mode

The insert subcommand mode allows you to add material to a line while editing it. The three keys you can use to enter this subcommand mode are X, I and H.

X (Extend Line)

Displays the rest of the current line. Typing **X** also moves the cursor to the end of the line and puts the computer in the insert subcommand mode. This enables you to add material to the end of the line.

For example, using line 100, when the display shows

```
100
```

press **X** (without pressing **ENTER**) and the entire line is displayed; notice that the cursor now follows the last character on the line:

```
100 FOR I = 1 TO 10 STEP .5: PRINT I, I^2,  
      I^3: NEXT
```

We can now add another statement to the line, or delete material from the line by using the **←** key. For example, type

```
: PRINT "DONE"  
ENTER
```

at the end of the line. If you typed:

```
LIST 100
```

the display should show something like this:

```
100 FOR I = 1 TO 10 STEP .5: PRINT I, I^2,  
      I^3: NEXT: PRINT "DONE"
```

NOTE: If you want to continue editing the line, press **SHIFT** **↑** to get out of the insert subcommand mode.

I (Insert)

Inserts material beginning at the current cursor position on the line.

For example, type

```
EDIT 100  
ENTER
```

then use the space bar to move over to the decimal point in line 100. The display shows:

```
100 FOR I = 1 TO 10 STEP ,
```

Suppose you want to change the increment from .5 to .25. Press the **I** key (don't press **ENTER**). The computer lets you insert material at

the current position. Type 2 now, and the display shows:

```
100 FOR I = 1 TO 10 STEP .2
```

You have made the necessary change, so press **(SHIFT)(↑)** to escape from the insert subcommand. Now press **(L)** to display the remainder of the line and move the cursor back to the beginning of the line:

```
100 FOR I = 1 TO 10 STEP .25: PRINT I, I^2,  
    I^3: NEXT: PRINT "DONE"  
100
```

NOTE: You can also exit the insert subcommand and save all changes by pressing **(ENTER)**. This returns you to command mode.

H (Hack and Insert)

Deletes the remainder of a line and lets you insert material at the current cursor position.

For example, using line 100, enter the edit mode and space over until just before the PRINT "DONE" statement. Suppose you wanted to delete this statement and insert an END statement. The display shows:

```
100 FOR I = 1 TO 10 STEP .25: PRINT I, I^2,  
    I^3: NEXT:
```

Press **(H)**, then type END and press **(ENTER)**. List the line:

```
100 FOR I = 1 TO 10 STEP .25: PRINT I, I^2,  
    I^3: NEXT: END
```

should be displayed.

NOTE: To continue editing the line, press **(SHIFT)(↑)** to get out of the insert subcommand mode.

A (Cancel and Restart)

Moves the cursor back to the beginning of the program line and cancels editing changes already made.

For example, if you have added, deleted, or changed something in a line, and you wish to go back to the beginning of the line and cancel the changes already made: first press **(SHIFT)(↑)** (to escape from any subcommand you may be executing); then press **(A)**. The cursor drops down to the next line, displays the line number and moves to the first character position.

E (Save Changes and Exit)

Ends editing and saves all changes made. You must be in edit mode, not executing any subcommand, when you press **(E)** to end editing.

Q (Cancel and Exit)

Ends editing and cancels all changes made in the current editing session. If you've decided not to change the line, type **Q** to cancel changes and leave the edit mode.

If a syntax error is detected during program execution, BASIC starts the editor. To examine variable values, you must press Q before typing any other command.

nD (Delete)

Deletes the specified number n of characters to the right of the cursor. The deleted characters appear enclosed in exclamation points.

For example, using line 100, space over to just before the PRINT statement:

```
100 FOR I = 1 TO 10 STEP .25:
```

Now type 19D. This tells the computer to delete 19 characters to the right of the cursor. The display should show something like this:

```
100 FOR I = 1 TO 10 STEP .25: \PRINT I, I^2,  
I^3:\
```

When you list the complete line, you will see that everything from the PRINT to the next statement has been deleted.

nC (Change)

Lets you change the specified number of characters beginning at the current cursor position. If you type C without a preceding number, the computer assumes you want to change one character. When you have entered n number of characters, the computer returns you to the edit mode (so you're not in the nC subcommand).

For example, using line 100, suppose you want to change the final value of the FOR NEXT loop, from "10" to "15". In the edit mode, space over to just before the "0" in "10".

```
100 FOR I = 1 TO 1
```

Now press **C**. The computer assumes you want to change just one character. Press **5**, then press **L**. When you list the line, you will see that the change has been made.

```
100 FOR I = 1 TO 15 STEP .25: NEXT: END
```

would be the current line if you've followed the editing sequence in this chapter.

nSc (Search)

Searches for the nth occurrence of the character c, and moves the cursor to that position. If you don't specify a value for n, the computer searches for the first occurrence of the specified character. If character c is not found, cursor goes to the end of the line.

NOTE: The computer only searches through characters to the right of the cursor.

For example, using the current form of line 100 type EDIT 100 (ENTER), then press (2)(S)(:). This tells the computer to search for the second occurrence of the colon character. The display should show:

```
100 FOR I = 1 TO 15 STEP .25: NEXT
```

You may now execute one of the subcommands beginning at the current cursor position. For example, suppose you want to add the counter variable after the NEXT statement. Type I to enter the insert subcommand, then type the variable name, I. That's all you want to insert, so press (SHIFT)(^) to escape from the insert subcommand mode. The next time you list the line, it should appear as:

```
100 FOR I = 1 TO 15 STEP .25: NEXT I: END
```

nKc (Search and "Kill")

Deletes all characters up to the nth occurrence of character c, and moves the cursor to that position.

For example, using the current version of line 100, suppose we wanted to delete the entire line up to the END statement. Type EDIT 100 (ENTER), then type (2)(K)(:). This tells the computer to delete all characters up to the 2nd occurrence of the colon.

```
100 \FOR I = 1 TO 15 STEP .25: NEXT I\
```

should be displayed. The second colon still needs to be deleted, so type D. The display now shows:

```
100 \FOR I = 1 TO 15 STEP .25: NEXT I\\:
```

Press (ENTER) and type LIST 100 (ENTER)

Line 100 should look something like this:

```
100 END
```

n (←)

Moves the cursor to the left by n spaces. If no number n is given, the cursor moves back one space. When the cursor backspaces, all characters in its path are erased from the display, but they are not deleted from the program. Use the space bar to advance the cursor forward and re-display the erased characters.

Section IV/ The BASIC Language

Chapter 4/ BASIC Concepts

This chapter explains how to use the full power of BASIC for TRSDOS Version 6. This information can help programmers build powerful and efficient programs. If you are still something of a novice, you might want to skip this chapter for now, keeping in mind that the information is here when you need it.

The chapter is divided into four sections:

A. Overview — Elements of a Program. This section defines many of the terms we will be using in the chapter.

B. How BASIC Handles Data. Here we discuss how BASIC classifies and stores data. This shows you how to get BASIC to store your data in its most efficient format.

C. How BASIC Manipulates Data. This gives you an overview of all the different operators and functions you can use to manipulate and test your data.

D. How to Construct an Expression. This topic can help you in constructing powerful statements instead of using many short ones.

A- Overview: Elements of a Program

This overview defines the elements of a program.

A program is made up of “statements”; statements may have several “expressions.”

We will refer to these terms during the rest of this chapter.

Program

A program is made up of one or more numbered lines. Each line contains one or more BASIC statements. BASIC allows line numbers from 0 to 65529 inclusive. You may include up to 255 characters per line, including the line number. You may also have two or more statements to a line, separated by colons.

* You can type a maximum of 249 characters per line. BASIC reserves the remaining six characters for the line number and for the space following the line number.

Here is a sample program:

Line number	BASIC statement	Colon between statements	BASIC statement
100	CLS: PRINT "NORMAL MODE..."		
110	PRINT "ABCDEFGHIJKLMNOPQRSTUVWXYZ"		
120	FOR I = 1 TO 1000: NEXT I		
130	CLS: PRINT CHR\$(23); "DOUBLE-SIZE MODE..."		
140	PRINT "ABCDEFGHIJKLMNOPQRSTUVWXYZ"		
150	END		

When BASIC executes a program, it handles the statements one at a time, starting with the first and proceeding to the last. Some statements, such as GOTO, ON . . . GOTO, GOSUB, change this sequence.

Statements

A statement is a complex instruction to BASIC, telling the computer to perform specific operations. For example:

```
GOTO 100
```

tells the computer to perform the operations of (1) locating line 100, (2) transferring control to that line and (3) executing the statement(s) on that line.

```
END
```

tells the computer to perform the operation of ending execution of the program.

Many statements instruct the computer to perform operations with data. For example, in the statement:

```
PRINT "SEPTEMBER REPORT"
```

the data is SEPTEMBER REPORT. The statement instructs the computer to print the data inside quotes.

Expressions

An expression is actually a general term for data. There are four types of expressions:

1. Numeric expressions, which are composed of numeric data.

Examples:

```
(1 + 5.2)/3
D
5*B
3.7682
ABS(X) + RND(0)
SIN(3 + E)
```

2. String expressions, which are composed of character data.

Examples:

```
A$  
"STRING"  
"STRING" + "DATA"  
M0$ + "DATA"  
MID$(A$,2,5) + MID$("MAN",1,2)  
M$ + A$ + B$
```

3. Relational expressions, which test the relationship between two expressions.

Examples:

```
A=1  
A$>B$
```

4. Logical expressions, which test the logical relationship between two expressions.

Examples:

```
A$="YES" AND B$="NO"  
C>5 OR M<B OR 0>-2  
578 AND 452
```

Functions

Functions are automatic subroutines. Most BASIC functions perform computations on data. Some serve a special purpose, such as controlling the video display or providing data on the status of the computer. You may use functions in the same manner that you use any data: as part of a statement.

These are some of BASIC's functions:

```
INT  
ABS  
STRING$
```

For example, ABS returns the absolute value of a numeric expression. The following example shows how this function works:

```
PRINT ABS(7*(-5)) (ENTER)  
35  
READY
```

B- How BASIC Handles Data

BASIC for TRSDOS Version 6 offers several different methods of handling your data. Using these methods properly can greatly improve the efficiency of your program. In this section we discuss:

Ways of Representing Data

- Constants
- Variables
- How BASIC Stores Data
 - Numeric (integer, single precision, double precision)
 - String
- How BASIC Classifies Constants
- How BASIC Classifies Variables
- How BASIC Converts Data

Ways of Representing Data

BASIC recognizes data in two forms: directly (as constants), or by reference to a memory location (as variables).

Constants

All data is input into a program as “constants” — values which are not subject to change. For example, the statement:

```
PRINT "1 PLUS 1 EQUALS"; 2
```

contains one string constant (1 PLUS 1 EQUALS), and one numeric constant (2).

In these examples, the constants “input” to the PRINT statement. They tell PRINT what data to print on the display.

These are more examples of constants:

3.14159	"L.O.SMITH"
1.775E+3	"0123456789ABCDEF"
"NAME TITLE"	- 123.45E - 8
57	"AGE"

Variables

A variable is a place in memory where data is stored. Unlike a constant, a variable's value can change. This allows you to write programs dealing with changing quantities. For example, in the statement:

```
A$ = "OCCUPATION"
```

The variable A\$ now contains the data OCCUPATION. However, if this statement appeared later in the program:

```
A$ = "FINANCE"
```

The variable A\$ would no longer contain OCCUPATION. It would now contain the data FINANCE.

Variables can also store numeric values. For example:

```
A = 134
```

Variable Names

In BASIC, variables are represented by names. Variable names must begin with a letter, A through Z. This letter may be followed by one or more characters (digits or letters).

For example:

AM A A1 BALANCE EMPLOYEE2

are all valid and distinct variable names.

Variable names may be up to 40 characters long. All characters are significant in BASIC.

Reserved Words

Certain combinations of letters are reserved as BASIC keywords and operator names. These combinations cannot be used as variable names. For example:

OR LEN OPTION

cannot be used as variable names. However, they may be embedded in a variable name. For example, OPTIONS is a valid variable name.

TRSDOS Version 6 requires that all reserved words be delimited. This means that you must leave a blank space between a reserved word and any variables, constants or other reserved words. See Appendix F for a list of BASIC's reserved words.

Simple and Subscripted Variables

Variables may also be "subscripted" so that an entire list of data can be stored under one variable name. This method of data storage is called an *array*. For example, an array named A may contain these elements (subscripted variables):

A(0) A(1) A(2) A(3) A(4)

You may use each of these elements to store a separate data item, such as:

A(0) = 5.3
A(1) = 7.2
A(2) = 8.3
A(3) = 6.8
A(4) = 3.7

In this example, array A is a one-dimensional array, since each element contains only one subscript. An array may also be two-dimensional, with each element containing two subscripts. For example, a two-dimensional array named X could contain these elements:

$X(0,0) = 8.6$ $X(0,1) = 3.5$
 $X(1,0) = 7.3$ $X(1,1) = 32.6$

With BASIC, you may have as many dimensions in your array as your program space allows. Here is an example of a three-dimensional array named L which contains these eight elements:

$L(0,0,0) = 35233$ $L(0,1,0) = 96522$
 $L(0,0,1) = 52000$ $L(0,1,1) = 10255$
 $L(1,0,0) = 33333$ $L(1,1,0) = 96253$
 $L(1,0,1) = 53853$ $L(1,1,1) = 79654$

BASIC assumes that all arrays contain 11 elements in each dimension. If you want more elements you must use the DIM statement at the beginning of your program to dimension the array.

For example, to dimension array L, put this line at the beginning of the program:

```
DIM L(1,1,1)
```

to allow room for two elements in the first dimension; two in the second, and two in the third for a total of $2 * 2 * 2 = 8$ elements.

How BASIC Stores Data

The way BASIC stores data determines the amount of memory it consumes and the speed in which BASIC can process it.

Numeric Data

You may get BASIC to store all numbers in your program as either integer, single precision, or double precision. In deciding how to get BASIC to store your numeric data, remember the tradeoffs. Integers are the most efficient and the least precise. Double precision is the most precise and least efficient.

Integers

(Fastest in Computations, Limited in Range)

To be stored as an integer, a number must be whole and in the range of -32768 to 32767 . An integer value requires two bytes of memory for storage. Arithmetic operations are faster when both operands are integers.

For example:

1 3200 -2 500 -12345

can all be stored as integers.

Single Precision (General Purpose, Full Numeric Range)

Single-precision numbers can include up to seven significant digits, and can represent normalized values* with exponents up to 38, i.e., numbers in the range:

$$[-1 \times 10^{38}, -1 \times 10^{-38}] [1 \times 10^{38}, 1 \times 10^{-38}]$$

If a number is raised to a power greater than 38, an "Overflow" error occurs. If it is raised to a power lower than -38 , no errors are generated and program execution continues.

A single-precision value requires four bytes of memory for storage. BASIC assumes a number is single precision if you do not specify the level of precision.

* In this manual, normalized value is one in which exactly one digit appears to the left of the decimal point. For example, 12.3 expressed in normalized form is 1.23×10 .

For example:

10.001 -200034 1.774E6 6.024E-23 123.4567

can all be stored as single-precision values. But even though BASIC stores a number with up to seven digits of precision, when printing it, only six digits are shown.

NOTE: When used in a decimal number, the symbol E stands for "single-precision times 10 to the power of . . ." Therefore 6.024E-23 represents the single-precision value:

$$6.024 \times 10^{-23}$$

Double Precision (Maximum Precision, Slowest in Computations)

Double-precision numbers can include up to 16 significant digits, and can represent values in the same range as that for single-precision numbers. A double-precision value requires eight bytes of memory for storage. Arithmetic operations involving at least one double-precision number are slower than the same operations when all operands are single precision or integer.

For example:

1010234578
-8.7777651010
3.141592653589793
8.00100708D12

can all be stored as double-precision values.

NOTE: When used in a decimal number, the symbol D stands for "double precision times 10 to the power of . . ." Therefore

8.00100708D12 represents the value

$$8.00100708 \times 10^{12}$$

Strings

Strings (sequences of characters) are useful for storing non-numeric information such as names, addresses, or text. You may store ASCII characters, as well as any of the graphic and non-ASCII symbols, in a string. (A list of Character Codes is included in Appendix C).

For example, the data constant:

Jack Brown, Age 38

can be stored as a string of 18 characters. Each character (and blank) in the string is stored as an ASCII code, requiring one byte of storage.

BASIC would store the above string constant internally as:

Hex Code	4A	61	63	6B	20	42	72	6F	77	6E	2C	20	41	67	65	20	33	38
ASCII Character	J	a	c	k		B	r	o	w	n	,		A	g	e		3	8

A string can be up to 255 characters long. Strings with length zero are called "null" or "empty".

How BASIC Classifies Constants

When BASIC encounters a data constant in a statement, it must determine the type of the constant: string, integer, single precision, or double precision. First, we will list the rules BASIC uses to classify the constant. Then we will show you how you can override these rules, if you want a constant stored differently:

Rule 1

If the value is enclosed in double-quotes, it is a string.

For example:

"YES"
"3331 Waverly Way"
"1234567890"

are all classified as strings.

Rule 2

If the value is not in quotes, it is a number. (An exception to this rule is during data input by an operator, and in DATA lists. See INPUT, INKEY\$, and DATA)

For example:

123001
1
- 7.3214E + 6

are all numeric data.

Rule 3

Whole numbers in the range of - 32768 to 32767 are integers.

For example:

12350
- 12
10012

are integer constants.

NOTE: If you enter a number as a constant in response to a command that calls for an integer, and the number is out of integer range, BASIC converts the number to single or double precision. When the number is printed, it appears with a type-declaration tag at the end.

Rule 4

If the number is not an integer and contains seven or fewer digits, it is single precision.

For example:

1234567
- 1.23
1.3321

are all classified as single precision.

Rule 5

If the number contains more than seven digits, it is double precision.

For example, these numbers:

1234567890123456
- 10000000000000.1
2.777000321

are all classified as double precision.

Type Declaration Tags

You can override BASIC's normal typing criteria by adding the following "tags" at the end of the numeric constant:

! Makes the number single precision. For example, in the statement:

A = 12.345678901234!

BASIC classifies the constant as single precision, and shortens it to seven digits. However, if you tell BASIC to print the value of A, only six digits are printed out:

12.3457

- E Single-precision exponential format. The E indicates that the constant is to be multiplied by a specific power of 10. For example:

A = 1.2E5

stores the single-precision number 120000 in A.

- # Makes the number double precision. For example, in statement:

PRINT 3#/7

BASIC classifies the first constant as double precision before the division takes place.

- D Double-precision exponential format. The D indicates the constant is to be multiplied by a specified power of 10. For example, in:

A = 1.23456789D - 1

the double-precision constant has the value 0.123456789.

How BASIC Classifies Variables

When BASIC encounters a variable name in the program, it classifies it as either a string, an integer, a single-precision number, or a double-precision number.

BASIC classifies all variable names as single-precision initially. For example:

AB AMOUNT XY L

are all single precision initially. If this is the first line of your program:

LP = 1.2

BASIC classifies LP as a single-precision variable.

However, you may assign different attributes to variables by using definition statements at the beginning of your program:

DEFINT - Defines variables as integer
DEFDBL - Defines variables as double-precision
DEFSTR - Defines variables as string
DEFSNG - Defines variables as single-precision. (Since BASIC classifies all variables as single precision initially)

anyway, you would only need to use DEFSNG if one of the other DEF statements was used).

For example:

```
DEFSTR L
```

makes BASIC classify all variables which start with L as string variables. After this statement, the variables:

```
L      LP      LAST
```

can all hold string values only.

Type Declaration Tags

As with constants, you can always override the type of a variable name by adding a type declaration tag at the end. The four types of declaration tags for variables are:

```
% Integer
! Single precision
# Double precision
$ String
```

For example:

```
I%      FT%      NUM%      COUNTER%
```

are all integer variables, **regardless** of what attributes have been assigned to the letters I, F, N, and C.

```
T!      RY!      QUAN!      PERCENT!
```

are all single-precision variables, **regardless** of what attributes have been assigned to the letters T, R, Q, and P.

```
X#      RR#      PREV#      LSTNUM#
```

are all double-precision variables, **regardless** of what attributes have been assigned to the letters X, R, P, and L.

```
Q$      CA$      WRD$      ENTRY$
```

are all string variables, **regardless** of what attributes have been assigned to the letters Q, C, W, and E.

Note that any given variable name can represent four different variables. For example:

```
A5#      A5!      A5%      A5$
```

are all valid and **distinct** variable names.

One further implication of type declaration: Any variable name used without a tag is equivalent to the same variable name used with one of the four tags. For example, after the statement:

DEFSTR C

the variable referenced by the name C1 is identical to the variable referenced by the name C1\$.

How BASIC Converts Numeric Data

Often your program might ask BASIC to assign one type of constant to a different type of variable. For example:

A% = 2.34

In this example, BASIC must first convert the single-precision constant 2.34 to an integer in order to assign it to the integer variable A%.

You might also want to convert one type of variable to a different type, such as:

A# = A%

A! = A#

A! = A%

The conversion procedures are explained on the following pages.

Single or double precision to integer type

BASIC rounds the fractional portion of the number.

NOTE: The original value must be greater than or equal to -32768, and less than 32768.

Examples

A% = 32766.7

assigns A% the value 32767.

A% = 2.503

assigns A% the value 2500.

A% = -123.45678901234578

assigns A% the value -123.

A% = -32768.5

produces an Overflow Error (out of integer range).

Integer to single or double precision

No error is introduced. The converted value looks like the original value with zeros to the right of the decimal place.

Examples

A# = 32767

Stores 32767.000000000000 in A#.

A! = -1234

Stores -1234.000 in A!.

Double to single precision

This involves converting a number with up to 16 significant digits into a number with no more than seven digits. BASIC rounds the number to seven significant digits. Before printing it, BASIC rounds it off to six digits.

Examples

A! = 1.234567890124567

stores 1.234568 in A!. However, the statement:

PRINT A

displays the value 1.23457, because only six digits are displayed. The full seven digits are stored in memory.

A! = 1.3333333333333333

stores 1.333333 in A!.

Single to double precision

To make this conversion, BASIC simply adds trailing zeros to the single-precision number. If the original value has an exact binary representation in single-precision format, no error is introduced. For example:

A# = 1.5

stores 1.5000000000000000 in A#, since 1.5 does have an exact binary representation.

However, for numbers which have no exact binary representation, an error is introduced when zeros are added. For example:

A# = 1.3

stores 1.299999952316284 in A#.

Because most fractional numbers do not have an exact binary representation, you should keep such conversions out of your programs. For example, whenever you assign a constant value to a double-precision variable, you can force the constant to be double precision:

A# = 1.3# A# = 1.3D

both store 1.3 in A#.

Here is a special technique for converting a single precision value to double precision, without introducing an error into the double-precision

value. It is useful when the single-precision value is stored in a variable.

Take the single-precision variable, convert it to a string with STR\$, then convert the resultant string back into a number with VAL. That is, use:

VAL(STR\$(single-precision variable))

For example, the following program:

```
10 A! = 1.3
20 A# = A!
30 PRINT A#
```

prints a value of:

1.299999952316284

Compare with this program:

```
10 A! = 1.3
20 A# = VAL(STR$(A!))
30 PRINT A#
```

which prints a value of:

1.3

The conversion in line 20 causes the value in A! to be stored accurately in double-precision variable A#.

Illegal Conversions

BASIC cannot automatically convert numeric values to string, or vice versa. For example, the statements:

```
A$ = 1234
A% = "1234"
```

are illegal. They would return a "Type mismatch" error. (Use STR\$ and VAL to accomplish such conversions.)

C- How BASIC Manipulates Data

You have many fast methods you may use to get BASIC to count, sort, test, and rearrange your data. These methods fall into two categories:

1. Operators
 - a. numeric
 - b. string
 - c. relational
 - d. logical
2. Functions

Operators

An operator is the single symbol or word which signifies some action to be taken on either one or two specified values referred to as operands.

In general, an operator is used like this:

operand-1	operator	operand-2
6	+	2

The addition operator + connects or relates its two operands, 6 and 2, to produce the result 8.

Operand-1 and -2 can be expressions.

A few operations take only one operand, and are used like this:

operator	operand
-	5

The negative operator - acts on single operand 5 to produce the result negative 5.

Neither 6 + 2 nor - 5 can stand alone; they must be used in statements to be meaningful to BASIC. For example:

```
A = 6 + 2
PRINT -5
```

Operators fall into four categories:

- Numeric
- String
- Relational
- Logical

based on the kinds of operands they require and the results they produce.

Numeric Operators

Numeric Operators are used in numeric expressions. Their operands must always be numeric, and the results they produce is one numeric data item.

In the description below, we use the terms integer, single-precision, and double-precision operations. Integer operations involve two-byte operands, single-precision operations involve four-byte operands, and double-precision operations involve eight-byte operands. The more bytes involved, the slower the operation.

There are five different numeric operators. Two of them, sign + and sign -, are unary, that is, they have only one operand. A sign operator has no effect on the precision of its operand.

For example, in the statement:

```
PRINT -77, +77
```

the sign operators $-$ and $+$ produce the values negative 77 and positive 77, respectively.

NOTE: When no sign operator appears in front of a numeric term, $+$ is assumed.

The other numeric operators are all binary, that is, they all take two operands.

These operators are, in order of precedence:

$^$	Exponentiation
$*, /$	Multiplication, Division
$+, -$	Addition, Subtraction

Exponentiation

The symbol $^$ denotes exponentiation. It converts both its operands to single precision and returns a single-precision result.

NOTE: To enter the $^$ operator, press **CLEAR** $\left(\frac{\square}{\square}\right)$.

For example:

```
PRINT 6^ .3
```

prints 6 to the .3 power.

Multiplication

The $*$ operator is the symbol for multiplication. Once again, BASIC uses the precision of the more precise operand to perform the operation (the less precise operand is converted).

Examples:

```
PRINT 33 * 11%
```

integer multiplication is performed.

```
PRINT 33 * 11.1
```

single-precision multiplication is performed.

```
PRINT 12.345678901234567 * 11
```

double-precision multiplication is performed.

Division

The $/$ symbol is used to indicate ordinary division. Both operands are converted to single precision or double precision, depending on their original precision:

-
- If either operand is double precision, then both are converted to double precision and eight-byte division is performed.
 - If neither operand is double precision, then both are converted to single precision and four-byte division is performed.

Examples:

```
PRINT 3/4
```

single-precision division is performed.

```
PRINT 3.8/4
```

single-precision division is performed.

```
PRINT 3/1.2345678901234567
```

double-precision division is performed.

Addition

The + operator is the symbol for addition. The addition is done with the precision of the more precise operand (the less precise operand is converted).

For example, when one operand is integer type and the other is single precision, the integer is converted to single precision and four-byte addition is performed. When one operand is single precision and the other is double precision, the single-precision number is converted to double precision and eight-byte addition is performed.

Examples:

```
PRINT 2 + 3
```

integer addition is performed.

```
PRINT 3.1 + 3
```

single-precision addition is performed.

```
PRINT 1.2345678901234567 + 1
```

double-precision addition is performed.

Subtraction

The – operator is the symbol for subtraction. As with addition, the operation is done with the precision of the more precise operand (the less precise operand is converted).

Examples:

```
PRINT 33 - 11
```

integer subtraction is performed.

```
PRINT 33 - 11.1
```

single-precision subtraction is performed.

```
PRINT 12.345678901234567 - 11
```

double-precision subtraction is performed.

String Operator

BASIC has a string operator (+) which allows you to concatenate (link) two strings into one. This operator should be used as part of a string expression. The operands are both strings and the resulting value is one piece of string data.

The + operator links the string on the right of the sign to the string on the left. For example:

```
PRINT "CATS" + "LOVE" + "MICE"
```

prints:

```
CATSLOVEMICE
```

Since BASIC does not allow one string to be longer than 255 characters, you will get an error if your resulting string is too long.

Relational Operators

Relational operators compare two numerical or two string expressions to form a relational expression. This expression reports whether the comparison you set up in your program is true or false. It returns a -1 if the relation is true; a 0 if it is false.

Numeric Relations

This is the meaning of the operators when you use them to compare numeric expressions:

<	Less than
>	Greater than
=	Equal to
<> or ><	Not equal to
=< or <=	Less than or equal to
=> or >=	Greater than or equal to

Examples of true relational expressions:

```
1 < 2
2 <> 5
2 <= 5
2 <= 2
5 > 2
7 = 7
```

String Relations

The relational operators for string expressions are the same as above, although their meanings are slightly different. Instead of comparing numerical magnitudes, the operators compare their ASCII sequence. This allows you to sort string data:

<	Precedes
>	Follows
> < or < >	Does not have the same precedence
< =	Precedes or has the same precedence
> =	Follows or has the same precedence

BASIC compares the string expressions on a character-by-character basis. When it finds a non-matching character, it checks to see which character has the lower ASCII code. The character with the lower ASCII code is the smaller (precedent) of the two strings.

NOTE: Appendix C contains a listing of ASCII codes for each character.

Examples of true relational expressions:

"A" < "B"

The ASCII code for A is decimal 65; for B it's 66.

"CODE" < "COOL"

The ASCII code for O is 79; for D it's 68.

If while making the comparison, BASIC reaches the end of one string before finding non-matching characters, the shorter string is the precedent. For example:

"TRAIL" < "TRAILER"

Leading and trailing blanks are significant. For example:

" A" < "A"

ASCII for the space character is 32; for A, it's 65.

"Z-80" < "Z-80A"

The string on the left is four characters long; the string on the right is five.

How to Use Relational Expressions

Normally, relational expressions are used as the test in an IF/THEN statement. For example:

```
IF A = 1 THEN PRINT "CORRECT"
```

BASIC tests to see if A is equal to 1. If it is, BASIC prints the message.

```
IF A$ < B$ THEN 50
```

if string A\$ alphabetically precedes string B\$, then the program branches to line 50.

```
IF R$ = "YES" THEN PRINT A$
```

if R\$ equals YES then the message stored as A\$ is printed.

However, you may also use relational expressions simply to return the true or false results of a test. For example:

```
PRINT 7 = 7
```

prints - 1 since the relation tested is true.

```
PRINT "A" > "B"
```

prints 0 because the relation tested is false.

Logical Operators

Logical operators make logical comparisons. Normally, they are used in IF/THEN statements to make a logical test between two or more relations. For example:

```
IF A = 1 OR C = 2 THEN PRINT X
```

The logical operator, OR, compares the two relations A = 1 and C = 2.

Logical operators may also be used to make bit comparisons of two numeric expressions.

For this application, BASIC does a bit-by-bit comparison of the two operands, according to predefined rules for the specific operator.

NOTE: The operands are converted to integer type, stored internally as 16-bit, two's complement numbers. To understand the results of bit-by-bit comparisons, you need to keep this in mind.

The following table summarizes the action of Boolean operators in bit manipulation.

Operator	Meaning of Operation	First Operand	Second Operand	Result
AND	When both bits are 1, the results will be 1. Otherwise, the result will be 0.	1	1	1
		1	0	0
		0	1	0
		0	0	0
OR	Result will be 1 unless both bits are 0.	1	1	1
		1	0	1
		0	1	1
		0	0	0
NOT	Result is opposite of bit.	1		0
		0		1
XOR	When one of the bits is 1, the result is 1. Otherwise, the result is 0.	1	1	0
		1	0	1
		0	1	1
		0	0	0
EQV	When both bits are 1 or both bits are 0, the result is 1.	1	1	1
		1	0	0
		0	1	0
		0	0	1
IMP	The result is 1 unless the first bit is 1 and the second bit is 0.	1	1	1
		1	0	0
		0	1	1
		0	0	1

Hierarchy of Operators

When your expressions have multiple operators, BASIC performs the operations according to a well-defined hierarchy so that results are always predictable.

Parentheses

When a complex expression includes parentheses, BASIC always evaluates the expressions inside the parentheses before evaluating the rest of the expression. For example, the expression:

$$8 - (3 - 2)$$

is evaluated like this:

$$\begin{aligned} 3 - 2 &= 1 \\ 8 - 1 &= 7 \end{aligned}$$

With nested parentheses, BASIC starts evaluating the innermost level first and works outward. For example:

$$4 * (2 - (3 - 4))$$

is evaluated like this:

$$\begin{aligned} 3 - 4 &= -1 \\ 2 - (-1) &= 3 \\ 4 * 3 &= 12 \end{aligned}$$

Order of Operations

When evaluating a sequence of operations on the same level of parentheses, BASIC uses a hierarchy to determine what operation to do first.

The two listings below show the hierarchy BASIC uses. Operators are shown in decreasing order of precedence and are executed as encountered **from left to right**:

For Numeric Operations:

() (Parentheses)
^ (Exponentiation)
+, - (Unary sign operands [**not** addition and subtraction])
*, / (Multiplication and division)
+, - (Addition and subtraction)
<, >, =, <=, >=, <>
NOT
AND
OR
XOR
EQV
IMP

For String Operations:

+
<, >, =, <=, >=, <>

For example, in the line:

$$X * X + 5 ^ 2.8$$

BASIC finds the value of 5 to the 2.8 power. Next it multiplies X*X, and finally it adds the value of 5 to the 2.8. If you want BASIC to perform the indicated operations in a different order, you must add parentheses. For example:

$$X * (X + 5) ^ 2.8$$

or

$$X * X + (5 ^ 2.8)$$

Here's another example:

```
IF X = 0 OR Y > 0 AND Z = 1 THEN GOTO 255
```

The relational operators = and > have the highest precedence, so BASIC performs them first, one after the next, from left to right. Then the logical operations are performed. AND has a higher precedence than OR, so BASIC performs the AND operation before OR.

If the above line looks confusing because you can't remember which operator is precedent over which, then you can use parentheses to make the sequence obvious:

```
IF X = 0 OR ((Y > 0) AND (Z = 1)) THEN GOTO 255
```

Functions

A function is a built-in sequence of operations which BASIC performs on data. BASIC functions save you from having to write a BASIC routine, and they operate faster than a BASIC routine would.

Examples:

```
SQR (A + 6)
```

tells BASIC to compute the square root of (A + 6).

```
MID$ (A$,3,2)
```

tells BASIC to return a substring of the string A\$, starting with the third character, with a length of 2.

BASIC functions are described in more detail in Chapter 7.

If the function returns numeric data, it is a numeric function and may be used in a numeric expression. If it returns string data, it is a string function and may be used in a string expression.

D- How to Construct an Expression

Understanding how to construct an expression will help you put together powerful statements — instead of using many short ones. In this section we will discuss the two kinds of expressions you may construct:

- Simple
- Complex

as well as how to construct a function.

As we have stated before, an expression is actually data. This is because once BASIC performs all the operations, it returns one data item. An expression may be string or numeric. It may be composed of:

- Constants
- Variables
- Operators
- Functions

Expressions may be either simple or complex:

A **simple expression** consists of a single term: a constant, variable or function. If it is a numeric term, it may be preceded by an optional + or - sign, or by the logical operator NOT.

For example:


+A 3.3 -5 SQR(8)

are all simple numeric expressions, since they only consist of one numeric term.

A\$ STRING\$(20,A\$) "WORD" "M"

are all simple string expressions, since they only consist of one string term.

Here's how a **simple expression** is formed:



A **complex expression** consists of two or more terms (simple expressions) combined by operators. For example:


A-1 X+3.2-Y 1=1 A AND B ABS(B)+LOG(2)

are all examples of complex numeric expressions. (Notice that you can use the relational expression (1=1) and the logical expression (A AND B) as a complex numeric expression since both actually return numeric data.)


A\$ + B\$ "Z" + Z\$ STRING\$(10, "A") + "M"

are all examples of complex string expressions.

This is how a **complex numeric expression** is formed:




This is how a **complex string expression** is formed:



Most functions, except functions returning system information, require that you input either or both of the following kinds of data:

- One or more numeric expressions
- One or more string expressions

This is how a **function** is formed:



If the data returned is a number, the function may be used as a term in a numeric expression. If the data is a string, the function may be used as a term in a string expression.

SIN(A) STR\$(X) VAL(A) LOG(.53)

are all examples of functions.

Chapter 5/ Disk Files

You may want to store data on your disk for future use. To do this, you need to store the data in a "disk file." A disk file is an organized collection of related data. It may contain a mailing list, a personnel record, or almost any kind of information. This is the largest block of information on disk that you can address with a single command.

To transfer data from a BASIC program to a disk file, and vice-versa, the data must first go through a "buffer". This is an area in memory where data is accumulated for further processing.

With BASIC, you can create and access two types of disk files. The difference between these two types is that each is created in a different "mode." The mode you choose determines what kind of access you will have to the file: sequential access or direct access.

Sequential-Access Files

With a sequential-access file, you can only access data in the same order it was stored: sequentially. To read from or write to a particular section in the file, you must first read through all the contents in the file until you get to the desired section.

Data is stored in a sequential file as ASCII characters. Therefore, it is ideal for storing free-form data without wasting space between data items. However, it is limited in flexibility and speed.

The statements and functions used with sequential files are:

OPEN	WRITE#	EOF
PRINT#	INPUT#	LOC
PRINT# USING	LINE INPUT#	CLOSE

These statements and functions are discussed in more detail in Chapters 6 and 7.

Creating a Sequential-Access File

1. To create the file, OPEN it in "O" (output) mode and assign it a buffer number (from 1 to 15).

Example

```
OPEN "O", 1, "LIST/EMP"
```

opens a sequential output file named LIST/EMP and gives buffer 1 access to this file.

2. To input data from the keyboard into one or more program variables, use either INPUT or LINE INPUT. (The difference between these two statements is that each recognizes a different set of "delimiters". Delimiters are characters that define where a data item begins or ends).

Example

```
LINE INPUT, "NAME? "; N$
```

inputs data from the keyboard and stores it in variable N\$.

3. To write data to the file, use the WRITE# statement (you can also use PRINT#, but make sure you delimit the data).

Example

```
WRITE# 1, N$
```

writes variable N\$ to the file, using buffer 1 (the buffer used to OPEN the file). Remember that data must go through a buffer before it can be written to a file.

4. To ensure that all the data was written to the file, use the CLOSE statement.

Example

```
CLOSE 1
```

closes access to the file, using buffer 1 (the same buffer used to OPEN the file).

Sample Program

```
10 OPEN "O", 1, "LIST/EMP"  
20 LINE INPUT "NAME? ";N$  
30 IF N$ = "DONE" THEN G0  
40 WRITE# 1, N$  
50 PRINT: GOTO 20  
60 CLOSE 1  
RUN
```

NOTE: The file "LIST/EMP" stores the data you input through the aid of the program, not the program itself (the program manipulates data). To save the program above, you must assign it a name using the SAVE command (refer to Chapter 1).

Example

```
SAVE "PAYROLL"
```

would save the program under the name "PAYROLL".

NOTE: Every time you modify a program, you must SAVE it again (you can use the same name); otherwise, the original program remains on disk, without your latest corrections.

5. To access data in the file, reOPEN it in the "I" (input) mode.

Example

```
OPEN "I", 1, "LIST/EMP"
```

OPENS the file named LIST/EMP for sequential input, using buffer 1.

6. To read data from the file and assign it to program variables, use either INPUT# or LINE INPUT#.

Examples

```
INPUT# 1, N$
```

reads a string item into N\$, using buffer 1 (the buffer used when the file was OPENed).

```
LINE INPUT# 1, N$
```

reads an entire line of data into N\$, using buffer 1.

INPUT# and LINE INPUT# each recognize a different set of "delimiters" for reading data from the file. Delimiters are characters that define the beginning or end of a data item. See Chapter 7 for a detailed explanation of these statements.

Sample Program

```
10 OPEN "I", 1, "LIST/EMP"  
20 IF EOF(1), THEN 100  
30 INPUT# 1, N$  
40 PRINT N$  
50 GOTO 20  
100 CLOSE
```

Updating a Sequential-Access File

1. To add data to the file, OPEN it in "E" (extend) mode.

```
OPEN "E", 1, "LIST/EMP"
```

opens the file LIST/EMP so that it can be extended. The data you enter is appended to LIST/EMP.

2. To enter new data to the file, follow the same procedure as for entering data in "O" mode.

The following program illustrates this technique. It builds Upon the file we previously created under the name LIST/EMP.

NOTE: Read through the entire program first. If you encounter BASIC words (commands or functions) that are unfamiliar to you, refer to Chapter 7 for their definitions.

```
NEW  
10 OPEN "E", 1, "LIST/EMP"  
20 LINE INPUT "TYPE A NEW NAME OR PRESS <N>"; N$  
30 IF N$ = "N" THEN 60  
40 WRITE# 1, N$  
50 GOTO 20  
60 CLOSE
```

If you want the program to print on your display the information stored in the updated file, add the following lines:

```
70 OPEN "I", 1, "LIST/EMP"
80 IF EOF(1) THEN 2000
90 INPUT# 1, N$
100 PRINT N$
110 GOTO 80
2000 CLOSE
RUN
```

Once you have RUN this program, SAVE it.

Example

```
SAVE "PAYROLL2"          'saves the new program
```

Direct-Access Files

With a direct-access file, you can access data almost anywhere on disk. It is not necessary to read through all the information, as with a sequential-access file. This is possible because in a direct-access file, information is stored and accessed in distinct units called "records". Each record is numbered.

Creating and accessing direct-access files requires more program steps than sequential-access files. However, direct-access files are more flexible and easier to update.

One important note: BASIC allocates space for records in numeric order. That is, if the first record you write to the file is number 200, BASIC allocates space for records 0 through 199 before storing record 200 in the file.

The maximum number of logical records is 65,535. Each record may contain between 1 and 256 bytes.

The statements and functions used with direct-access files are:

OPEN	FIELD	LSET/RSET
GET	PUT	CLOSE
LOC	MKD\$	MKI\$
MKS\$	CVD	CVI
CVS		

These statements and functions are discussed in more detail in Chapters 6 and 7.

Creating a Direct-Access File

1. To create the file, OPEN it for direct access in "D" mode ("R" may also be used. It stands for "random access", which is simply another name for direct access).

Example

```
OPEN, "D", 1, "LISTING", 32
```

opens the file named "LISTING", gives buffer 1 direct access to the file, and sets the record length to 32 bytes. (If the record length is omitted, the default is 256 bytes). Remember that data is passed to and from disk in records.

2. Use the FIELD statement to allocate space in the buffer for the variables that will be written to the file. This is necessary because you must place the entire record into the buffer before putting it into the disk file.

Example

```
FIELD 1, 20 AS N$, 4 AS A$, 8 AS P$
```

allocates the first 20 positions in buffer 1 to string variable N\$, the next four positions to A\$, and the next eight positions to P\$. N\$, A\$ and P\$ are now "field names".

3. To move data into the buffer, use the LSET statement. Numeric values must be converted into strings when placed in the buffer. To do this, use the "make" functions: MKI\$ to make an integer value into a string, MKS\$ for a single-precision value, and MKD\$ for a double-precision value.

Example

```
LSET N$=X$  
LSET A$=MKS$(AMT)
```

Note: RSET right justifies a string into the buffer. For example, RSET N\$=X\$.

4. To write data from the buffer to a record (within a direct-access disk file), use the PUT statement.

```
PUT 1, CODE%
```

writes the data from buffer 1 to a record with the number CODE%. (The percentage sign at the end of a variable specifies that it is an integer variable.)

The following program writes information to a direct-access file:

```
10 OPEN "D", 1, "LISTING", 32  
20 FIELD 1, 20 AS N$, 4 AS A$, 8 AS P$  
30 INPUT "2-DIGIT CODE, 0 TO END"; CODE%  
40 IF CODE% = 0 THEN 130  
50 INPUT "NAME"; X$  
60 INPUT "AMOUNT"; AMT  
70 INPUT "PHONE"; TEL$  
80 LSET N$ = X$  
90 LSET A$ = MKS$(AMT)
```

```

100 LSET P$ = TEL$
110 PUT 1, CODE%
120 GOTO 30
130 CLOSE 1

```

The two-digit code that you enter in line 30 becomes a record number. That record number will store the name(s), amount(s) and phone number(s) you enter when lines 50, 60 and 70 are executed. The record is written to the file when BASIC executes the PUT statement in line 110.

After typing this program, SAVE it and RUN it. Then, enter the following data:

```

2-DIGIT CODE, 0 TO END? 20
NAME? SMITH
AMOUNT? 34.55
PHONE? 567-9000
2-DIGIT CODE, 0 TO END? 0

```

BASIC stored SMITH, 34.55, and 567-9000 in record 20 of file LISTING.

Accessing a Direct-Access File

1. OPEN the file in "D" mode ("R" can also be used).

Example

```
OPEN "D", 1, "FILE", 32
```

2. Use the FIELD statement to allocate space in the buffer for the variables that will be read from the file.

Example

```
FIELD 1, 20 AS N$, 4 AS A$, 8 AS P$
```

3. Use the GET statement to read the desired record from a direct disk file into a buffer.

Example

```
GET 1, CODE%
```

gets the record numbered CODE% and reads it into buffer 1.

4. Convert string values back to numbers using the "convert" functions: CVI for integers, CVS for single-precision values, and CVD for double-precision values.

Example

```
PRINT N$
PRINT CVS(A$)
```

The program may now access the data in the buffer.

The following program accesses the direct-access file "LISTING" (created with the previous program). When BASIC executes line 30, enter any *valid* record number from "LISTING". This program will print the contents of that record.

```
10 OPEN "D", 1, "LISTING", 32
20 FIELD 1,20 AS N$,4 AS A$,8 AS P$
30 INPUT "2-DIGIT CODE, 0 TO END"; CODE%
35 IF CODE% = 0 THEN 1000
40 GET #1, CODE%
50 PRINT N$
60 PRINT USING "$$,##"; CVS(A$)
70 PRINT P$: PRINT
80 GOTO 30
1000 CLOSE 1
```

After typing this program, SAVE it and RUN it. When BASIC asks you to enter a 2-digit code, enter 20 (the record we created through the previous program). Your display should show:

```
2-DIGIT CODE, 0 TO END? 20
SMITH
$34.55
567-9000
```

If you entered a record number which is not a part of "LISTING", your display would show:

```
$0.00
```

If you wanted to go back and update "LISTING", simply LOAD the previous program (the one that created "LISTING") and RUN it.

Chapter 6/ Introduction To BASIC Statements And Functions

BASIC is made up of keywords. These keywords instruct the computer to perform certain operations.

Chapter 7 describes all of BASIC's keywords. This chapter explains the format used in Chapter 7. It also introduces you to BASIC's two types of keywords: statements and functions.

Format for Chapter 7

Keyword

Syntax <i>parameter(s)</i> or (<i>expression(s)</i>)
--

Brief definition of keyword.

Detailed definition of keyword.

Example(s)

Sample Program(s)

This format varies slightly, depending on the complexity of each keyword. For instance, some keywords are used alone (without parameters or expressions). Others have several possible syntaxes. As a general rule, definitions for statements are longer than definitions for functions. That is because a statement is a complete instruction to BASIC, while a function is a built-in subroutine which may only be used as part of a statement.

Some keywords have several sample programs, others don't have any at all. We added programs to illustrate useful applications which may not be readily apparent. Remember that this manual is to be used as a reference, not a tutorial on how to program in BASIC.

IMPORTANT NOTE: BASIC for TRSDOS Version 6 requires that keywords be delimited by spaces. This means that you must leave a space between a keyword and any variables, constants or other keywords. The only exceptions to this rule are characters which are shown as part of the syntax of the keyword.

For example, if you typed:

DELETE.

BASIC would return a "Syntax error." You must leave a blank space between the word DELETE and the period.

For a definition of the terms and notation used in Chapter 7, see page 2-4 of the Introduction.

Statements

A program is made up of lines; each line contains one or more statements. A statement tells the computer to perform some operation when that particular line is executed. For example,

```
100 STOP
```

tells the computer to stop executing the program when it reaches line 100.

Statements for assigning values to variables and defining memory space:

CLEAR	clears all variables, allocates memory and stack space.
COMMON	passes variables to a CHAINED program.
DATA	stores data in your program so that you may assign it to a variable.
DEFDBL	defines variables as double precision.
DEF FN	defines a function according to your specifications.
DEFINT	defines variables as integers.
DEFSNG	defines variables as single precision.
DEFSTR	defines variables as strings.
DEF USR	defines the entry point for USR routines.
DIM	dimensions an array.
ERASE	erases an array.
LET	assigns a value to a variable (the keyword LET may be omitted).
MID\$	replaces a portion of a string.
OPTION BASE	declares the minimum value for array subscripts.
RANDOM	reseeds the random number generator.
READ	reads data stored in the DATA statement and assigns it to a variable.
RESTORE	restores the DATA pointer.
SWAP	exchanges the values of variables.

Statements for altering program sequence:

CHAIN	loads another program and passes variables to the current program.
END	ends a program.
FOR/NEXT	establishes a program loop.
GOSUB	transfers program control to the subroutine.
GOTO	transfers program control to the specified line number.
IF ... THEN ... ELSE	evaluates an expression and performs an operation if conditions are met.
ON ... GOSUB	evaluates an expression and branches to a subroutine.

ON . . . GOTO	evaluates an expression and branches to another program line.
RETURN	returns from a subroutine to the calling program.
STOP	stops program execution.
WHILE . . . WEND	executes statements in a loop as long as a given condition is true.
WAIT	suspends program execution while monitoring the status of a machine input port.

Statements for storing and accessing data on disk:

CLOSE	closes access to a disk file.
FIELD	organizes a direct-access buffer.
GET	gets a record from a direct-access file.
INPUT#	inputs data from a disk file.
LINE INPUT#	inputs an entire line from a disk file.
LSET	moves data (and left-justifies it) to a field in a direct-access file buffer.
OPEN	opens a disk file.
PRINT#	writes data to a sequential disk file.
PRINT# USING	writes data to a disk file using the specified format.
PUT	puts a record into a direct-access file.
RSET	moves data (and right-justifies it) to a field in a direct-access file buffer.
WRITE#	writes data to a sequential file.

Statements for debugging a program:

CONT	continues program execution.
ERL	returns the line number where an error occurred.
ERR	returns an error code after an error.
ERROR	simulates the specified error.
ON ERROR GOTO	sets up an error-trapping routine.
RESUME	terminates an error-handling routine.
TROFF	turns the tracer off.
TRON	turns the tracer on.

Statements for inputting or outputting data to the video display or the line printer:

CLS	clears the display.
INPUT	inputs data from the keyboard.
LINE INPUT	inputs an entire line from the keyboard.
LIST	lists a program to the display.
LLIST	lists program to line printer.
LPRINT	prints data at the line printer.
PRINT	prints data to the display.
WRITE	prints data on the display.

Statements for performing system functions or entering other modes of operation:

AUTO	automatically numbers program lines.
CALL	calls an assembly-language subroutine.
DELETE	erases program lines from memory.
DEF USR	specifies the starting address of an assembly-language subroutine.
EDIT	edits program lines.
KILL	deletes a disk file.
LOAD	loads a program from disk.
MERGE	merges a disk program with a resident program.
NAME	renames a disk file.
NEW	erases a program from RAM.
OUT	sends a byte to a machine output port.
POKE	writes a byte into a memory location.
RENUM	renumbers a program.
RUN	executes a program.
SAVE	saves a program on disk.
SOUND	generates a sound
SYSTEM	returns to TRSDOS.

Functions

A function is a built-in subroutine. It may only be used as part of a statement.

Most BASIC functions return numeric or string data by performing certain built-in routines. Special print functions are used to control the video display.

Numeric Functions (return a number):

ABS	computes the absolute value.
ASC	returns the ASCII code.
ATN	computes the arctangent.
CDBL	converts to double precision.
CINT	returns the largest integer not greater than the parameter.
COS	computes the cosine.
CSNG	converts to single precision.
EXP	computes the natural exponential.
FIX	truncates to whole number.
FRE	returns the number of bytes in memory not being used.
INSTR	searches for a specified string.
INP	returns the byte read from a port.
INT	returns the largest whole number not greater than the argument.
LEN	returns the length of the string.
LOG	computes the natural logarithm.

MEM	returns the amount of memory.
PEEK	returns a byte from a memory location.
RND	returns a pseudorandom number.
SGN	returns the sign.
SIN	calculates the sign.
SQR	calculates the square root.
TAN	computes the tangent.
USR	calls an assembly-language subroutine.
VAL	returns the numeric value of a string.
VARPTR	returns an address for a variable or buffer.

String Functions (return a string value):

CHR\$	returns the specified character.
DATE\$	returns today's date.
ERRS\$	returns the latest TRSDOS error number and message.
HEX\$	converts a decimal value to a hexadecimal string.
LEFT\$	returns the left portion of a string.
MID\$	returns the mid-portion of a string.
OCT\$	converts a decimal value to an octal string.
RIGHT\$	returns the right portion of a string.
SPACE\$	returns a string of spaces.
STR\$	converts to string type.
STRING\$	returns a string of characters.
TIME\$	returns the time.

Input/Output Functions (perform input/output to the keyboard, display, line printer or disk files):

INKEY\$	returns the keyboard character.
INPUT\$	returns a string of characters from the keyboard.
POS	returns the cursor column position on the display.
ROW	returns the row position on the display.
SPC	prints spaces to the display.
CVD	restores data from a direct disk file to double precision.
CVI	restores data from a direct disk file to integer.
CVS	restores data from a direct disk file to single precision.
EOF	checks for end-of-file.
INPUT\$	inputs a string of characters from a sequential disk file.
LOC	returns the current disk file record number.
LOF	returns the disk file's end-of-file.
MKI\$	converts an integer value to a string for writing it to a direct-access disk file.
MKS\$	converts a single-precision number to a string for writing it to a direct-access file.
MKD\$	converts a double-precision value to a string for writing it to a direct-access file.

Chapter 7/ Statements And Functions

ABS

ABS(<i>number</i>)	Function
---------------------------	-----------------

Computes the absolute value of *number*.

ABS returns the absolute value of the argument, that is, the magnitude of the number without respect to its sign.

If *number* is greater than or equal to zero, $ABS(number) = number$. If *number* is less than zero, $ABS(negative\ number) = -number$.

Example

```
X = ABS(Y)
```

computes the absolute value of Y and assigns it to X.

Sample Program

```
100 INPUT "WHAT'S THE TEMPERATURE OUTSIDE  
(DEGREES F)"; TEMP  
110 IF TEMP < 0 THEN PRINT "THAT'S" ABS(TEMP)  
    "BELOW ZERO!  BRR!": END  
120 IF TEMP = 0 THEN PRINT "ZERO DEGREES! MITE  
    COLD!": END  
130 PRINT TEMP "DEGREES ABOVE ZERO?  BALMY!":  
    END
```

ASC

ASC(string)	Function
--------------------	-----------------

Returns the ASCII code for the first character of *string*.

The value is returned as a decimal number. If *string* is null, an "Illegal function call" error occurs.

Example

```
PRINT ASC("A")
```

prints 65, the ASCII code for "A".

Sample Programs

ASC can be used to make sure that a program is receiving the proper input. Suppose you've written a program that requires the user to input hexadecimal digits 0-9, A-F. To make sure that only those characters are input, and exclude all other characters, you can insert the following routine.

```
100 INPUT "ENTER A HEXADECIMAL VALUE  
    (0-9,A-F)";N$  
110 A = ASC(N$)           'get ASCII code  
120 IF A>47 AND A<58 OR A>64 AND A<71 THEN  
    PRINT "OK,": GOTO 100  
130 PRINT "VALUE NOT OK,": GOTO 100
```

ASC can also be used to program the special function keys, as in the following program.

```
100 CLS : PRINT "Enter ANY Keyboard Character : ";  
110 IN$ = INKEY$ : IF IN$ = "" THEN GOTO 110  
120 A = ASC(IN$)  
130 IF A = 129 THEN IN$ = CHR$(13) + "F1 KEY" +  
    CHR$(13)  
140 IF A = 130 THEN IN$ = CHR$(13) + "F2 KEY" +  
    CHR$(13)  
150 IF A = 131 THEN IN$ = CHR$(13) + "F3 KEY" +  
    CHR$(13)  
160 PRINT IN$;  
170 GOTO 110  
180 END
```

ATN

ATN(<i>number</i>)	Function
---------------------------	-----------------

Computes the arctangent of *number* in radians.

ATN returns the angle whose tangent is *number*. The result is always single precision, regardless of *number*'s numeric type.

To convert this value to degrees, multiply ATN(*number*) by 57.29578.

Example

```
X = ATN(Y/3)
```

computes the arctangent of Y/3 and assigns the value to X.

AUTO

AUTO [<i>line number</i>][,<i>increment</i>]	Statement
---	------------------

Automatically generates a *line number* every time you press **(ENTER)**. Immediately following the line number, you can enter your text for that line.

AUTO begins numbering at *line* and displays the next line using *increment*. The default for both values is 10. A period (.) can be substituted for *line*. In this case, BASIC uses the current line number.

IF AUTO generates a line number that has already been used, it displays an asterisk after the number. To save the existing line, press **(ENTER)** immediately after the asterisk. AUTO then generates the next line number.

To turn off AUTO, press **(BREAK)**. The current line is canceled and BASIC returns to command level.

Examples

AUTO

generates lines 10, 20, 30, 40.

AUTO 100, 50

generates lines 100, 150, 200, 250 . . .

CALL

CALL <i>variable</i> [(<i>parameter list</i>)]

Statement

Transfers program control to an assembly-language subroutine stored at *variable*.

Variable contains the address where the subroutine starts in memory. *Variable* may not be an array variable.

Parameter list contains the values that are passed to the external subroutine. *Parameter list* may contain only variables.

A CALL statement with no parameters generates a simple Z-80 "CALL" instruction. The corresponding subroutine should return with a simple "RET".

The method for passing parameters depends upon the number of parameters to pass:

1. If the number of parameters is less than or equal to 3, they are passed in the registers. HL contains the address pointing to parameter 1. DE contains the address pointing to parameter 2. BC contains the address pointing to parameter 3.

2. If the number of parameters is greater than 3, they are passed as follows:

HL contains the address pointing to parameter 1.

DE contains the address pointing to parameter 2.

BC points to the low byte of a contiguous data block containing parameters 3 through n (that is, to the low byte of parameter 3).

Note that with this scheme, the subroutine must know how many parameters to expect in order to find them. The calling program is responsible for passing the correct number of parameters.

When accessing parameters in a subroutine, remember that they are pointers to the actual arguments passed.

NOTE: The number, type and length of the parameters in the calling program must match with the parameters expected by the subroutine. This applies to BASIC subroutines, as well as those subroutines written in assembly language.

See also USR and VARPTR.

Example

```
110 MYROUT = &HD000
120 CALL MYROUT(I,J,K)
```

We assume that D000 is the address for an assembly-language routine. The values of I, J, and K (which we also assume were given elsewhere) are passed to that routine.

CDBL

CDBL(<i>number</i>)	Function
----------------------------	-----------------

Converts *number* to double precision.

CDBL returns a 17-digit value. This function may be useful if you want to force an operation to be performed in double precision, even though the operands are single precision or integers.

Sample Program

```
210 A=454.67
220 PRINT A; CDBL(A)
RUN
454.67 454.6700134277344
Ready
```

CHAIN

Statement
CHAIN [MERGE] "<i>filespec</i>" [,<i>line</i>] [,ALL] [,DELETE <i>line-line</i>]]

Loads a BASIC program named *filespec*, chains it to a "main" program, and begins running it.

Filespec must have been saved in ASCII format before you can CHAIN it. To do this, use SAVE with the 'A' option.

Line is the first line to be run in the CHAINED program. If omitted, execution begins at the first program line of the CHAINED program.

The ALL option passes every variable in the main program to the chained program. If omitted, the main program must contain a COMMON statement to pass variables. If you will be CHAINing subsequent programs (and passing variables), each new program must contain a COMMON statement.

The MERGE option "overlays" the lines of *filespec* with the main program. See MERGE to understand how BASIC overlays (merges) program lines.

The DELETE option deletes *lines* in the overlay so that you can MERGE in a new overlay.

Examples

```
CHAIN "PROG2"
```

loads PROG2, chains it to the main program currently in memory, and begins executing it.

```
CHAIN "SUBPROG/BAS" , ALL
```

loads, chains and executes SUBPROG/BAS. The values of all the variables in the main program are passed to SUBPROG/BAS.

Sample Program 1

```
10 REM THIS PROGRAM DEMONSTRATES CHAINING
   REM USING COMMON TO PASS VARIABLES.
20 REM SAVE THIS MODULE ON DISK AS "PROG1"
   REM USING THE A OPTION.
30 DIM A$(2),B$(2)
40 COMMON A$(),B$()
50 A$(1)="VARIABLES IN COMMON MUST BE ASSIGNED "
```

```

60 A$(2)="VALUES BEFORE CHAINING"
70 B$(1)="" : B$(2)=""
80 CHAIN "PROG2"
90 PRINT : PRINT B$(1) : PRINT : PRINT B$(2) :
  PRINT
100 END

```

Save this program as "PROG1", using the 'A' option (Type: SAVE "filespec", A). Type NEW, then enter the following program.

```

10 REM THE STATEMENT "DIM A$(2),B$(2)" MAY
  ONLY BE EXECUTED ONCE.
20 REM HENCE, IT DOES NOT APPEAR IN THIS
  MODULE.
30 REM SAVE THIS MODULE ON THE DISK AS "PROG2"
  USING THE A OPTION.
40 COMMON A$(),B$()
50 PRINT: PRINT A$(1);A$(2)
60 B$(1)="NOTE HOW THE OPTION OF SPECIFYING A
  STARTING LINE NUMBER"
70 B$(2)="WHEN CHAINING AVOIDS THE DIMENSION
  STATEMENT IN 'PROG1',"
80 CHAIN "PROG1",90
90 END

```

Save this program as "PROG2", using the 'A' option. Load PROG1 and run it. Your screen should display:

```

VARIABLES IN COMMON MUST BE ASSIGNED VALUES
BEFORE CHAINING. NOTE HOW THE OPTION OF
SPECIFYING A STARTING LINE NUMBER WHEN
CHAINING AVOIDS THE DIMENSION STATEMENT IN
'PROG1'.

```

Type NEW and this program:

Sample Program 2

```

10 REM THIS PROGRAM DEMONSTRATES CHAINING
  USING THE MERGE AND ALL OPTIONS.
20 A$="MAINPROG"
30 CHAIN MERGE "OVLAY1", 1000, ALL
40 END

```

Save this program as "MAINPROG", using the 'A' option. Enter NEW, then type:

```

1000 PRINT A$;" HAS CHAINED TO OVLAY1."
1010 A$="OVLAY1"
1020 B$="OVLAY2"
1030 CHAIN MERGE "OVLAY2", 1000, ALL, DELETE
  1020-1040
1040 END

```

Save this program as "OVLAY1", using the 'A' option. Enter NEW, then type:

```
1000 PRINT A$; " HAS CHAINED TO ";B$;"", "  
1010 END
```

Save this program as "OVLAY2", using the 'A' option. Load MAINPROG and run it. Your screen should display:

```
MAINPROG HAS CHAINED TO OVLAY1.  
OVLAY1 HAS CHAINED TO OVLAY2.
```

NOTE

The CHAIN statement with the MERGE option leaves the files open and preserves the current OPTION BASE setting.

If the MERGE option is omitted, CHAIN does not preserve variable types or user-defined functions for use by the chained program. That is, any DEFINT, DEFSNG, DEFDBL, DEFSTR, or DEF FN statements containing shared variables must be restated in the chained program.

When using the MERGE option, user-defined functions should be placed before any CHAIN MERGE statements in the program. Otherwise, the user-defined functions will be undefined after the merge is complete.

CHR\$

CHR\$(code)	Function
-------------	----------

Returns the character corresponding to an ASCII or control *code*.

This is the inverse of the ASC function. CHR\$ is commonly used to send a special character to the display.

Examples

```
PRINT CHR$(35)
```

prints the character corresponding to ASCII code 35 (the character is #).

```
PRINT CHR$(16)
```

puts the display into its black-on-white mode, also called reverse video mode. PRINT CHR\$(28) returns it to white-on-black and converts all reverse video characters into graphics characters. See Appendix C for more information.

Sample Program

The following program lets you investigate the effect of printing codes 32 through 255 on the display. (Codes 0-31 represent certain control functions.)

```
100 CLS
110 INPUT "TYPE IN THE CODE (32-255)"; C
120 PRINT CHR$(C);
130 GOTO 110
```

For a complete list and discussion of output to the video display, see the Character Codes table in Appendix C. See also the sample program given for the ASC function of BASIC.

CINT

CINT(<i>number</i>)	Function
-----------------------	----------

Converts *number* to integer representation.

CINT rounds the fractional portion of *number* to make it an integer.

For example, PRINT CINT(1.5) returns 2; PRINT CINT(-1.5) returns -2. The result is a two-byte integer.

Sample Program

```
PRINT CINT(17.65)
18
Ready
```

CLEAR

CLEAR [, <i>memory location</i>] [, <i>stack space</i>]
--

Statement

Clears the value of all variables and CLOSEs all open files.

Memory location must be an integer. It specifies the highest memory location available for BASIC. The default is the current top of memory (as specified when BASIC was loaded or by the location of HIGH\$). This option is useful if you will be loading a machine-language subroutine, since it prevents BASIC from using that memory area.

Stack space must also be an integer. This sets aside memory for temporarily storing internal data and addresses during subroutine calls and during FOR/NEXT loops. The default is 512 bytes or one-eighth of the memory available, whichever is smaller. An "Out of memory" error occurs if there is insufficient stack space for program execution.

NOTE: BASIC allocates string space dynamically. An "Out of string space" error occurs only if no free memory is left for BASIC.

Since CLEAR initializes all variables, you must use it near the beginning of your program, before any variables have been defined and before any DEF statements.

Examples:

```
CLEAR
```

clears all variables and closes all files.

```
CLEAR , 45000
```

clears all variables and closes all files; makes 45000 the highest address BASIC may use to run your programs.

```
CLEAR , 61000 , 200
```

clears all variables and closes all files; makes 61000 the highest address BASIC may use to run your programs, and allocates 200 bytes for stack space.

CLOSE

CLOSE [<i>buffer</i> , ...]	Statement
--------------------------------------	------------------

Closes access to a file.

Buffer is a number from 1 - 15 used to OPEN the file. If no buffers are specified, BASIC closes all open files.

This command terminates access to a file through the specified buffer. If a *buffer* was not assigned in a previous OPEN statement, then

```
CLOSE buffer
```

has no effect.

Do not remove a diskette which contains an open file. CLOSE the file first. This is because the last records may not have been written to disk yet. Closing the file writes the data, if it hasn't already been written.

See also OPEN and the chapter on 'Disk Files'.

Examples

```
CLOSE 1, 2, 8
```

terminates the file assignments to buffers 1,2, and 8. These buffers can now be assigned to other files with OPEN statements.

```
CLOSE FIRST% + COUNT%
```

terminates the file assignment to the buffer specified by the sum FIRST% + COUNT%.

CLS

CLS	Statement
-----	-----------

Clears the screen and moves the cursor to the upper-left corner. All characters on the screen are erased.

Sample Program

```
540 CLS
550 FOR I = 1 TO 24
560 PRINT STRING$ (79,33)
570 NEXT I
580 GOTO 540
```

COMMON

COMMON <i>variable, . . .</i>	Statement
-------------------------------	-----------

Reserves space for *variables* so they can be passed to a CHAINED program.

COMMON may appear anywhere in a program, but we recommend using it at the beginning.

The same variable cannot appear in more than one COMMON statement. To specify array variables, append "()" to the variable name. If all variables are to be passed, use CHAIN with the ALL option and omit the COMMON statement.

NOTE: array variables used in a COMMON statement must have been declared in a DIM statement.

Example

```
90 DIM D(50)
100 COMMON A, B, C, D(),G$
110 CHAIN "PROG3", 10
```

line 100 passes variables A, B, C, D and G\$ to the CHAIN command in line 110.

See also CHAIN.

CONT

	Statement
CONT	

Resumes program execution.

You may only use CONT if the program was stopped by the **BREAK** key, a STOP or an END statement in the program.

CONT is primarily a debugging tool. During a break or stop in execution, you may examine variable values (using PRINT) or change these values. Then type CONT **ENTER**; execution continues with the current variable values.

You cannot use CONT after editing your program lines or otherwise changing your program. CONT is also invalid after execution has ended normally.

Example

```
10 INPUT A, B, C
20 K=A^2
30 L=B^3/ .26
40 STOP
50 M=C+40*K+100: PRINT M
```

Run this program. (To enter the ^, press **CLEAR** **;**.) You will be prompted with:

?

Type:

1, 2, 3 **ENTER**

The computer displays:

```
Break in 40
```

You can now type any immediate command.

For example:

```
PRINT L
```

displays 30.7692. You can also change the value of A, B, or C.

For example:

```
C = 4
```

changes the value of C in the program. Type:

```
CONT
```

your screen displays: 144.

See also STOP.

COS

COS(<i>number</i>)

Function

Computes the cosine of *number*.

COS returns the cosine of *number* in radians. The *number* must be given in radians. When *number* is in degrees, use COS(*number* * .01745329).

The result is always single precision.

Examples

```
Y = COS(X * .01745329)
```

stores in Y the cosine of X, if X is an angle in degrees.

```
PRINT COS(5.8) - COS(85 * .42)
```

prints the arithmetic (not trigonometric) difference of the two cosines.

CSNG

CSNG(<i>number</i>)	Function
----------------------------	-----------------

Converts *number* to single precision.

If *number* is double precision, when its single-precision value is printed, only six significant digits are shown. BASIC rounds the number in this conversion.

Example

```
PRINT CSNG(.1453885509)
```

prints .145389

Sample Program

```
280 V# = 876.2345678#
290 PRINT V#; CSNG(V#)
RUN
      876.2345678000001      876.235
Ready
```

CVD, CVI, CVS

CVD(<i>eight-byte string</i>) CVS(<i>four-byte string</i>) CVI(<i>two-byte string</i>)	Function
---	-----------------

Convert string values to numeric values.

These functions let you restore data to numeric form after it is read from disk. Typically, the data has been read by a GET statement, and is stored in a direct access file buffer.

CVD converts an *eight-byte string* to a double-precision number. CVS converts a *four-byte string* to a single-precision number. CVI converts a *two-byte string* to an integer.

CVD, CVI, and CVS are the inverses of MKD\$, MKI\$, and MKS\$, respectively.

Examples

Suppose the name GROSSPAY\$ references an eight-byte field in a direct-access file buffer, and after GETting a record, GROSSPAY\$ contains an MKD\$ representation of the number 13123.38. Then the statement

```
A# = CVD(GROSSPAY$)
```

assigns the numeric value 13123.38 to the double-precision variable A#.

Sample Program

This program reads from the file "TEST/DAT", which is assumed to have been previously created. For the program that creates the file, see MKD\$, MKI\$, and MKS\$.

```
1420 OPEN "D", 1, "TEST/DAT", 14
1430 FIELD 1, 2 AS I1$, 4 AS I2$, 8 AS I3$
1440 GET 1
1450 PRINT CVI(I1$), CVS(I2$), CVD(I3$)
1460 CLOSE
```

NOTE: GET without a record number tells BASIC to get the first record from the file, or the record following the last record accessed.

DATA

DATA constant, . . .

Statement

Stores numeric and string *constants* to be accessed by a READ statement.

This statement may contain as many *constants* (separated by commas) as will fit on a line. Each will be read sequentially, starting with the first constant in the first DATA statement, and ending with the last item in the last DATA statement.

Numeric expressions are not allowed in a DATA list. If your string values include leading blanks, colons, or commas, you must enclose these values in double quotation marks.

DATA statements may appear anywhere it is convenient in a program. The data types in a DATA statement must match up with the variable types in the corresponding READ statement, otherwise a "Syntax error" occurs.

Examples

```
1340 DATA NEW YORK, CHICAGO, LOS ANGELES,  
        PHILADELPHIA, DETROIT
```

stores five string data items. Note that quote marks aren't needed, since the strings contain no delimiters and the leading blanks are not significant.

```
1350 DATA 2.72, 3.14159, 0.0174533, 57.29578
```

stores four numeric data items.

```
1360 DATA "SMITH, T.H.", 38, "THORN, J.R.", 41
```

stores both types of constants. Quote marks are required around the first and third items because they contain commas (commas are delimiters within data fields).

Sample Program

```
NEW  
10 PRINT "CITY", "STATE", "ZIP"  
20 READ C$,S$,Z  
30 DATA "DENVER,", COLORADO, 80211  
40 PRINT C$,S$,Z
```

This program READS string and numeric data from the DATA statement in line 30.

DATE\$

DATE\$	Function
--------	----------

Returns today's date.

The operator sets the date when TRSDOS is started up.
(This system supports dates between January 1, 1980 and December 31, 1987).

During a program, if you request the date, BASIC displays it in this fashion:

03/12/83

Sample Program

```
1090 PRINT "Inventory Check:"
1100 IF DATE$ = "01/31/80" THEN PRINT "Today is
    the last day of January 1980. Time to
    perform monthly inventory.": END
```

DEFDBL/INT/SNG/STR

DEFDBL <i>letter</i> , ... DEFINT <i>letter</i> , ... DEFSNG <i>letter</i> , ... DEFSTR <i>letter</i> , ...	Statement
--	------------------

Defines any variables beginning with *letter(s)* as: (DBL) double precision, (INT) integer, (SNG) single precision, or (STR) string.

NOTE: A type declaration character always takes precedence over a DEF statement.

Examples

```
10 DEFDBL L-P
```

classifies all variables beginning with the letters L through P as double-precision variables. Their values include 17 digits of precision, though only 16 are printed out.

```
10 DEFSTR A
```

classifies all variables beginning with the letter A as string variables.

```
10 DEFINT I-N, W,Z
```

classifies all variables beginning with the letters I through N, W and Z as integer variables. Their values are in the range -32768 to 32767.

```
10 DEFSNG I, Q-T
```

classifies all variables beginning with the letters I or Q through T as single-precision variables. Their values include seven digits of precision, though only six are printed out.

DEF FN

Statement
DEF FN <i>function name</i> [(<i>variable</i>, . . .)] = <i>function definition</i>

Defines *function name* according to your *function definition*.

Function name must be a valid variable name. The type of variable used determines the type of value the function will return. For example, if you use a single-precision variable, the function will always return single-precision values.

Variable represents those variables in *function definition* that are to be replaced when the function is called. If you enter several variables, separate them by commas.

Function definition is an expression that performs the operation of the function. A variable used in a function definition may or may not appear as *variable*. If it does, BASIC uses its value to perform the function. Otherwise, it uses the current value of the variable.

Once you define and name a function (by using this statement), you can call it and BASIC performs the associated operations.

Examples

```
DEF FNR = RND(90)+9
```

defines a function FNR to return a random value between 10 and 99. Notice that the function can be defined with no arguments.

```
210 DEF FNW# (A#,B#)=(A#-B#)*(A#-B#)
280 T = FNW#(I#,J#)
```

defines function FNW# in line 210. Line 280 calls that function and replaces parameters A# and B# with parameters I# and J#. (We assume that I# and J# were assigned values elsewhere in the program.)

NOTE: Using a variable as a parameter in a DEF FN statement has no effect on the value of that variable. You may use that variable in another part of the program without interference from DEF FN.

DEF USR

DEF USR[<i>digit</i>] = <i>address</i>	Statement
---	------------------

Defines the starting address for the assembly-language subroutine identified by *digit*.

A program may contain any number of DEF USR statements, allowing access to as many subroutines as necessary. However, only 10 definitions may be in effect at one time.

If you omit *digit*, BASIC assumes USR0.

See also USR, VARPTR and CALL.

Examples

```
DEF USR3 = &H7D00
```

assigns the starting address 7D00 hexadecimal, 32000 decimal, to the USR3 call. When your program calls USR3, control branches to your subroutine beginning at 7D00.

```
DEF USR = (BASE + 16)
```

assigns the starting address of BASE + 16 to the USR0 subroutine.

DELETE

DELETE <i>line1</i> - <i>line2</i>	Statement
------------------------------------	-----------

Deletes from *line1* through *line2* of a program in memory.

A period (".") can be substituted for either *line1* or *line2* to indicate the current line number.

Examples

DELETE 70

deletes line 70 from memory. If there is no line 70, an error will occur.

DELETE 50-110

deletes lines 50 through 110 inclusive.

DELETE -40

deletes all program lines up to and including line 40.

DELETE -.

deletes all program lines up to and including the line that has just been entered or edited.

DELETE .

deletes the program line that has just been entered or edited.

DIM

Statement
DIM array (dimension(s)), array (dimension(s)), . . .

Sets aside storage for *arrays* with the *dimensions* you specify.

Arrays may be of any type: string, integer, single precision or double precision, depending on the type of variable used to name the array. If no type is specified, the array is classified as single precision.

When you create the array, BASIC reserves space in memory for each element of the array. All elements in a newly- created array are set to zero (numeric arrays) or the null string (string arrays).

NOTE: The lowest element in a dimension is always zero, unless OPTION BASE 1 has been used.

Arrays can be created implicitly, without explicit DIM statements. Simply refer to the desired array in a BASIC statement. For example,

```
A(5) = 300
```

creates array A and assigns element A(5) the value of 300. Each dimension of an implicitly-defined array is 11 elements deep, subscripts 0 – 10.

Examples

```
DIM AR(100)
```

sets up a one-dimensional array AR(), containing 101 elements: AR(0), AR(1), AR(2), . . . , AR(98), AR(99), and AR(100).

NOTE: The array AR() is completely independent of the variables AR.

```
DIM L1%(8,25)
```

sets up a two-dimensional array L1%(,), containing 9×26 integer elements, L1%(0,0), L1%(1,0), L1%(2,0), . . . , L1%(8,0), L1%(0,1), L1%(1,1), . . . , L1%(8,1), . . . , L1%(0,25), L1%(1,25), . . . , L1%(8,25).

Two-dimensional arrays like AR(,) can be thought of as a table in which the first subscript specifies a row position, and the second subscript specifies a column position:

```

0,0  0,1  0,2  0,3  ...  0,23  0,24  0,25
1,0  1,1  1,2  1,3  ...  1,23  1,24  1,25
.
.
.
7,0  7,1  7,2  7,3  ...  7,23  7,24  7,25
8,0  8,1  8,2  8,3  ...  8,23  8,24  8,25

DIM B1(2,5,8), CR(2,5,8), LY$(50,2)

```

sets up three arrays:

B1(,,) and CR (, ,) are three-dimensional, each containing 3*6*9 elements.

LY(,) is two-dimensional, containing 51*3 string elements.

EDIT

EDIT <i>line</i>	Statement
------------------	-----------

Enters the edit mode so that you can edit *line*.

See the chapter on the “Edit Mode” for more information.

Examples

```
EDIT 100
```

enters edit mode at line 100.

```
EDIT ,
```

enters edit mode at current line.

END

END	Statement
-----	-----------

Ends execution of a program.

This statement may be placed anywhere in the program. It forces execution to end at some point other than the last sequential line.

An END statement at the end of a program is optional.

Sample Program

```
40 INPUT S1, S2
50 GOSUB 100
55 PRINT H
60 END
100 H=SQR(S1*S1 + S2*S2)
110 RETURN
```

line 60 prevents program control from "crashing" into the subroutine. Line 100 may only be accessed by a branching statement, such as GOSUB in line 50.

EOF

EOF(<i>buffer</i>)	Function
----------------------	----------

Detects the end of a file.

This function checks to see whether all characters up to the end-of-file marker have been accessed, so you can avoid "Input past end" errors during sequential input.

EOF(*buffer*) returns 0 (false) when the EOF record has not been read yet, and -1 (true) when it has been read. The buffer number must access an open file.

Sample Program

The following sequence of lines reads numeric data from DATA/TXT into the array A(). When the last data character in the file is read, the EOF test in line 30 "passes", so the program branches out of the disk access loop.

```
1470 DIM A(100)      'ASSUMING THIS IS A SAFE VALUE
1480 OPEN "I", 1, "DATA/TXT"
1490 I% = 0
1500 IF EOF(1) THEN 1540
1510 INPUT#1, A(I%)
1520 I% = I% + 1
1530 GOTO 1500
1540 REM  PROG.  CONT.  HERE AFTER DISK INPUT
```

ERASE

ERASE <i>array</i>, . . .	Statement
----------------------------------	------------------

Erases one or more *arrays* from a program.

This lets you to either redimension arrays or use their previously allocated space in memory for other purposes.

If one of the parameters of ERASE is a variable name which is not used in the program, an "Illegal Function Call" occurs.

Example

```
450 ERASE C,F  
460 DIM F(99)
```

line 450 erases arrays C and F. Line 460 redimensions array F.

ERL

ERL	Statement
-----	-----------

Returns the line in which an error has occurred.

This function is primarily used inside an error-handling routine. If no error has occurred when ERL is called, line number 0 is returned. Otherwise, ERL returns the line number in which the error occurred. If the error occurred in the command mode, 65535 (the largest number representable in two bytes) is returned.

Examples

```
PRINT ERL
```

prints the line number of the error.

```
E = ERL
```

stores the error's line number for future use.

For an example of how to use ERL in a program, see ERROR.

ERR

ERR	Statement
-----	-----------

Returns the error code (if an error has occurred).

ERR is only meaningful inside an error-handling routine accessed by ON ERROR GOTO. See Appendix D for a list of Error Codes.

Example

```
IF ERR = 7 THEN 1000 ELSE 2000
```

branches the program to line 1000 if the error is an "Out of Memory" error (code 7); if it is any other error, control goes instead to line 2000.

For an example of how to use ERR in a program, see ERROR.

ERRS\$

ERRS\$	Function
--------	----------

Returns a system error number and message.

This function returns the number and description of the TRSDOS error that caused the latest BASIC disk-related error. If no TRSDOS error has occurred, ERRS\$ returns a null string.

Example

```
PRINT "THE LATEST TRSDOS ERROR IS "; ERRS$
```

prints the latest error number message.

ERROR

ERROR code	Statement
------------	-----------

Simulates a specified error during program execution.

Code is an integer expression in the range 0 to 255 specifying one of BASIC's error codes.

This statement is mainly used for testing an ON ERROR GOTO routine. When the computer encounters an ERROR code statement, it proceeds as if the error corresponding to that code had occurred. (Refer to Appendix D for a listing of Error Codes and their meanings).

Example

```
ERROR 1
```

a "Next Without For" error (code 1) "occurs" when BASIC reaches this line.

Sample Program

```
110 ON ERROR GOTO 400
120 INPUT "WHAT IS YOUR BET"; B
130 IF B>5000 THEN ERROR 21 ELSE GOTO 420
400 IF ERR = 21 THEN PRINT "HOUSE LIMIT IS
    $5000"
410 IF ERL = 130 THEN RESUME 500
420 S = S+B
430 GOTO 120
500 PRINT "THE TOTAL AMOUNT OF YOUR BET IS";S
510 END
```

This program receives and totals bets until one of them exceeds the house limit.

EXP

EXP(<i>number</i>)	Function
---------------------------	-----------------

Calculates the natural exponent of *number*.

Returns e (base of natural logarithms) to the power of *number*. This is the inverse of the LOG function; therefore, *number* = EXP(LOG(*number*)). The *number* you supply must be less than or equal to 87.3365.

The result is always single precision.

Example

```
PRINT EXP(-2)
```

prints the exponential value .135335.

Sample Program

```
310 INPUT "NUMBER"; N
320 PRINT "E RAISED TO THE N POWER IS" EXP(N)
```

FIELD

FIELD <i>buffer, length AS field name, . . .</i>

Statement

Divides a direct-access *buffer* into one or more fields. Each field is identified by *field name* and is the *length* you specify.

Field name must be a string variable.

This divides a direct file buffer so that you can send data from memory to disk and disk to memory. FIELD must be run prior to GET or PUT.

Before “fielding” a buffer, use an OPEN statement to assign that buffer to a particular disk file. (The direct access mode, i.e., OPEN “D”, . . . must be used.) The sum of all field lengths should equal the record length assigned when the file was OPENed.

You may use the FIELD statement any number of times to “re-field” a file buffer. “Fielding” a buffer does not clear the buffer’s contents; only the means of accessing it. Also, two or more field names can reference the same area of the buffer.

See also the chapter on “Disk Files”, OPEN, CLOSE, PUT, GET, LSET, and RSET.

Example

```
FIELD 3, 128 AS A$, 128 AS B$
```

tells BASIC to assign two 128-byte fields to the variables A\$ and B\$. If you now print A\$ or B\$, you will see the contents of the field. Of course, this value would be meaningless unless you have previously used GET to read a 256-byte record from disk.

NOTE: All data — both strings and numbers — must be placed into the buffer in string form. There are three pairs of functions (MKI\$/CVI, MKS\$/CVS, and MKD\$/CVD) for converting numbers to strings and strings to numbers.

```
FIELD 3, 16 AS NM$, 25 AS AD$, 10 AS CY$, 2 AS  
ST$, 7 AS ZP$
```

assigns the first 16 bytes of buffer 3 to field NM\$; the next 25 bytes to AD\$; the next 10 to CY\$; the next 2 to ST\$; and the next 7 to ZP\$.

FIX

FIX(<i>number</i>)	Function
---------------------------	-----------------

Returns the truncated integer of *number*.

All digits to the right of the decimal point are simply chopped off, so the resultant value is a whole number. For a negative, non-whole number X , $\text{FIX}(X) = \text{INT}(X) + 1$. For all others, $\text{FIX}(X) = \text{INT}(X)$.

The result is the same precision as the argument (except for the fractional portion).

Examples

```
PRINT FIX (2.6)
```

prints 2.

```
PRINT FIX(-2.6)
```

prints -2.

FOR/NEXT

<p style="text-align: right;">Statement</p> <p>FOR <i>variable</i> = <i>initial value</i> TO <i>final value</i> [STEP <i>increment</i>] NEXT [<i>variable</i>]</p>

Establishes a program loop.

A loop allows for a series of program statements to be executed over and over a specified number of times.

BASIC executes the program lines following the FOR statement until it encounters a NEXT. At this point, it increases *variable* by STEP *increment*. If the value of *variable* is less than or equal to *final value*, BASIC branches back to the line after FOR, and repeats the process. If *variable* is greater than *final value*, it completes the loop and continues with the statement after NEXT.

If *increment* has a negative value, then the final value of *variable* is actually lower than the initial value. BASIC always sets the final value for the loop variable before setting the initial value.

NOTE: BASIC skips the body of the loop if *initial value* times the sign of STEP *increment* exceeds *final value* times the sign of STEP *increment*.

Example

```
20 FOR H=1 TO -10 STEP -2
30 PRINT H
40 NEXT H
```

the initial value of H times the sign of STEP increment is greater than the final value of H times the sign of STEP increment, therefore BASIC skips the body of the loop. (The sign of STEP increment is negative in this case.)

Sample Program

```
820 I=5
830 FOR I = 1 TO I + 5
840 PRINT I;
850 NEXT
RUN
```

this loop is executed ten times. It produces the following output:

1 2 3 4 5 6 7 8 9 10

Nested Loops

FOR/NEXT loops may be "nested". That is, a FOR . . . NEXT loop may be placed within the context of another FOR . . . NEXT loop.

The NEXT statement for the inside loop must appear before the NEXT for the outside loop. If nested loops have the same end point, a single NEXT statement may be used for all of them.

Sample Program

```
880 FOR I = 1 TO 3
890 PRINT "OUTER LOOP"
900 FOR J = 1 TO 2
910 PRINT "INNER LOOP"
920 NEXT J
930 NEXT I
```

This program performs three "outer loops" and within each, two "inner loops".

The NEXT statement can be used to close nested loops by listing the counter variables (but make sure not to type the variables out of order). For example, delete line 920 and change 930 to:

```
NEXT J, I
```

NOTE: In nested loops, if the variable(s) in the NEXT statement is omitted, the NEXT statement matches the most recent FOR statement.

FRE

FRE(<i>dummy number</i>) or (<i>dummy string</i>)
--

Function

Returns the number of bytes in memory not being used by BASIC.

NOTE: FRE forces a "garbage collection" before returning the number of free bytes. This may take up to one and a half minutes. Using FRE periodically results in shorter delays for each garbage collection.

Examples

```
PRINT FRE("44")
```

prints the amount of memory left.

```
PRINT FRE(44)
```

prints the amount of memory left.

GET

GET <i>buffer</i> [,<i>record</i>]

Statement

Gets a *record* from a direct-access disk file and places it in a *buffer*.

Before using GET, you must OPEN the file and assign it a buffer.

When BASIC encounters GET, it reads the record number from the file and places it into the buffer. The actual number of bytes read equals the record length set when the file is OPENed.

If *record* is omitted, BASIC gets the next record (after the last GET) and reads it into the buffer.

Examples

GET 1

gets the next record into buffer 1.

GET 1, 25

gets record 25 into buffer 1.

GOSUB

GOSUB <i>line</i>	Statement
--------------------------	------------------

Goes to a subroutine, beginning at *line*.

You can call subroutine as many times as you want. When the computer encounters RETURN in the subroutine, it returns control to the statement which follows GOSUB.

GOSUB is similar to GOTO in that it may be preceded by a test statement. Every subroutine must end with a RETURN.

Example

GOSUB 1000

branches control to the subroutine at 1000.

Sample Program

```
260 GOSUB 280
270 PRINT "BACK FROM SUBROUTINE": END
280 PRINT "EXECUTING THE SUBROUTINE"
290 RETURN
```

transfers control from line 260 to the subroutine beginning at line 280. Line 290 instructs the computer to return to the statement immediately following GOSUB.

GOTO

GOTO <i>line</i>	Statement
-------------------------	------------------

Goes to the specified *line*.

When used alone, GOTO *line* results in an unconditional (automatic) branch. However, test statements may precede the GOTO to effect a conditional branch.

You can use GOTO in the command mode as an alternative to RUN. This lets you pass values assigned in the command mode to variables in the execute mode.

Example

```
GOTO 100
```

transfers control automatically to line 100.

Sample Program

```
10 READ R
20 IF R = 13 THEN END
30 PRINT "R=";R
40 A=3.14*R^2
50 PRINT "AREA =" ;A
60 GOTO 10
70 DATA 5,7,12, 13
RUN
```

line 10 reads each of the data items in line 70; line 50 returns program control to line 10. This enables BASIC to calculate the area for each of the data items, until it reaches item 13.

NOTE: To enter the ^ symbol, press **CLEAR** **()**.

HEX\$

HEX\$(<i>number</i>)	Function
-----------------------------	-----------------

Calculates the hexadecimal value of *number*.

HEX\$ returns a string which represents the hexadecimal value of the argument. The value returned is like any other string: it cannot be used in a numeric expression. That is, you cannot add hex strings. You can concatenate them, though.

Examples

```
PRINT HEX$(30), HEX$(50), HEX$(90)
```

prints the following strings:

```
1E          32          5A
```

```
Y$ = HEX$(X/16)
```

Y\$ is the hexadecimal string representing the integer quotient X/16.

IF . . . THEN . . . ELSE

IF <i>expression</i> THEN <i>statement(s)</i> or <i>line</i> [ELSE <i>statement(s)</i> or <i>line</i>]	Statement
---	------------------

Tests a conditional expression and makes a decision regarding program flow.

If *expression* is true, control proceeds to the THEN *statement* or *line*. If not, control jumps to the matching ELSE *statement*, *line*, or down to the next program line.

Examples

```
IF X > 127 THEN PRINT "OUT OF RANGE" : END
```

passes control to PRINT, then to END if X is greater than 127. If X is not greater than 127, control jumps down to the next line in the program, skipping the PRINT and END statements.

```
IF A < B THEN PRINT "A < B" ELSE PRINT "B < A"
```

tests the first expression, if true, prints "A < B". Otherwise, the program jumps to the ELSE statement and prints "B < A".

```
IF X > 0 AND Y <> 0 THEN Y = X + 180
```

assigns the value $X + 180$ to Y if both expressions are true. Otherwise, control passes directly to the next program line, skipping the THEN clause.

```
IF A$ = "YES" THEN 210 ELSE IF A$ = "NO" THEN  
400 ELSE 370
```

branches to line 210 if A\$ is YES. If not, the program skips over to the first ELSE, which introduces a new test. If A\$ is NO, then the program branches to line 400. If A\$ is any value besides NO or YES, the program branches to line 370.

Sample Program

IF THEN ELSE statements may be nested. However, you must take care to match up the IFs and ELSEs. (If the statement does not contain the same number of ELSE's and IF's, each ELSE is matched with the closest unmatched IF.)

```
1040 INPUT "ENTER TWO NUMBERS"; A, B  
1050 IF A <= B THEN IF A < B THEN PRINT A;  
ELSE PRINT "NEITHER"; ELSE PRINT B;  
1060 PRINT "IS SMALLER THAN THE OTHER"
```

This program prints the relationship between the two numbers entered.

INKEY\$

INKEY\$	Function
----------------	-----------------

Returns a keyboard character.

Returns a one-character string from the keyboard without having to press **ENTER**. If no key is pressed, a null string (length zero) is returned. Characters typed to INKEY\$ are not echoed to the display.

INKEY\$ is invariably put inside some sort of loop. Otherwise a program execution would pass through the line containing INKEY\$ before a key could be pressed.

Example

```
10 A$ = INKEY$  
20 IF A$ = "" THEN 10
```

This causes the program to wait for a key to be pressed.

INP

INP(<i>port</i>)	Function
-------------------------	-----------------

Returns the byte read from a *port*.

INP is the complementary function of the OUT statement.

Port may be any integer from 0 to 255. For information on assigned ports, see the Technical Reference Manual.

Example

```
100 A=INP(42)
```

INPUT

INPUT [<i>prompt string</i> ;] <i>variable1, variable2, . . .</i>	Statement
---	------------------

Inputs data from the keyboard into one or more *variables*.

When BASIC encounters this statement, it stops execution and displays a question mark. This means that the program is waiting for you to type data.

INPUT may specify a list of string or numeric variables, indicating string or numeric data items to be input. For instance, INPUT X\$, X1, Z\$, Z1 calls for you to input a string literal, a number, another string literal, and another number, in that order.

The number of data items you supply must be the same as the number of variables specified. You must separate data items by commas.

Responding to INPUT with too many items, or with the wrong type of value (including numeric type), causes BASIC to print the message “?Redo from start”. No values are assigned until you provide an acceptable response.

If a *prompt string* is included, BASIC prints it, followed by a question mark. This helps the person inputting the data to enter it correctly. If instead of a semicolon, you type a comma after *prompt string*, BASIC suppresses the question mark when printing the prompt. *Prompt string* must be enclosed in quotes. It must be typed immediately after INPUT.

Examples

```
INPUT Y%
```

when BASIC reaches this line, you must type any number and press **ENTER** before the program will continue.

```
INPUT SENTENCE$
```

when BASIC reaches this line, you must type in a string. The string wouldn't have to be enclosed in quotation marks unless it contained a comma, a colon, or a leading blank.

```
INPUT "ENTER YOUR NAME AND AGE (NAME, AGE)";  
N$, A
```

would print a message on the screen which would help the person at the keyboard to enter the right kind of data.

Sample Program

```
50 INPUT "HOW MUCH DO YOU WEIGH"; X  
60 PRINT "ON MARS YOU WOULD WEIGH ABOUT"  
   CINT(X * .38) "POUNDS."
```

INPUT#

Statement
INPUT# <i>buffer, variable, . . .</i>

Inputs data from a sequential disk file and stores it in a program *variable*.

Buffer is the number used when the file was OPENed for input.

Variable contains the variable name(s) that will be assigned to the item(s) in the file.

With INPUT#, data is input sequentially. That is, when the file is OPENed, a pointer is set to the beginning of the file. The pointer advances each time data is input. To start reading from the beginning of the file again, you must close the file buffer and re-OPEN it.

INPUT# doesn't care how the data was placed on the disk — whether a single PRINT# statement put it there, or whether it required ten different PRINT# statements. What matters to INPUT# is the position of the terminating characters and the EOF marker.

When inputting data into a variable, BASIC ignores leading blanks. When the first non-blank character is encountered, BASIC assumes it has encountered the beginning of the data item.

The data item ends when a terminating character is encountered or when a terminating condition occurs. The terminating characters vary, depending on whether BASIC is inputting to a numeric or string variable.

Numeric values: BASIC begins input at the first character which is neither a space nor a carriage return. It ends input when it encounters a space, carriage return, or a comma.

String values: BASIC begins input with the first character which is neither a space nor carriage return. It ends input when it encounters a carriage return or comma. One exception to this rule: If the first character is a quotation mark ("), the string will consist of all characters between the first quotation mark and the second. Thus, a quoted string may not contain a quotation mark as a character.

If the end-of-file is reached when a numeric or string item is being INPUT, the item is terminated.

Examples

```
INPUT#1, A,B
```

sequentially inputs two numeric data items from disk and places them in A and B. Buffer #1 is used.

```
INPUT#4, A$, B$, C$
```

sequentially inputs three string data items from disk and places them in A\$, B\$, and C\$. Buffer #4 is used.

INPUT\$

Statement
INPUT\$(<i>number</i> [,<i>buffer</i>])

Inputs a string of characters from either the keyboard or a sequential disk file.

Number is the number of characters to be input. It must be a value in the range 1 to 255. *Buffer* is a buffer which accesses a sequential input file.

INPUT\$(*number*) inputs a string of characters from the keyboard. When the program reaches this line, it stops until you (or any operator) type *number* characters. (You don't need to press **ENTER** to signify end-of-line.) The character(s) you type are not displayed on the screen. Any character, except **BREAK**, is accepted for input. No characters are echoed.

`INPUT$(number, buffer)` inputs a string from a sequential disk file. *Buffer* is the buffer associated with that disk file.

Examples

```
A$ = INPUT$(5)
```

assigns a string of five keyboard characters to A\$. Program execution is halted until the operator types five characters.

```
A$ = INPUT$(11,3)
```

assigns a string of 11 characters to A\$. The characters are read from the disk file associated with buffer 3.

Sample Programs

This program shows how you could use `INPUT$` to have an operator input a password for accessing a protected file. By using `INPUT$`, the operator can type in the password without anyone seeing it on the video display. (To see the full file specification, run the program, then type `PRINT F$`.)

```
110 LINE INPUT "TYPE IN THE FILESPEC/EXT"; F$
120 PRINT "TYPE IN THE PASSWORD -- MUST TYPE 8
    CHARACTERS: ";
130 P$ = INPUT$(8)
140 F$ = F$ + "," + P$
```

In the program below, line 100 `OPENs` a sequential input file (which we assume has been previously created). Line 200 retrieves a string of 70 characters from the file and stores them in T\$. Line 300 `CLOSEs` the file.

```
100 OPEN "I", 2, "TEST/DAT"
200 T$ = INPUT$(70,2)
300 CLOSE
```

INSTR

INSTR (<i>[integer,]</i> <i>string1</i> , <i>string2</i>)
--

Function

Searches for the first occurrence of *string2* in *string1*, and returns the position at which the match is found.

Integer specifies a position in *string1*. If used it must be a value in the range 1 to 255.

This function lets you search through a string to see if it contains another string. If it does, INSTR returns the starting position of the substring in the target string; otherwise, it returns zero. Note that the entire substring must be contained in the search string, or zero is returned.

Optional *integer* sets the position for starting the search. If omitted, INSTR starts searching at the first character in *string1*.

Examples

In these examples, A\$ = "LINCOLN":

```
INSTR(A$, "INC")
```

returns a value of 2.

```
INSTR(A$, "12")
```

returns a zero.

```
INSTR(A$, "LINCOLNABRAHAM")
```

returns a zero. For a slightly different use of INSTR, look at:

```
INSTR (3, "1232123", "12")
```

which returns 5.

Sample Program

The program below uses INSTR to search through the addresses contained in the program's DATA lines. It counts the number of addresses with a specified county zip code (761—) and returns that

number. The zip code is preceded by an asterisk to distinguish it from the other numeric data found in the address.

```
360 RESTORE
370 COUNTER = 0
390 READ ADDRESS$
395 IF ADDRESS$ = "$END" THEN 410
400 IF INSTR(ADDRESS$, "*761") <> 0 THEN COUNTER =
    COUNTER + 1 ELSE 390
405 GOTO 390
410 PRINT "NUMBER OF TARRANT COUNTY, TX
    ADDRESSES IS" COUNTER: END
420 DATA "5950 GORHAM DRIVE, BURLESON, TX
    *76148"
430 DATA "71 FIRSTFIELD ROAD, GAITHERSBURG, MD
    *20760"
440 DATA "1000 TWO TANDY CENTER, FORT WORTH,
    TX *76102"
450 DATA "16633 SOUTH CENTRAL EXPRESSWAY,
    RICHARDSON, TX *75080"
460 DATA "$END"
```

INT

INT(<i>number</i>)	Function
---------------------------	-----------------

Converts *number* to integer value.

This function returns the largest integer which is not greater than the *number*. *Number* may be an expression.

The result has the same precision as the argument except for the fractional portion. *Number* is not limited to the range -32768 to 32767.

Examples

```
PRINT INT(79.89)
```

prints 79.

```
PRINT INT (-12.11)
```

prints -13.

KILL

KILL "<i>filespec</i>"	Statement
-------------------------------	------------------

"Kills" (deletes) *filespec* from disk.

You may KILL any type of disk file. However, if the file is currently OPEN, a "File already open" error occurs. You must CLOSE the file before deleting it.

Example

```
KILL "FILE/BAS"
```

deletes this file from the first drive which contains it.

```
KILL "DATA:2"
```

deletes this file from Drive 2 only.

LEFT\$

LEFT\$(<i>string</i>,<i>integer</i>)	Function
---	-----------------

Returns the leftmost *integer* characters of *string*.

If *integer* is equal to or greater than LEN (*string*), the entire string is returned.

Examples:

```
PRINT LEFT$("BATTLESHIPS", 6)
```

prints BATTLE.

```
PRINT LEFT$("BIG FIERCE DOG", 20)
```

since BIG FIERCE DOG is less than 20 characters long, the whole phrase is printed.

Sample Program

```
740 A$ = "TIMOTHY"  
750 B$ = LEFT$(A$, 3)  
760 PRINT B$; "--THAT'S SHORT FOR "; A$
```

When this is run, BASIC prints:

```
TIM--THAT'S SHORT FOR TIMOTHY
```

Line 750 gets the three leftmost characters of A\$ and stores them in B\$. Line 760 prints these three characters, a string, and the original contents of A\$.

LEN

LEN(<i>string</i>)	Function
---------------------------	-----------------

Returns the number of characters in *string*.

Examples

```
X = LEN(SENTENCE$)
```

gets the length of SENTENCE\$ and stores it in X.

```
PRINT LEN("CAMBRIDGE") + LEN("BERKELEY")
```

prints 17.

LET

[LET] <i>variable</i> = <i>expression</i>
--

Statement

Assigns the value of *expression* to *variable*.

BASIC doesn't require assignment statements to begin with LET, but you might want to use LET to be compatible with versions of BASIC that do require it.

Examples

```
LET A$ = "A ROSE IS A ROSE"  
LET B1 = 1.23  
LET X = X - Z1
```

In each case, the variable on the left side of the equals sign is assigned the value of the constant or expression on the right side.

Sample Program

```
550 P = 1001: PRINT "P =" P  
560 LET P = 2001: PRINT "NOW P = "P
```

LINE INPUT

LINE INPUT <i>[prompt string;] string variable</i>	Statement
---	------------------

Inputs an entire line (up to 254 characters) from the keyboard.

LINE INPUT is a convenient way to input string data without having to worry about accidental entry of delimiters (commas, quotation marks, etc.).

LINE INPUT (the space is *not* optional) is similar to INPUT, except:

- The computer does not display a question mark when waiting for input.
- Each LINE INPUT statement can assign a value to only one variable.
- Commas and quotes can be used as part of the string input.
- Leading blanks are not ignored — they become part of variable.

The only way to terminate the string input is to press **(ENTER)**.

Some situations require that you input commas, quotes, and leading blanks as part of the data. LINE INPUT serves well in such cases.

Examples:

```
LINE INPUT A$
```

inputs A\$ without displaying any prompt.

```
LINE INPUT "LAST NAME, FIRST NAME? "; N$
```

displays a prompt message and inputs data. Commas do not terminate the input string, as they would in an INPUT statement.

You may abort a LINE INPUT statement by pressing **(BREAK)**. BASIC returns to command level and displays Ready. Typing CONT resumes execution at LINE INPUT.

LINE INPUT#

LINE INPUT# <i>buffer, variable</i>	Statement
--	------------------

Inputs an entire line of data from a sequential disk file to a string *variable*.

Buffer is the number under which the file was OPENed.

This statement is useful when you want to read an ASCII-format BASIC program file as data, or when you want to read in data without following the usual restrictions regarding leading characters and terminators.

LINE INPUT# reads everything from the first character up to:

- the end-of-file
- the 255th data character

Other characters encountered — quotes, commas, leading blanks — are included in the string.

Example

If the data on disk looks like this:

```
10 CLEAR 500
20 OPEN "I", 1, "PROG"
```

then the statement

```
LINE INPUT#1, A$
```

could be used repetitively to read each program line, one at a time.

LIST

LIST [<i>startline</i>]-[<i>endline</i>]	Statement
---	------------------

Lists a program in memory to the display.

Startline specifies the first line to be listed. If omitted, BASIC starts with the first line in your program.

Endline specifies the last line to be listed. If omitted, BASIC ends with the last line in your program.

You can substitute period (.) for either *startline* or *endline* to signify current line number.

Examples

LIST

displays the entire program. To stop the automatic scrolling, press **SHIFT**@. This freezes the display. Press any key to continue the listing.

LIST 50

displays line 50.

LIST 50-85

displays lines in the range 50-85.

LIST .-

displays the program line that has just been entered or edited, and all higher-numbered lines.

LIST -227

displays all lines up to and including 227.

LLIST

LLIST [<i>startline</i>]-[<i>endline</i>]	Statement
--	------------------

Lists program lines in memory to the printer.

The only difference between LLIST and LIST is that LLIST lists the lines on printer. See LIST.

Examples

```
LLIST
```

lists the entire program to the printer. To stop this process, press **SHIFT**@. This causes a temporary halt in the computer's output to the printer. Press any key to continue printing.

```
LLIST 68-90
```

prints lines in the range 68-90.

LOAD

LOAD "<i>filespec</i>" [,R]

Statement

Loads *filespec*, a BASIC program, into memory.

The R option tells BASIC to run the program. (LOAD with the R option is equivalent to the command RUN *filespec*, R.)

LOAD without the R option wipes out any resident BASIC program, clears all variables, and CLOSES all OPEN files. LOAD with the R option leaves all OPEN files open and runs the program automatically.

You can use either of these commands inside programs to allow program chaining (one program calling another).

If you attempt to LOAD a non-BASIC file, a "Direct statement in file" error will occur.

Example

```
LOAD "PROG1/BAS:2"
```

loads PROG1/BAS from Drive 2. BASIC then returns to the command mode.

```
LOAD "PROG1/BAS"
```

loads PROG1/BAS. Since no drive is specified, BASIC begins searching for it in Drive 0.

LOC

LOC(<i>buffer</i>)	Function
---------------------------	-----------------

Returns the current record number.

Buffer is the buffer under which the file was OPENed.

LOC is used to determine the current record number, that is, the number of the last record processed since the file was OPENed. It returns the record number accessed by the last GET or PUT statement.

LOC is also valid for sequential files. It returns the number of sectors (256-byte block) read from or written to the file since the file was OPENed.

Example

```
IF LOC(1)>55 THEN END
```

if the current record number is greater than 55, ends program execution.

Sample Program

```
1310 A$ = "WILLIAM WILSON"  
1320 GET 1  
1330 IF N$ = A$ THEN PRINT "FOUND IN RECORD"  
      LOC(1): CLOSE: END  
1340 GOTO 1320
```

This is a **portion** of a program. Elsewhere the file has been OPENed and FIELDed. N\$ is a field variable. If N\$ matches A\$, the record number in which it was found is printed.

LOF

LOF(<i>buffer</i>)	Function
---------------------------	-----------------

Returns the end-of-file record number.

Buffer is the number under which a file was OPENED.

This function tells you the number of the last record in a direct-access file.

Example

```
Y = LOF(5)
```

assigns the last record number to variable Y.

Sample Programs

During direct access to a pre-existing file, you often need a way to know when you've read the last valid record. LOF provides a way.

```
1540 OPEN "R", 1, "UNKNOWN/TXT", 255
1550 FIELD 1, 255 AS A$
1560 FOR I% = 1 TO LOF(1)      'LOF(1) = HIGHEST
1570 GET 1, I%                'RECORD NUM. TO BE
1580 PRINT A$                  'ACCESSED
1590 NEXT I%
1600 CLOSE
```

If you attempt to GET record numbers beyond the end-of-file, BASIC gives you an error.

When you want to add to the end of a file, LOF tells you where to start adding:

```
1600 I% = LOF(1) + 1          'HIGHEST EXISTING RECORD
1610 PUT 1, I%                'ADD NEXT RECORD
```

LOG

LOG(<i>number</i>)	Function
---------------------------	-----------------

Computes the natural logarithm of *number*.

This is the inverse of the EXP function. The result is always in single precision.

Examples

```
PRINT LOG(3.14159)
```

prints the value 1.14473.

```
Z = 10 * LOG(Ps/P1)
```

performs the indicated calculation and assigns the value to Z.

Sample Program

This program demonstrates the use of LOG. It utilizes a formula taken from space communications research.

```
540 INPUT "DISTANCE SIGNAL MUST TRAVEL  
(MILES)"; D  
550 INPUT "SIGNAL FREQUENCY (GIGAHERTZ)"; F  
560 L = 96.58 + (20 * LOG(F)) + (20 * LOG(D))  
570 PRINT "SIGNAL STRENGTH LOSS IN FREE SPACE  
IS" L "DECIBELS."
```

LPOS

LPOS(<i>number</i>)	Function
----------------------------	-----------------

Returns the logical position of the line printer's print head within the line printer's buffer.

Number is a dummy argument.

This function does not necessarily give the physical position of the print head.

Example

```
100 IF LPOS(X)>60 THEN LPRINT
```

LPRINT, LPRINT USING

LPRINT <i>data</i>, . . . LPRINT USING <i>format</i>; <i>data</i>, . . .	Statement
---	------------------

Prints *data* on the printer.

See PRINT and PRINT USING for more information.

Examples

```
LPRINT (A * 2)/3
```

prints the value of expression (A * 2)/3 on the printer.

```
LPRINT TAB(50) "TABBED 50"
```

moves the line printer carriage to TAB position 50 and prints "TABBED 50". (Refer to the TAB function).

```
LPRINT USING "####,.#"; 2.17
```

sends the formatted value ~~bbbb~~2.2 to the line printer.

LSET

LSET <i>field name</i> = <i>data</i>

Statement

Sets *data* in a direct-access buffer *field name*.

Before using LSET, you must have used FIELD to set up buffer fields.

See also the chapter on "Disk Files", OPEN, CLOSE, FIELD, GET, PUT, and RSET.

Example

Suppose NM\$ and AD\$ have been defined as field names for a direct access file buffer. NM\$ has a length of 18 characters; AD\$ has a length of 25 characters. The statements

```
LSET NM$ = "JIM CRICKET, JR."  
LSET AD$ = "2000 EAST PECAN ST,"
```

set the data in the buffer as follows:

```
JIMCRICKET, JR.    2000EASTPECANST.    
```

Notice that filler blanks were placed to the right of the data strings in both cases. If we had used RSET statements instead of LSET, the filler spaces would have been placed to the left. This is the only difference between LSET and RSET.

If a string item is too large to fit in the specified buffer field, it is always truncated on the right. That is, the extra characters on the right are ignored. This applies to both LSET and RSET.

MEM

MEM	Function
-----	----------

Returns the amount of memory.

MEM performs the same function as FRE. It returns the number of unused and unprotected bytes in memory.

This function may be used in the immediate mode to see how much space a resident program occupies. It may also be used inside a program to avert "Out of memory" errors. MEM requires no argument.

Example

```
PRINT MEM
```

Enter this command in the immediate mode (no line number is needed). The number returned indicates the amount of leftover memory; that is, memory not being used to store programs, variables, strings, the stack, or not reserved for object files.

Sample Program

```
1610 IF MEM < 80 THEN 1630
1620 DIM A(15)
1630 REM          PROGRAM CONTINUES HERE
```

If fewer than 80 bytes of memory are left, control switches to another part of the program. Otherwise, an array of 16 elements is created.

MERGE

MERGE <i>"filespec"</i>

Statement

Loads *filespec*, a BASIC program, and merges it with the program currently in memory.

Filespec specifies a BASIC file in ASCII format (a program saved with the A option). If *filespec* is a constant, it must be enclosed in quotes.

Program lines in the disk program are inserted into the resident program in sequential order. For example, suppose that three of the lines from the disk program are numbered 75, 85 and 90, and three of the lines from the current program are numbered 70, 80, and 90. When MERGE is used on the two programs, this portion of the new program will be numbered 70, 75, 80, 85, 90.

If line numbers on the disk program coincide with line numbers in the resident program, the disk program's lines replace the resident program's lines.

MERGE closes all files and clears all variables. Upon completion, BASIC returns to the command mode.

Example

Suppose you have a BASIC program on disk, PROG2/TXT (saved in ASCII), which you want to merge with the program you've been working on in memory. Then we use:

```
MERGE "PROG2/TXT"
```

merges the two programs.

Sample Programs

MERGE provides a convenient means of putting program modules together. For example, an often-used set of BASIC subroutines can be tacked onto a variety of programs with this command.

Suppose the following program is in memory:

```
80 REM          MAIN PROGRAM
90 REM LINE NUMBER RESERVED FOR SUBROUTINE HOOK
100 REM         PROGRAM LINE
110 REM         PROGRAM LINE
120 REM         PROGRAM LINE
130 END
```

And suppose the following subroutine, SUB/TXT, is stored on disk in ASCII format:

```
90 GOSUB 1000 SUBROUTINE HOOK
1000 REM        BEGINNING OF SUBROUTINE
1010 REM        SUBROUTINE LINE
1020 REM        SUBROUTINE LINE
1030 REM        SUBROUTINE LINE
1040 RETURN
```

You can MERGE the subroutine with the main program with:

```
MERGE "SUB/TXT"
```

and the new program in memory is:

```
80  REM          MAIN PROGRAM
90  GOSUB 1000 SUBROUTINE HOOK
100 REM          PROGRAM LINE
110 REM          PROGRAM LINE
120 REM          PROGRAM LINE
130 END
1000 REM         BEGINNING OF SUBROUTINE
1010 REM         SUBROUTINE LINE
1020 REM         SUBROUTINE LINE
1030 REM         SUBROUTINE LINE
1040 RETURN
```

MID\$

Statement
MID\$(oldstring, position [,length]) = replacement string

Replaces a portion of an *oldstring* with *replacement string*.

Oldstring is the variable name of the string you want to change.

Position is a number specifying the position of the first character to be changed.

Length is a number specifying the number of characters to be replaced.

Replacement string is the string to replace a portion of *oldstring*.

The length of the resultant string is always the same as the original string. If *replacement string* is shorter than *length*, the entire replacement string is used.

Examples:

```
A$ = "LINCOLN"
```

```
MID$ (A$, 3, 4) = "12345": PRINT A$
```

returns LI1234N.

```
MID$ (A$, 5) = "01": PRINT A$
```

returns LINC01N.

```
MID$ (A$, 1, 3) = "***": PRINT A$
```

returns ***COLN.

MID\$

MID\$(<i>string</i>, <i>integer</i> [,<i>number</i>])
--

Function

Returns a substring of *string*, beginning at position *integer*.

If *integer* is greater than the number of characters in *string*, MID\$ returns a null string.

Number is the number of characters in the substring. If omitted, BASIC returns all right most characters, beginning with the character at position *integer*.

Examples

If A\$ = "WEATHERFORD" then

```
PRINT MID$(A$, 3, 2)
```

prints AT.

```
F$ = MID$(A$, 3)
```

puts ATHERFORD into F\$.

Sample Program

```
200 INPUT "AREA CODE AND NUMBER  
   (NNN-NNN-NNNN)"; PH$  
210 EX$ = MID$(PH$, 5, 3)  
220 PRINT "NUMBER IS IN THE " EX$ " EXCHANGE."
```

The first three digits of a local phone number are sometimes called the exchange of the number. This program looks at a complete phone number (area code, exchange, last four digits) and picks out the exchange of that number.

MKD\$, MKI\$, MKS\$

Function
MKI\$(integer expression)
MKS\$(single-precision expression)
MKD\$(double-precision expression)

Convert numeric values to string values.

Any numeric value that is placed in a direct file buffer with an LSET or RSET statement must be converted to a string.

These three functions are the inverse of CVD, CVI, and CVS. The byte values which make up the number are not changed; only one byte, the internal data-type specifier, is changed, so that numeric data can be placed in a string variable.

MKD\$ returns an eight-byte string; MKI\$ returns a two-byte string; and MKS\$ returns a four-byte string.

Example

```
LSET AVG$ = MKS$(0.123)
```

Sample Program

```
1350 OPEN "D", 1, "TEST/DAT", 14
1360 FIELD 1, 2 AS I1$, 4 AS I2$, 8 AS I3$
1370 LSET I1$ = MKI$(3000)
1380 LSET I2$ = MKD$(3000.1)
1390 LSET I3$ = MKD$(3000.00001)
1400 PUT 1, 1
1410 CLOSE 1
```

For a program that retrieves the data from TEST/DAT, see CVD/CVI/CSV.

NAME

NAME <i>old filespec</i> AS <i>new filespec</i>	Statement
--	------------------

Renames *old filespec* as *new filespec*.

With this statement, the data in the file is left unchanged. The *new filespec* may not contain a password or drive specification.

Example

```
NAME "FILE" AS "FILE/OLD"
```

renames FILE as FILE/OLD.

```
NAME B$ AS A$
```

renames B\$ as A\$.

NEW

NEW	Statement
------------	------------------

Deletes the program currently in memory and clears all variables.

NEW displays a new (clear) screen and returns you to the command mode.

Example

```
NEW
```

OCT\$

OCT\$(<i>number</i>)	Function
------------------------	----------

Computes the octal value of *number*.

OCT\$ returns a string which represents the octal value of *number*. The value returned is like any other string — it cannot be used in a numeric expression.

Examples

```
PRINT OCT$(30), OCT$(50), OCT$(90)
```

prints the following strings:

```
36      62      132
```

```
Y$ = OCT$(X/84)
```

Y\$ is a string representation of the integer quotient X/84 to base 8.

ON ERROR GOTO

ON ERROR GOTO <i>line</i>	Statement
---------------------------	-----------

Transfers control to *line* if an error occurs.

This lets your program “recover” from an error and continue execution. (Normally, you have a particular type of error in mind when you use the ON ERROR GOTO statement).

ON ERROR GOTO has no effect unless it is executed before the error occurs. To disable it, execute an ON ERROR GOTO 0. If you use ON ERROR GOTO 0 inside an error-trapping routine, BASIC stops execution and prints an error message.

The error-handling routine must be terminated by a RESUME statement. See RESUME.

Example

```
10 ON ERROR GOTO 1500
```

branches program control to line 1500 if an error occurs anywhere after line 10.

For the use of ON ERROR GOTO in a program, see the sample program for ERROR.

ON . . . GOSUB

ON <i>expression</i> GOSUB <i>line</i> , . . .	Statement
--	-----------

Calls the subroutine at the *line* based on the value of *expression*.

Expression is a numeric expression between 0 and 255, inclusive. For example, if *expression*'s value is three, the third line number in the list is the destination of the branch.

If *expression*'s value is zero or greater than the number of items in the list (but less than or equal to 255), BASIC continues with the next executable statement. If *expression* is negative or greater than 255, an "Illegal function call" error occurs.

Example

```
ON Y GOSUB 1000, 2000, 3000
```

If Y = 1, the subroutine beginning at 1000 is called. If Y = 2, the subroutine at 2000 is called. If Y = 3, the subroutine at 3000 is called.

Sample Program

```
430 INPUT "CHOOSE 1, 2, OR 3" ; I
440 ON I GOSUB 500, 600, 700
450 END
500 PRINT "SUBROUTINE #1": RETURN
600 PRINT "SUBROUTINE #2": RETURN
700 PRINT "SUBROUTINE #3": RETURN
```

ON . . . GOTO

ON <i>expression</i> GOTO <i>line</i> , . . .	Statement
---	-----------

Goes to the *line* specified by the value of *expression*.

Expression is a numeric expression between 0 and 255.

This statement is very similar to ON . . . GOSUB. However, instead of branching to a subroutine, it branches control to another program line.

The value of *expression* determines to which line the program will branch. For example, if the value is four, the fourth line number in the list is the destination of the branch. If there is no fourth line number, control passes to the next statement in the program.

If the value of *expression* is negative or greater than 255, an "Illegal function call" error occurs. Any amount of line numbers may be included after GOTO.

Example

```
ON MI GOTO 150, 160, 170, 150, 180
```

tells BASIC to "Evaluate MI;
if the value of MI equals one then go to line 150;
if it equals two, then go to 160;
if it equals three, then go to 170;
if it equals four, then go to 150;
if it equals five, then go to 180;
if the value of MI doesn't equal any of the numbers one through five,
advance to the next statement in the program".

OPEN

OPEN <i>mode, buffer, "filespec" [,record length]</i>
--

Statement

Opens a disk file.

Mode is a string expression whose first character is one of the following:

- O for sequential output mode
- I for sequential input mode
- E for sequential output and extend mode
- D or R for direct input/output mode

Buffer is an integer between 1 and 15. It specifies which area in memory you will use to access the file.

Filespec specifies a TRSDOS file.

Record length is an integer which sets the record length for direct-access files. The default is 256 bytes.

Once you have assigned a buffer to a file with the OPEN statement, that buffer cannot be used in another OPEN statement. You must first CLOSE the first file.

Examples

```
OPEN "D", 2, "DATA/BAS.SPECIAL"
```

opens the file DATA/BAS in direct-access mode, with the password SPECIAL. Buffer 2 is used. If DATA/BAS does not exist, it is created on the first non write-protected drive. The record length is 256 bytes.

```
OPEN "D", 5, "TEXT/BAS", 64
```

opens the file TEXT/BAS for direct access. Buffer 5 is used. The record length is 64. If this length does not match the record length assigned to TEXT/BAS when the file was originally OPENed, an error occurs.

```
OPEN "D", 7, "INV/CONT"
```

opens the sequential file "INV/CONT" for output. If "INV/CONT" does not exist, it is created. Information is written to the file sequentially, starting at the first byte. If the file does exist, any new information is written over the existing information; the file's previous contents are lost.

```
OPEN "E", 1, "LIST/EMP"
```

opens the file LIST/EMP and extends it by appending new data to the end of the file. If "LIST/EMP" does not exist, OPEN "E" works the same way as OPEN "O".

```
OPEN "I", 8, "MGT"
```

opens the sequential file "MGT" for sequential input. This enables you to retrieve information from the file (using INPUT# or LINE INPUT#). If "MGT" does not exist, a "File not found" error occurs.

See the chapter on "Disk Files" for programming information.

OPTION BASE

OPTION BASE <i>n</i>	Statement
----------------------	-----------

Sets *n* as the minimum value for an array subscript.

N may be 1 or 0. The default is 0.

If you use this statement in a program, it must precede the DIM statement.

If the statement

```
OPTION BASE 1
```

is executed, the lowest value an array subscript may have is one.

OUT

OUT <i>port, data byte</i>	Statement
-----------------------------------	------------------

Sends a *data byte* to a machine output *port*.

Port is an integer between 0 and 255. *Data byte* is also an integer between 0 to 255.

A port is an input/output location in memory. For information on assigned ports, see the Technical Reference Manual.

Example

```
OUT 32,100
```

sends 100 to port 32.

PEEK

PEEK(<i>memory location</i>)	Function
-------------------------------------	-----------------

Returns a byte from *memory location*.

The *memory location* must be in the range – 32768 to 65535.

The value returned is an integer between 0 and 255. (For the interpretation of a negative value of *memory location*, see the statement VARPTR.)

PEEK is the complementary function of the statement POKE.

Example

```
A = PEEK (&H5A00)
```

POKE

POKE <i>memory location</i> , <i>data byte</i>	Statement
--	-----------

Writes *data byte* into *memory location*.

Both *memory location* and *data byte* must be integers. *Memory location* must be in the range – 32768 to 65535.

POKE is the complementary statement of PEEK. The argument to PEEK is a memory location from which a byte is to be read.

PEEK and POKE are useful for storing data efficiently, loading assembly-language subroutines, and passing arguments (or results) to and from assembly-language subroutines.

For more information, see the Technical Reference Manual.

Example

```
10 POKE &H5A00, &HFF
```

POS

POS(<i>number</i>)	Function
----------------------	----------

Returns the position of the cursor.

Number is a dummy argument.

POS returns a number from 1 to 80 indicating the current cursor-column position on the display.

Example

```
PRINT TAB(40) POS(0)
```

prints 40. The PRINT TAB statement moves the cursor to position 40, therefore, POS(0) returns the value 40. (However, since a blank is inserted before the "4" to accommodate the sign, the "4" is actually at position 41).

Sample Program

```
150 CLS
160 A$ = INKEY$
170 IF A$ = "" THEN 160
180 IF POS(X) > 70 THEN IF A$ = CHR$(32)
    THEN A$ = CHR$(13)
190 PRINT A$;
200 PRINT A$;
210 GOTO 160
```

This program lets you use your printer as a typewriter (except that you cannot correct mistakes). Your computer keyboard is the typewriter keyboard. The program will keep watch at the end of a line so that no word is divided between two lines.

PRINT

PRINT <i>data</i>, ...

Statement

Prints numeric or string *data* on the display.

BASIC prints the values of the data items you list in this statement.

You may separate the data items by commas or semicolons. If you use commas, the cursor automatically advances to the next tab position before printing the next item. (BASIC divides each line into five tab positions, at columns 0, 16, 32, 48, and 64). If you use semicolons, it prints the items without any spaces between them.

A semicolon or comma at the end of a line causes the next PRINT statement to begin printing where the last one left off. If no trailing punctuation is used with PRINT, the cursor drops down to the beginning of the next line.

Single-precision numbers with six or fewer digits that can be accurately represented in ordinary (rather than exponential) format,

are printed in ordinary format. For example, 1E-7 is printed as .0000001; 1E-8 is printed as 1E-08.

Double-precision numbers with 16 or fewer digits that can be accurately represented in ordinary format, are printed using the ordinary format. For example, 1D-15 is printed as .0000000000000001; 1D-16 is printed as 1D-16.

BASIC prints positive numbers with a leading blank. It prints all numbers with a trailing blank.

To insert strings into this statement, surround them with quotation marks.

Examples

```
PRINT "DO"; "NOT"; "LEAVE"; "SPACES";  
"BETWEEN"; "THESE"; "WORDS"
```

prints on the display:

DONOTLEAVESPACESBETWEENTHESEWORDS

Sample Program

```
60 INPUT "ENTER THIS YEAR"; Y  
70 INPUT "ENTER YOUR AGE"; A  
80 INPUT "ENTER A YEAR IN THE FUTURE"; F  
90 N = A + (F - Y)  
100 PRINT "IN THE YEAR" F "YOU WILL BE" N "YEARS  
    OLD"  
RUN
```

Since F and N are positive numbers, PRINT inserts a space before and after them, therefore your display should look similar to this (depending on your input):

IN THE YEAR 2004 YOU WILL BE 46 YEARS OLD

If we had separated each expression in line 100 by a comma,

```
100 PRINT "IN THE YEAR", F, "YOU WILL  
    BE", N, "YEARS OLD"
```

BASIC would move to the next tab position after printing each data item.

PRINT USING

PRINT USING <i>format</i>; <i>data item</i>, . . .	Statement
---	------------------

Prints *data items* using a *format* specified by you.

Format consists of one or more field specifiers enclosed in quotes, or a string variable which contains the field specifier(s).

Data item may be string and/or numeric value(s).

This statement is especially useful for printing report headings, accounting reports, checks, or any other documents which require a specific format.

With PRINT USING, you may use certain characters (field specifiers) to format the field. These field specifiers are described below. They are followed by sample program lines and their output to the screen.

Specifiers for String Fields:

! Print the first character in the string only.

```
PRINT USING "!"; "PERSONNEL"  
P
```

\ spaces \ Print 2 + n characters from the string. If you type the backslashes without any spaces, BASIC prints two characters; with one space, BASIC prints three characters, and so on. If the string is longer than the field, the extra characters are ignored. If the field is longer than the string, the string is left-justified and padded with spaces on the right. To enter a backslash, press **CLEAR** **?**.

```
PRINT USING "\bbb\"; "PERSONNEL"  
(three spaces between the backslashes)  
PERSO
```

& Print the string without modifications.

```
10 A$ = "TAKE":B$ = "RACE"  
20 PRINT USING "!";A$;  
30 PRINT USING "&";B$  
RUN  
TRACE
```

Specifiers for Numeric Fields:

- #** Print the same number of digit positions as number signs (#). If the number to be printed has fewer digits than positions specified, the number is right-justified (preceded by spaces). Numbers are rounded as necessary. You may insert a decimal point at any position. In that case, the digits preceding the decimal point are always printed (as zero, if necessary).
- If the number to be printed is larger than the specified numeric field, a percent sign (%) is printed in front of the number. If rounding the number exceeds the field, a percent sign is also printed in front of the rounded number.
- PRINT USING "###.##";111.22
%111.22
- If the number of digits specified exceeds 24, an "Illegal function call" occurs.
- PRINT USING "###.##";.75
0.75
- PRINT USING "###.##";876.567
876.57
- +** Print the sign of the number. The plus sign may be typed at the beginning or at the end of the format string.
- PRINT USING "+###.## ";
- 98.45,3.50,22.22,-.9
- 98.45 + 3.50 + 22.22 - 0.90
- PRINT USING "###.## + ";
- 98.45,3.50,22.22,-.9
98.54 - 3.50 + 22.22 + 0.90 -
- (Note the use of spaces at the end of a format string to separate printed values).
- Print a negative sign after negative numbers (and a space after positive numbers).
- PRINT USING "###.## - "; - 768.660
768.7 -
- **** Fill leading spaces with asterisks. The two asterisks also establish two more positions in the field.
- PRINT USING "**###.##"; 44.0
****44
-

\$\$	<p>Print a dollar sign immediately before the number. This specifies two more digit positions, one of which is the dollar sign.</p> <p>PRINT USING "\$\$###.##"; 112.7890 \$112.79</p>
\$	<p>Fill leading spaces with asterisks and print a dollar sign immediately before the number.</p> <p>PRINT USING "*\$###.##"; 8.333 ***\$8.33</p>
,	<p>Print a comma before every third digit to the left of the decimal point. The comma establishes another digit position.</p> <p>PRINT USING "####,.##"; 1234.5 1,234.50</p>
^ ^ ^ ^	<p>Print in exponential format. The four exponent signs are placed after the digit position characters. To type the ^, press (CLEAR). You may specify any decimal point position.</p> <p>PRINT USING ".####^ ^ ^ ^"; 888888 .8889E+06</p>
_	<p>Print next character as a literal character.</p> <p>PRINT USING "_!##.##_!"; 12.34 !12.34!</p>

Sample Program

```

420 CLS: A$ = "***$###,#####,## DOLLARS"
430 INPUT "WHAT IS YOUR FIRST NAME"; F$
440 INPUT "WHAT IS YOUR MIDDLE NAME"; M$
450 INPUT "WHAT IS YOUR LAST NAME"; L$
460 INPUT "ENTER AMOUNT PAYABLE"; P
470 CLS : PRINT "PAY TO THE ORDER OF ";
480 PRINT USING "!! !! " ; F$ ; ", " ; M$ ; ", " ;
490 PRINT L$
500 PRINT :PRINT USING A$ ; P

```

In line 480, each ! picks up the first character of one of the following strings (F\$, ".", M\$, and "." again). Notice the two spaces in "!!b!!b". These two spaces insert the appropriate spaces after the initials of the name (see below). Also notice the use of the variables A\$ for format and P for item list in line 500. Any serious use of the PRINT USING statement would probably require the use of variables at least for item list rather than constants. (We've used constants in our examples for the sake of better illustration).

When the program above is run, the output should look something like this:

```
WHAT IS YOUR FIRST NAME? JOHN
WHAT IS YOUR MIDDLE NAME? PAUL
WHAT IS YOUR LAST NAME? JONES
ENTER AMOUNT PAYABLE? 12345.6
PAY TO THE ORDER OF J. P. JONES
```

```
*****$12,435.60 DOLLARS
```

PRINT @

PRINT@ <i>location</i>, PRINT@ (<i>row</i>, <i>column</i>),	Statement
--	------------------

Specifies exactly where printing is to begin.

The *location* specified must be a number between 0 and 1919. It can also be a pair of numbers (*r*, *c*), where $23 \geq r \geq 0$ and $79 \geq c \geq 0$.

Whenever you instruct BASIC to PRINT @ the bottom line of the display, it generates an automatic line feed; everything on the display moves up one line. To suppress this automatic line feed, use a trailing semicolon at the end of the statement.

NOTE: If the string you are printing extends past column 80, BASIC prints the entire string on the next line.

Examples

```
PRINT @ (11,39), "*"

```

prints an asterisk in the middle of the display. The space between PRINT and @ is optional.

```
PRINT @ 0, "*"

```

prints an asterisk at the top left corner of the display.

PRINT TAB

PRINT TAB(<i>n</i>)	Statement
----------------------------	------------------

Moves the cursor to the *n* position on the current line.

TAB may be used more than once in a print list.

Since numeric expressions may be used to specify a TAB position, TAB can be very useful in creating tables, graphs of mathematical functions, etc.

TAB can't be used to move the cursor to the left. If the cursor is to the right of the specified position, the TAB statement is simply ignored.

The first parenthesis must be typed immediately after the word TAB.

If *n* is greater than 80, BASIC divides *n* by 80 and uses the remainder of the division as the tab position. For example, if you enter the line:

```
PRINT "NAME"; TAB(85); "AMOUNT"
```

BASIC converts TAB(84) into TAB(4). Since the cursor is already at column five after printing NAME, BASIC moves the string AMOUNT to the next line. If, instead, you had typed TAB(85), BASIC would print AMOUNT on the same line.

If the string you are printing is too long to fit on the current line, BASIC moves the string to the next line.

Example

```
PRINT TAB(5) "TABBED 5"; TAB(25) "TABBED 25"
```

Notice that no punctuation is needed after the TAB modifiers.

Sample Program

```
220 CLS
230 PRINT TAB(2) "CATALOG NO."; TAB(16)
    "DESCRIPTION OF ITEM";
240 PRINT TAB(39) "QUANTITY"; TAB(51) "PRICE
    PER ITEM";
245 PRINT TAB(69) "TOTAL PRICE"
```

PRINT#

PRINT# <i>buffer, item1, item2, ...</i>	Statement
--	------------------

Prints data *items* in a sequential disk file.

Buffer is the buffer number used to OPEN the file for input.

When you first OPEN a file for sequential output, BASIC sets a pointer to the beginning of the file — that's where PRINT# starts printing the values of the *items*. At the end of each PRINT# operation, the pointer advances, so values are written in sequence.

A PRINT# statement creates a disk image similar to what a PRINT to the display creates on the screen. For this reason, make sure to delimit the data so that it will be input correctly from the disk.

PRINT# does not compress the data before writing it to disk. It writes an ASCII-coded image of the data.

Examples

```
If A = 123.45
PRINT# 1,A
```

writes this nine-byte character sequence onto disk:

```
123.45 carriage return
```

The punctuation in the PRINT list is very important. Unquoted commas and semicolons have the same effect as they do in regular PRINT statements to the display. For example, if A = 2300 and B = 1.303, then

```
PRINT# 1, A,B
ENTER
```

writes the data on disk as

```
2300 1.303 carriage return
```

The comma between A and B in the PRINT# list causes 10 extra spaces in the disk file. Generally you wouldn't want to use up disk space this way, so you should use semicolons instead of commas.

Files can be written in a carefully controlled format using PRINT# USING. You can also use this option to control how many characters of a value are written to disk.

For example, suppose A\$ = "LUDWIG", B\$ = "VON", and C\$ = "BEETHOVEN". Then the statement

```
PRINT# 1, USING"!.,\X\X\";A$;B$;C$
```

would write the data in nickname form:

```
L.V.BEET
```

(In this case, we didn't want to add any explicit delimiters.) See PRINT USING for more information on the USING option.

PUT

PUT <i>buffer</i> [, <i>record</i>]	Statement
--------------------------------------	-----------

Puts a *record* in a direct-access disk file.

Buffer is the same buffer used to OPEN the file.

Record is the record number you want to PUT into the file. It is an integer between 1 and 65535. If omitted, the current record number is used.

This statement moves data from the buffer of a file into a specified place in the file.

If *record* is higher than the end-of-file record number, then *record* becomes the new end-of-file record number.

The first time you use PUT after OPENing a file, you must specify the *record*. The first time you access a file via a particular buffer, the next record is set equal to one. (The next record is the record whose number is one greater than the last record accessed).

See the chapter on "Disk Files" for programming information.

```
PUT 1
```

writes the next record from buffer 1 to a direct-access file.

```
PUT 1, 25
```

writes record 25 from buffer 1 to a direct-access file.

RANDOM

RANDOM	Function
---------------	-----------------

Reseeds the random number generator.

If your program uses the RND function, every time you load it, BASIC generates the same sequence of pseudorandom numbers. Therefore, you may want to put RANDOM at the beginning of the program. This will help ensure that you get a different sequence of pseudorandom numbers each time you run the program.

RANDOM needs to execute just once.

Sample Program

```
600 CLS : RANDOM
610 INPUT "PICK A NUMBER BETWEEN 1 AND 5"; A
620 B = RND(5)
630 IF A = B THEN 650
640 PRINT "YOU LOSE, THE ANSWER IS" B "--TRY
    AGAIN."
645 GOTO 610
650 PRINT "YOU PICKED THE RIGHT NUMBER -- YOU
    WIN!": GOTO 610
```

READ

READ <i>variable</i>, . . .

Statement

Reads values from a DATA statement and assigns them to *variables*.

BASIC assigns values from the DATA statement on a one-to-one basis. The first time READ is executed, the first value in the first DATA statement is used; the second time, the second value is used, and so on.

A single READ may access one or more DATA statements (each DATA statement is accessed in order), or several READs may access the same DATA statement.

The values read must agree with the variable types specified in list of variables, otherwise, a "Syntax error" occurs. If the number of variables in the READ statement exceeds the number of elements in the DATA statement(s), an "Out of data" error message is printed.

If the number of variables specified is lower than the number of elements in the DATA statement(s), subsequent READ statements begin reading data at the first unread element.

Example

```
READ T
```

reads a numeric value from a DATA statement and assigns it to variable "T".

Sample Program

This program illustrates a common application for the READ and DATA statements.

```
40 PRINT "NAME", "AGE"
50 READ N$
60 IF N$="END" THEN PRINT "END OF LIST": END
70 READ AGE
80 IF AGE<18 THEN PRINT N$, AGE
90 GOTO 50
100 DATA "SMITH, JOHN", 30, "ANDERS, T.M.", 20
110 DATA "JONES, BILL", 15, "DOE, SALLY", 21
120 DATA "COLLINS, W.P.", 17, "END"
```

REM

REM	Statement
-----	-----------

Inserts a remark line in a program.

REM instructs the computer to ignore the rest of the program line. This allows you to insert remarks into your program for documentation. Then, when you look at a listing of your program, or someone else does, it will be easier to figure it out.

If REM is used in a multi-statement program line, it must be the last statement in the line.

You may use an apostrophe (') as an abbreviation for REM.

Sample Program

```
110 DIM V(20)
120 REM CALCULATE AVERAGE VELOCITY
130 FOR I=1 TO 20
140 SUM=SUM + V(I)
```

OR

```
110 DIM V(20)
120 FOR I=1 TO 20      'CALCULATE AVERAGE VELOCITY
130 SUM=SUM + V(I)
140 NEXT I
```

RENUM

RENUM [<i>new line</i>] [, [<i>line</i>] [, <i>increment</i>]]
--

Statement

Renums a program, starting at *line*, using *new line* as the first new line and *increment* for the new sequence.

If you omit *new line*, BASIC starts numbering at line 10. If you omit the *line*, it renums the entire program. If you omit *increment*, it jumps 10 numbers between lines.

RENUM also changes all line number references appearing after GOTO, GOSUB, THEN, ELSE, ON . . . GOTO, ON . . . GOSUB, ON ERROR GOTO, RESUME, and ERL[relational operator].

Examples

RENUM

renums the entire resident program, incrementing by 10's. The new number of the first line will be 10.

RENUM 600, 5000, 100

renums all lines numbered from 5000 up. The first renumbered line will become 600, and an increment of 100 will be used between subsequent lines.

RENUM 10000, 1000

renums line 1000 and all higher-numbered lines. The first renumbered line will become line 10000. An increment of 10 will be used between subsequent line numbers.

RENUM 100, , 100

renums the entire program, starting with a new line number of 100, and incrementing by 100's. Notice that the commas must be retained even though the middle argument is gone.

Error Conditions

1. RENUM cannot be used to change the order of program lines. For example, if the original program has lines numbered 10, 20 and 30, then the command:

RENUM 15, 30

is illegal, since the result would be to move the third line of the program ahead of the second. In this case, an "Illegal function call" error occurs, and the original program is left unchanged.

2. RENUM will not create new line numbers greater than 65529. Instead, an "Illegal function call" error occurs, and the original program is left unchanged.
3. If an undefined line number is used inside your original program, RENUM prints a warning message, Undefined line XXXX in YYYY", where XXXX is the original line number reference and YYYY is the original number of the line containing XXXX. Note that RENUM rennumbers the program in spite of this warning message. It does not change the incorrect line number reference, but it does renumber YYYY, according to the parameters in your RENUM command.

RESTORE

RESTORE [<i>line</i>]	Statement
-------------------------	-----------

Restores a program's access to previously-read DATA statements.

This lets your program re-use the same DATA lines.

If *line* is specified, the next READ statement accesses the first item in the specified DATA statement.

Sample Program

```
160 READ X$
170 RESTORE
180 READ Y$
190 PRINT X$, Y$
200 DATA THIS IS THE FIRST ITEM, AND THIS IS
    THE SECOND
```

When this program is run,

```
THIS IS THE FIRST ITEM    THIS IS THE FIRST ITEM
```

is printed on the display. Because of the RESTORE statement in line 170, the second READ statement starts over with the first DATA item.

RESUME

RESUME [<i>line</i>] RESUME NEXT	Statement
---	------------------

Resumes program execution after an error-handling routine.

RESUME without an argument and RESUME 0 both cause the computer to return to the statement in which the error occurred.

RESUME *line* causes the computer to branch to the specified line number.

RESUME NEXT causes the computer to branch to the statement following the point at which the error occurred.

A RESUME that is not in an error-handling routine causes a "RESUME without error" message.

Examples

```
RESUME
```

if an error has occurred, this line transfers program control to the statement in which it occurred.

```
RESUME 10
```

if an error has occurred, transfers control to line 10.

Sample Program

```
10 ON ERROR GOTO 900
.
.
.
900 IF (ERR=230) AND(ERL=90) THEN PRINT "TRY
      AGAIN" : RESUME 80
```

RETURN

RETURN	Statement
--------	-----------

Returns control to the line immediately following the most recently executed GOSUB.

If the program encounters a RETURN statement without execution of a matching GOSUB, an error occurs.

Sample Program

```
330 PRINT "THIS PROGRAM FINDS THE AREA OF A  
    CIRCLE"  
340 INPUT "TYPE IN A VALUE FOR THE RADIUS"; R  
350 GOSUB 370  
360 PRINT "AREA IS" ; A: END  
370 A = 3.14 * R * R  
380 RETURN
```

RIGHT\$

RIGHT\$(<i>string</i> , <i>number</i>)	Function
--	----------

Returns the rightmost *number* characters of *string*.

RIGHT\$ returns the last *number* characters of *string*. If LEN (*string*) is less than or equal to *number*, the entire string is returned.

Examples:

```
PRINT RIGHT$("WATERMELON", 5)  
prints MELON.
```

```
PRINT RIGHT$("MILKY WAY", 25)  
prints MILKY WAY.
```

Sample Program

```
850 RESTORE : ON ERROR GOTO 880
860 READ COMPANY$
870 PRINT RIGHT$(COMPANY$, 2), : GOTO 860
880 END
890 DATA "BECHMAN LUMBER COMPANY, SEATTLE, WA"
900 DATA "ED NORTON SEWER SERVICE, BROOKLYN, NY"
910 DATA "HAMMON MANUFACTURING COMPANY,
      HAMMOND, IN"
```

This program prints the name of the state in which each company is located.

RND

RND(<i>number</i>)

Function

Generates a pseudorandom number between 0 and *number*.

Number must be greater than or equal to 0 and less than 32768.

RND produces a pseudorandom number using the current "seed" number. BASIC generates the seed internally, therefore, it is not accessible to the user. RND may be used to produce random numbers between 0 and 1, or random integers greater than 0, depending on the argument.

RND(0) returns a single-precision value between 0 and 1, RND(*number*) returns an integer between 1 and *number*. For example, RND(55) returns a pseudorandom integer between 1 and 55. RND(55.5) returns a pseudorandom number between 1 and 56 (the argument is rounded).

Examples

```
A = RND(2)
```

assigns A a value of 1 or 2.

```
A = RND(45)
```

assigns A a random integer between 1 and 45.

```
PRINT RND (0)
```

prints a decimal fraction between 0 and 1.

ROW

ROW(<i>number</i>)	Function
---------------------------	-----------------

Returns the row position of the cursor.

Number is a dummy argument.

ROW finds the row in which the cursor is currently located and returns that row number. The 24 rows are numbered 0-23.

Examples

```
X = ROW(Y)
```

assigns the cursor's current row number to X.

Sample Program

When you type a key, the program below prints: the keyboard character, the cursor's row number and column number, and the character's ASCII code.

```
100 CLS
110 R=0: C=0
120 PRINT@ (21,32), "ROW", "COLUMN"
130 X$ = INPUT$(1)
140 PRINT @ (R,C), X$;
150 C=POS(0): R=ROW(0)
160 PRINT @ (22,32), R,C;
163 PRINT @ (23,32), STRING$(20,32);
165 PRINT @ (23,32), "ASCII CODE IS
    "HEX$(ASC(X$));
170 PRINT @ (R,C),"";
180 GOTO 130
```

RSET

RSET <i>field name</i> = <i>data</i>	Statement
---	------------------

Sets *data* in a direct-access buffer *field name*.

This statement is similar to LSET. The difference is that with RSET, data is right-justified in the buffer.

See LSET for details.

RUN

RUN [<i>line</i>] RUN <i>filespec</i>[,R]	Statement
--	------------------

Runs a program.

RUN followed by a *line* or nothing at all simply executes the program in memory, starting at *line* or at the beginning of the program.

RUN followed by a *filespec* loads a program from disk and then runs it. Any resident BASIC program is replaced by the new program.

Option R leaves all previously OPEN files open. If omitted, BASIC closes all open files.

RUN automatically CLEARS all variables. However, it does not re-set the value of an ERL variable.

Examples

RUN

starts execution at lowest line number.

RUN 100

starts execution at line 100.

RUN "PROGRAM/A"

loads and executes PROGRAM/A.

RUN "EDITDATA", R

loads and executes EDITDATA, leaving OPEN files open.

SAVE

SAVE "<i>filespec</i>" [,A] [,P]

Statement

Saves a program in a disk file under *filespec*.

If *filespec* already exists, its contents will be lost as the file is re-created.

SAVE without the A option saves the program in a compressed format. This takes up less disk space. It also helps in performing SAVES and LOADs faster. BASIC programs are stored in RAM using compressed format.

Using the A option causes the program to be saved in ASCII format. This takes up more disk space. However, the ASCII format allows you to MERGE this program later on. Also, data programs which will be read by other programs must usually be in ASCII.

For compressed-format programs, a useful convention is to use the extension BAS. For ASCII-format programs, use /TXT.

The P option protects the file by saving it in an encoded binary format. When a protected file is later RUN (or LOADED), any attempt to list or edit it fails. The only operations that can be performed on a protected file are: RUN, LOAD, MERGE, and CHAIN.

Examples

```
SAVE "FILE1/BAS,JOHNQDOE:3"
```

saves the resident BASIC program in compressed format. The file name is FILE1; the extension is /BAS; the password is JOHNQDOE. The file is placed on Drive 3.

```
SAVE "MATHPAK/TXT", A
```

saves the resident program in ASCII form, using the name MATHPAK/TXT, on the first non-write-protected drive.

SGN

SGN(<i>number</i>)	Function
----------------------	----------

Determines *number's* sign.

If *number* is a negative number, SGN returns -1 . If *number* is a positive number, SGN returns 1 . If *number* is zero, SGN returns 0 .

Examples

```
Y = SGN(A * B)
```

determines what the sign of the expression $A * B$ is, and passes the appropriate number ($-1,0,1$) to Y.

Sample Program

```
610 INPUT "ENTER A NUMBER"; X
620 ON SGN(X) + 2 GOTO 630, 640, 650
630 PRINT "NEGATIVE": END
640 PRINT "ZERO": END
650 PRINT "POSITIVE": END
```

SIN

SIN(<i>number</i>)	Function
---------------------------	-----------------

Computes the sine of *number*.

Number must be in radians. To obtain the sine of *number* when *number* is in degrees, use SIN(*number* * .01745329). The result is always single precision.

Examples

```
PRINT SIN(7.96)
```

prints .994385.

Sample Program

```
660 INPUT "ANGLE IN DEGREES"; A
670 PRINT "SINE IS"; SIN A * .01745329)
```

SOUND

SOUND <i>tone, duration</i>	Statement
------------------------------------	------------------

Generates a sound with the *tone* and *duration* specified.

Tone is a digit between 0 and 7. It specifies the sound's frequency level. Zero specifies the lowest frequency level; seven specifies the highest.

Duration is an integer between 0 and 31. It specifies for how long the sound is to be generated. Zero specifies the shortest duration; 31 the longest.

This statement can be especially useful in educational applications. For example, you can have the computer respond with a sound if a

user has answered a program's prompt incorrectly (or vice versa).

Sample Program

```
10 INPUT "IN HONOR OF WHOM WAS THE CONTINENT OF  
   AMERICA NAMED"; A$  
20 IF A$="AMERIGO VESPUCCI" THEN SOUND 7,2 ELSE  
   GOTO 40  
30 PRINT "THAT'S RIGHT!": END  
40 SOUND 1,2 : PRINT "THE CORRECT ANSWER IS  
   AMERIGO VESPUCCI"
```

SPACE\$

SPACE\$(number)

Function

Returns a string of *number* spaces.

Number must be in the range 0 to 255.

Example

```
PRINT "DESCRIPTION" SPACE$(4) "TYPE" SPACE$(9)  
"QUANTITY"
```

prints DESCRIPTION, four spaces, TYPE, nine spaces, QUANTITY.

Sample Program

```
920 PRINT "Here"  
930 PRINT SPACE$(13) "is"  
940 PRINT SPACE$(26) "an"  
950 PRINT SPACE$(39) "example"  
960 PRINT SPACE$(52) "of"  
970 PRINT SPACE$(65) "SPACE$"
```

SPC

SPC(<i>number</i>)	Function
---------------------------	-----------------

Prints a line of *number* blanks.

Number is in the range 0 to 255. SPC does not use string space. The left parenthesis must immediately follow SPC.

SPC may only be used with PRINT, LPRINT, or PRINT#.

Example

```
PRINT "HELLO" SPC(15) "THERE"
```

prints HELLO, 15 spaces, THERE

SQR

SQR(<i>number</i>)	Function
---------------------------	-----------------

Calculates the square root of *number*.

The *number* must be greater than zero.

The result is always single precision.

Example

```
PRINT SQR(155.7)
```

prints 12.478.

Sample Program

```
680 INPUT "TOTAL RESISTANCE (OHMS)"; R
690 INPUT "TOTAL REACTANCE (OHMS)"; X
700 Z = SQR((R * R) + (X * X))
710 PRINT "TOTAL IMPEDANCE (OHMS) IS" Z
```

This program computes the total impedance for series circuits.

STOP

STOP	Statement
------	-----------

Stops program execution.

When a program encounters a STOP statement, it prints the message BREAK IN, followed by the line number that contains the STOP. STOP is primarily a debugging tool. During the break in execution, you can examine variables or change their values.

The CONT command resumes execution at the point it was halted. But if the program itself is altered during the break, CONT cannot be used.

Sample Program

```
2260 X = RND(10)
2270 STOP
2280 GOTO 2260
```

A random number between 1 and 10 is assigned to X, then program execution halts at line 2270. You can now examine the value X with PRINT X. Type CONT to start the cycle again.

STR\$

STR\$(number)	Function
----------------------	-----------------

Converts *number* into a string.

If *number* is positive, STR\$ places a blank before the string.

While arithmetic operations may be performed on *number*, only string functions and operations may be performed on the string.

Example

```
S$ = STR$(X)
```

converts the number X into a string and stores it in S\$.

Sample Program

```
10 A = 1.6 : B# = A : C# = VAL(STR$(A))
20 PRINT "REGULAR CONVERSION" TAB(40) "SPECIAL
   CONVERSION"
30 PRINT B# TAB(40) C#
```

STRING\$

STRING\$(number,character)	Function
-----------------------------------	-----------------

Returns a string of *number* characters.

Number must be in the range 0 to 255.

Character is a string or an ASCII code. If you use a string constant, it must be enclosed in quotes. All the characters in the string will have either the ASCII code specified, or the first letter of the string specified.

STRING\$ is useful for creating graphs or tables.

Examples:

```
B$ = STRING$(25, "X")
```

puts a string of 25 "X"s into B\$.

```
PRINT STRING$(50, 10)
```

prints 50 blank lines on the display, since 10 is the ASCII code for a line feed.

Sample Program

```
1040 CLEAR 300
1050 INPUT "TYPE IN THREE NUMBERS BETWEEN 33
      AND 159"; N1, N2, N3
1060 CLS: FOR I = 1 TO 4: PRINT STRING$(20,
      N1): NEXT I
1070 FOR J = 1 TO 2: PRINT STRING$(40, N2):
      NEXT J
1080 PRINT STRING$(80, N3)
```

This program prints three strings. Each string has the character corresponding to one of the ASCII codes provided.

SWAP

SWAP <i>variable1, variable2</i>

Statement

Exchanges the values of two variables.

Variables of any type may be SWAPped (integer, single precision, double precision, string). However, both must be of the same type, otherwise, a "Type mismatch" error results.

Either or both of the variables may be elements of arrays. If one or both of the variables are non-array variables which have not been assigned values, an "Illegal Function Call" error results.

Example

```
SWAP F1#, F2#
```

swaps the contents of F1# and F2#. The contents of F2# are put into F1#, and the contents of F1# are put into F2#.

Sample Program

```
10 A$="ONE ":B$="ALL ":C$="FOR "  
20 PRINT A$ C$ B$  
30 SWAP A$, B$  
40 PRINT A$ C$ B$  
RUN  
ONE FOR ALL  
ALL FOR ONE
```

SYSTEM

SYSTEM [<i>"command"</i>]	Statement
------------------------------------	------------------

Returns you to TRSDOS level.

Command tells the system to execute the specified TRSDOS command and immediately return to BASIC. Your program and variables are not affected. If *command* is a constant, it must be enclosed in quotes. You can specify only the TRSDOS library commands, not the utilities.

If you omit *command*, SYSTEM returns to the TRSDOS Ready mode. Your resident BASIC program is not retained in memory.

NOTE: You cannot call DEBUG from BASIC.

Examples

```
SYSTEM
```

returns you to TRSDOS. Your resident BASIC program is lost.

```
SYSTEM "DIR"
```

runs the TRSDOS command, DIR (print directory), then returns to BASIC. Your resident BASIC program remains intact.

TAB

TAB(<i>number</i>)	Function
---------------------------	-----------------

Spaces to position *number* on the display.

Number must be in the range 1 to 255.

If the current print position is already beyond space *number*, TAB goes to that position on the next line. Space one is the leftmost position; the width minus one is the rightmost position.

TAB may only be used with the PRINT and LPRINT statements.

Sample Program

```
10 PRINT "NAME" TAB(25) "AMOUNT":PRINT
20 READ A$, B$
30 PRINT A$ TAB(25) B$
40 DATA "G.T.JONES", "$25.00"
RUN
```

The display shows:

NAME	AMOUNT
G.T.JONES	\$25.00

TAN

TAN(<i>number</i>)	Function
---------------------------	-----------------

Computes the tangent of *number*.

Number must be in radians. To obtain the tangent of *number* when it is in degrees, use TAN (number * .01745329). The result is always single precision.

Examples

```
PRINT TAN(7.96)
```

prints -9.39702.

Sample Program

```
720 INPUT "ANGLE IN DEGREES"; ANGLE
730 T = TAN(ANGLE * .01745329)
740 PRINT "TAN IS" T
```

TIME\$

TIME\$	Function
--------	----------

Returns the time of the day.

This function lets you use the time in a program.

The operator sets the time initially when TRSDOS is started up. When you request the time, TIME\$ supplies it using this format:

```
14:47:18
```

which means 14 hours, 47 minutes and 18 seconds (24-hour clock).

To change the time, use the TRSDOS command, TIME. For example,

```
SYSTEM "TIME 10:15:00"
```

Example

```
A$ = TIME$
```

stores the current time in A\$.

Sample Program

```
1130 SYSTEM "TIME 10:15:00"
1140 IF LEFT$(TIME$, 5) = "10:15" THEN PRINT
      "Time is 10:15 A.M.--time to pick up the
      mail." : END
1150 GOTO 1140
```

TROFF, TRON

TROFF TRON	Statements
-----------------------------	-------------------

Turn the "trace function" on/off.

The trace function lets you follow program flow. This is helpful for debugging and analyzing of the execution of a program.

Each time the program advances to a new line, TRON displays that line number inside a pair of brackets. TROFF turns the tracer off.

Sample Program

```
2290 TRON
2300 X = X * 3.14159
2310 TROFF
```

Lines 2290 and 2310 above might be helpful in assuring you that line 2300 is actually being executed, since each time it is executed [2300] is printed on the display.

After a program is debugged, the TRON and TROFF statements can be removed.

USR

Function
USR[<i>digit</i>](<i>expression</i>)

Calls a user's assembly-language subroutine identified with *digit* and passes *expression* to that subroutine.

The *digit* you specify must correspond to the *digit* supplied with the DEF USR statement for that routine. If *digit* is omitted, zero is assumed.

This function lets you call as many as 10 machine-language subroutines, then continue execution of your BASIC program. Subroutines must have been previously defined with DEF USR[*digit*] statements.

When BASIC encounters a USR call, it transfers control to the address defined in the DEF USR[*digit*] statement. (This address specifies the entry point to your machine-language subroutine.)

"Machine language" is the low-level language used internally by your computer. It consists of Z-80 microprocessor instructions. Machine-language subroutines are useful for special applications (things you can't do in BASIC) and for doing things very fast (like to "white-out" the display).

Writing such routines requires familiarity with assembly-language programming and with the Z-80 instruction set. There are books available on this subject; check your local Radio Shack or a book store.

Example

```
X = USR5(Y)
```

calls the machine-language routine USR5, previously defined in a DEF USR5 = *address* statement.

Passing arguments from BASIC to the subroutine:

Upon entry to a USR subroutine, the following register contents are set up (for notation, see the TRSDOS reference section in this manual):

A	=	Type of argument in USR[<i>digit</i>] reference
		A = 8 if argument is double-precision
		A = 4 if argument is single-precision

	A = 2 if argument is integer
	A = 3 if argument is string
HL	= When the argument is a number, this register points to the argument storage area(ASA) described later.
DE	= When the argument is a string, this register points to a string description, as follows: The first byte gives the length of the string. The next two bytes give the address where the string is stored: least significant byte (LSB) followed by most significant byte(MSB).

Description of Argument Storage Area (ASA) — for numeric values only.

For double-precision numbers:

ASA + 3	Exponent in 128-excess form, e.g., a value of 128 indicates a 0 exponent; a value of 66 indicates a - 62 exponent. A value of 0 always indicates the number is zero.
ASA + 2	Highest seven bits of the mantissa with hidden (implied) leading one. Bit 7 is the sign of the number(0 positive, 1 negative), e.g., a value of X'84' indicates the number is negative and the MSB of the mantissa is X'84'. A value of X'04' indicates the number is positive and the MSB of the mantissa is X'84'.
ASA + 1	Next MSB of the mantissa.
ASA	Next MSB.
ASA - 1	Next MSB.
ASA - 2	Next MSB.
ASA - 3	Next MSB.
ASA - 4	Lowest eight bits of the mantissa.

For single-precision numbers:

ASA	LSB of the mantissa.
ASA + 1 through ASA + 3	Same as for double-precision numbers.

For integers:

ASA	LSB of the number
ASA + 1	MSB of the number. Together, the two bytes represent the number in signed, two's complement form.

Your routine can call BASIC's FRCINT routine to put the argument into HL in 16-bit, signed two's complement form. The address of FRCINT is stored in [X'2603', X'2604'].

For example, you can put the following code at the beginning of your subroutine:

```
FRCINT EQU 2603H      ;CONVERTS USR ARGUMENT
                        ;TO INTEGER IN HL
LD HL,CTNU            ;(HL)=CONTINUATION
                        ;ADDRESS
PUSH HL               ;SAVE IT FOR RETURN
                        ;FROM FRCINT
LD HL,(FRCINT)        ;(HL)=FORCE INTEGER
                        ;ROUTINE
JP (HL)               ;DO FRCINT ROUTINE
```

Returning values from the subroutine to BASIC:

If the USR[digit] expression is a variable, you can modify its value by changing the ASA or string contents, as pointed to by HL or DE. For example, the statement:

```
X=USR1(A%)
```

transfers control to the USR1 subroutine, with HL pointing to the two-byte ASA for integer variable A%. Suppose you modify the contents of its storage area. When you do a RET instruction to return to BASIC, A% will have a new value, and X will be assigned this new value.

In general, USR[digit](expression) will return the same type of value as the expression. However, you can use BASIC's MAKINT routine to return an integer value. The address of the MAKINT routine is stored at [X'2605',X'2606'].

For example, you might include the following code at the end of your program to return a value to BASIC:

```
MAKINT EQU 2605H
LD HL,VAL              ;VAL IS THE VALUE TO
                        ;BE RETURNED.
PUSH HL               ;SAVE VALUE IN STACK
LD HL,(MAKINT)        ;RESTORE VAL INTO HL
EX (SP),HL             ;AND PUT MAKINT
                        ;INTO STACK
RET
```

VAL

VAL(<i>string</i>)	Function
---------------------------	-----------------

Calculates the numerical value of *string*.

VAL is the inverse of the STR\$ function; it returns the number represented by the characters in a string argument. This number may be integer, single precision, or double precision, depending on the range of values and the rules used for typing all constants.

For example, if A\$ = "12" and B\$ = "34" then VAL(A\$ + "." + B\$) returns the value 12.34 and VAL(A\$ + "E" + B\$) returns the value 12E34, that is, $12 * 10^{34}$.

VAL terminates its evaluation on the first character which has no meaning in a numeric value.

If the string is non-numeric or null, VAL returns a zero.

Examples

```
PRINT VAL("100 DOLLARS")
```

prints 100.

```
PRINT VAL("1234E5")
```

prints 1.234E+08.

```
B = VAL("3" + "*" + "2")
```

assigns the value 3 to B (the asterisk has no meaning in a numeric term).

Sample Program

```
10 READ NAMES$, CITY$, STATE$, ZIP$
20 IF VAL(ZIP$) < 90000 OR VAL(ZIP$) > 96699
   THEN PRINT NAME$ TAB(25) "OUT OF STATE"
30 IF VAL(ZIP$) > 90801 AND VAL(ZIP$) <= 90815
   THEN PRINT NAME$ TAB(25) "LONG BEACH"
```

VARPTR

	Function
VARPTR (<i>variable</i>) or VARPTR (<i>#buffer</i>)	

Returns the absolute memory address.

VARPTR can help you locate a value in memory. When used with *variable*, it returns the address of the first byte of data identified with *variable*.

When used with *buffer*, it returns the address of the file's data buffer.

If the *variable* you specify has not been assigned a value, an "Illegal Function Call" occurs. If you specify a *buffer* that was not allocated when loading BASIC, a "Bad file number" error occurs. (See Chapter 1 for information on how to load BASIC.)

VARPTR is used primarily to pass a value to a machine-language subroutine via USR[*digit*]. Since VARPTR returns an address which indicates where the value of a variable is stored, this address can be passed to a machine-language subroutine as the argument of USR; the subroutine can then extract the contents of the variable with the help of the address that was supplied to it.

If VARPTR returns a negative address, add it to 65536 to obtain the actual address.

If VARPTR(integer *variable*) returns address K:

Address K contains the least significant byte (LSB) of the 2-byte integer.

Address K + 1 contains the most significant byte (MSB) of the integer.

If VARPTR(single-precision *variable*) returns address K:

- (K)* = LSB of value
- (K + 1) = Next most significant byte (Next MSB)
- (K + 2) = MSB with hidden (implied) leading one. Most significant bit is the sign of the number
- (K + 3) = exponent of value excess 128 (128 is added to the exponent).

*(K) signifies "contents of address K"

If VARPTR(double-precision variable) returns K:

- (K) = LSB of value
- (K + 1) = Next MSB
- (K + . . .) = Next MSB
- (K + 6) = MSB with hidden (implied) leading one. Most significant bit is the sign of the number.
- (K + 7) = exponent of value excess 128 (128 is added to the exponent).

For single and double-precision values, the number is stored in normalized exponential form, so that a decimal is assumed before the MSB. 128 is added to the exponent. Furthermore, the high bit of MSB is used as a sign bit. It is set to 0 if the number is positive or to 1 if the number is negative. See examples below.

If VARPTR(string variable) returns K:

- (K) = length of string
- (K + 1) = LSB of string value starting address
- (K + 2) = MSB of string value starting address

The address will probably be in high RAM where string storage space has been set aside. But, if your string variable is a constant (a string literal), then it will point to the area of memory where the program line with the constant is stored, in the program buffer area. Thus, program statements like A\$="HELLO" do not use string storage space.

For all of the above variables, addresses (K-1) and (K-2) stores the TRS-80 Character Code for the variable name. Address (K-3) contains a descriptor code that tells the computer what the variable type is. Integer is 02; single precision is 04; double precision is 08; and string is 03.

VARPTR(array variable) returns the address for the first byte of that element in the array. The element consists of 2 bytes if it is an integer array; 3 bytes if it is a string array; 4 bytes if it is a single precision array; and 8 bytes if it is a double precision array.

The first element in the array is preceded by:

1. A sequence of two bytes per dimension, each two-byte pair indicating the "depth" of each respective dimension.
2. A single byte indicating the total number of dimensions in the array.
3. A two-byte pair indicating the total number of elements in the array.
4. A two-byte pair containing the ASCII-coded array name.

5. A one-byte type-descriptor(02 = Integer, 03 = String, 04 = Single = Precision, 08 = Double-Precision).

Item 1 immediately precedes the first element, Item 2 precedes Item 1, and so on.

The elements of the array are stored sequentially with the first dimension-subscripts varying "fastest", then the second, etc.

Examples

$A! = 2$ is stored as follows:

$2 = 10$ Binary, normalized as $.1E2 = .1 \times 10$ (to the second)

So exponent of A is $128 + 2 = 130$ (called excess 128)

MSB of A is 10000000; however, the high bit is changed to zero since the value is positive(called hidden or implied leading one).

So A! is stored as

Exponent(K + 3)	MSB(K + 2)	Next MSB(K + 1)	LSB(K)
130	0	0	0

$A! = -.5$ is stored as

Exponent(K + 3)	MSB(K + 2)	Next MSB(K + 1)	LSB(K)
128	128	0	0

$A! = 7$ is stored as

Exponent(K + 3)	MSB(K + 2)	Next MSB(K + 1)	LSB(K)
131	96	0	0

$A! = -7$:

Exponent(K + 3)	MSB(K + 2)	Next MSB(K + 1)	LSB(K)
131	224	0	0

Zero is stored as a zero-exponent. The other bytes are insignificant.

$Y = \text{USR1}(\text{VARPTR}(\text{number}))$

If number is an integer value, VARPTR(number) finds the address of the least significant byte of number. This address is passed to the subroutine, which in turn passes its result to Y.

WAIT

WAIT <i>port</i>, <i>integer1</i> [,<i>integer2</i>]	Statement
---	------------------

Suspends program execution until a machine input *port* develops a specified bit pattern. (A port is an input/output location.)

The data read at the port is exclusive OR'ed with *integer2*, then AND'ed with *integer1*. If the result is zero, BASIC loops back and reads the data at the port again. If the result is nonzero, execution continues with the next statement. If *integer2* is omitted, it is assumed to be zero.

It is possible to enter an infinite loop with the WAIT statement. In this case, you will have to manually restart the machine. To avoid this, WAIT must have the specified value at port number during some point in program execution.

For information on assigned ports, refer to the Technical Reference Manual.

Example

```
100 WAIT 32,2
```

WHILE WEND

	Statement
WHILE <i>expression</i>	
.	
.	
.	
.	
{loop statements}	
.	
WEND	

Execute a series of statements in a loop as long as a given condition is true.

If *expression* is not zero (true), BASIC executes loop statements until it encounters a WEND. BASIC returns to the WHILE statement and checks *expression*. If it is still true, BASIC repeats the process. If it is not true, execution resumes with the statement following the WEND statement.

WHILE/WEND loops may be nested to any level. Each WEND matches the most recent WHILE. An unmatched WHILE statement causes a "WHILE without WEND" error, and an unmatched WEND causes a "WEND without WHILE" error.

Sample Program

```
90 'BUBBLE SORT ARRAY A$
100 FLIPS=1 'FORCE ONE PASS THRU LOOP
110 WHILE FLIPS
115 FLIPS=0
120 FOR I=1 TO J-1
130 IF A$(I)>A$(I+1) THEN SWAP A$(I), A$(I+1):
    FLIPS=1
140 NEXT I
150 WEND
```

This program sorts the elements in array A\$. Control falls out of the WHILE loop when no more SWAPS are performed on line 130.

WRITE

WRITE [<i>data</i> , ...]	Statement
------------------------------------	------------------

Writes *data* on the display.

WRITE prints the values of the data items you type. If *data* is omitted, BASIC prints a blank line. The *data* may be numeric and/or string. They must be separated by commas.

When the *data* are printed, each data item is separated from the last by a comma. Strings are delimited by quotation marks. After printing the last item on the list, BASIC inserts a carriage return.

Example

```
10 D=95:B=76:V$="GOOD BYE"  
20 WRITE D, B, V$  
RUN  
  95, 76, "GOOD BYE"  
Ready
```

WRITE#

WRITE# <i>buffer, data, . . .</i>	Statement
--	------------------

Writes *data* to a sequential-access file.

Buffer must be the number used to OPEN the file.

The *data* you enter may be numeric or string expressions.

WRITE# inserts commas between the data items as they are written to disk. It delimits strings with quotation marks. Therefore, it is not necessary to put explicit delimiters between the data.

The items on *data* must be separated by commas.

WRITE# inserts a carriage return after writing the last data item to disk.

For example, if

A\$="MICROCOMPUTER" and B\$="NEWS"

the statement

WRITE#1, A\$,B\$

writes the following image to disk:

"MICROCOMPUTER","NEWS"

Part III/ Appendices

Appendix	Page
A/ Job Control Language	A-3
B/ Model 4 Hardware	A-35
C/ Character Codes	A-45
D/ Error Messages and Problems	A-61
E/ Converting TRSDOS Version 1 BASIC Programs to TRSDOS Version 6 BASIC Programs	A-75
F/ BASIC Keywords and Derived Functions	A-79
G/ BASIC Worksheets	A-83
H/ Glossary	A-85
I/ TRSDOS Programs	A-91
J/ BASIC Memory Map	A-101
K/ Using The Device-Related Commands	A-103
L/ HERZ50	A-107
M/ Backup Limited Diskettes	A-109

Appendix A/ Job Control Language

The TRSDOS Job Control Language (JCL) is one of the most powerful features of TRSDOS. It consists of:

- TRSDOS commands
- Macros
- Special symbols

You can use JCL to make your computer more “user friendly.” That is, you can write JCL programs that perform a variety of functions, such as FORMAT and BACKUP, and have TRSDOS execute these functions when the user types in one command line.

If you have read the entries on the BUILD and DO commands, you know how to create a JCL file composed of TRSDOS commands. You can make this file more powerful by utilizing macros and other features of JCL. This section describes how.

The steps for creating and using a JCL file are:

1. Create a JCL file consisting of TRSDOS commands, macros, or special symbols. You can do this with the BUILD command, SCRIPSIT, or a BASIC program.
2. Execute the JCL file with the DO command. This causes the JCL processor to:
 - Take control of the keyboard (for line input)
 - Read a line in the DO file exactly as if it came from the keyboard
 - Return control of the keyboard to the user when it reaches the last line.

The following sections give complete information on all the JCL features:

- Simple JCL Execution
- Simple JCL Compiling
- Advanced JCL Compiling

Simple JCL Execution

This section lists the execution macros and gives examples on how to create and run a JCL file.

Creating a JCL File

A JCL file contains characters normally available from the keyboard (ASCII characters).

There are several ways to create a JCL file: the BUILD library command lets you create or extend a JCL file, but it does not let you edit an existing file. You can create and edit a JCL file with a BASIC program. A word processing system, such as SCRIPSIT, will also let you create or edit a JCL file.

Restrictions of JCL

- A JCL file line cannot be longer than 79 characters. Depending on the JCL method used (execute only or compile), JCL either ignores all characters after the 79th or aborts the processing entirely.
- Any program or utility with unpredictable prompts will not function properly when run from a JCL file.
- Any program or utility which requires removing the system disk causes the JCL to abort.
- You cannot execute certain TRSDOS library commands and utilities from a JCL file. The commands and utilities NOT valid from a JCL file are : certain BACKUP commands, BUILD, certain CONV commands, all (X) commands, DEBUG, certain PURGE commands, SYSGEN, and SYSTEM (SYSTEM=) command.
- As a general rule, you should not use a library command or utility when you specify the QUERY parameter.

Table 1/ Execution Macros

Macro Group	Group Description	Macros	Macro Description
Execution Comment		.Comment	Displays a comment on the screen during execution. Comments are written to SYSTEM/JCL.
Termination Macros	Terminate execution.	//ABORT //EXIT //STOP	Stops execution, displays "Job aborted". Returns to TRSDOS or BASIC Ready. Stops execution, displays "Job done". Returns to TRSDOS or BASIC Ready. Stops execution. Returns control to the user program.
Pause/Delay Macros	Provide special functions.	//PAUSE //DELAY //WAIT //SLEEP	Suspends execution and displays a message. Suspends execution and displays a message for a specified amount of time. Suspends execution depending upon the setting of the system clock. Suspends execution for a predetermined amount of time.
Alert Macros	Provide video and audio alerts.	//FLASH //ALERT	Flashes a message on the screen a specified number of times. Provides an audible signal to the operator.
Keyboard Macros	Accept key-board input.	//KEYIN //INPUT	Selects predefined blocks of JCL lines. Inputs a line of information from the keyboard.

JCL Execution Macros

A macro is a pre-defined JCL instruction. `//ABORT` is an example of a macro symbol. Macro symbols must start at the first character position in the line. **An execution macro cannot be the first line in a JCL file.**

The JCL execution macros are:

`//ABORT`

Use this macro to exit a JCL procedure (if an error is encountered) and return to the program that initiated the `DO` command.

Your system returns you to the calling program if your JCL processing logic detects an error. The following message:

```
Job aborted
```

is displayed when an error is encountered.

`//ALERT [(tone,silence,tone,silence, . . .)]`

Use this macro to produce tones to the operator. `//ALERT` can generate up to eight different tones using the sound generator inside the computer.

You could use this macro to signify the end of a large JCL procedure. It could also be used during the execution of a procedure to bring attention to a specific process.

Tone is controlled by a number ranging from 0 - 7, with 7 producing the lowest tone and 0 producing the highest tone.

The tone is followed by a period of silence which you select with a second number ranging from 0 - 7, with 7 producing the longest period of silence and 0 producing the shortest period of silence. Tone and silence must be entered as number pairs (for example, "1,0"). You can enter as many number pairs as can fit on one line.

You can repeat the tone-silence sequence by enclosing the entire string in parentheses. The sequence keeps repeating until you press **ENTER**, which continues execution of the JCL. Pressing **BREAK** aborts the JCL.

Any value entered (for tone or silence) is used in its modulo 8 form. That is, if you enter the number 8, a zero value is assumed. For example, the value 10 produces the tone assigned to 2.

`//DELAY duration`

The `//DELAY` macro provides a definite timed pause with execution automatically continuing at the end of the delay. The actual delay will be approximately 0.1 second per count. The count ranges from 1 to 256. Thus, a delay of from 0.1 second to 25.6 seconds is possible.

You could use the //DELAY macro to suspend execution long enough for you to make sure the printer is ready to print.

The execution time of a //DELAY macro will vary slightly according to the speed TRSDOS is running under (FAST or SLOW). See the SYSTEM library command.

//EXIT

Use this macro to halt execution of JCL processing and return to the program that initiated the DO command.

If you do not enter a termination macro in a JCL file, the JCL processing terminates when it reaches the end of the file (as if //EXIT were the last line in the JCL file). The following message is displayed:

```
Job done
```

This message indicates a normal conclusion of the JCL file.

You should use //EXIT if the conclusion of the JCL file also represents the conclusion of the job that is running. So, //EXIT can be used to conclude a program that does not require any more keyboard input, and needs to return to TRSDOS Ready or BASIC Ready after it finishes.

To conclude a program that requires additional keyboard input, use the //STOP macro. Using the //EXIT macro would terminate the program.

//FLASH [*duration*] *message*

This macro flashes *message* on and off the video screen. *duration* is the number of times the *message* will flash and can be any number from 0 to 255. If *duration* is not specified, the message flashes 256 times. The message is any comment that you want displayed (up to 72 characters).

//KEYIN [*comment string*]

Use this macro to prompt for a single character entry (0 - 9), with the entire //KEYIN line being displayed.

During execution, press the appropriate character (0 - 9) to select the corresponding execution block in a JCL file. There can be up to ten execution blocks in a JCL file, each tagged with // and a number 0 - 9.

Do not use //KEYIN to enter data at execution time. If you do need to enter data at execution time, use the //INPUT macro.

//INPUT [*message string*]

Use this macro to input a line from the keyboard during JCL execution. With this macro, control of the keyboard is temporarily

returned to the operator. Now, any command can be typed on the keyboard and then passes to the system.

The number of characters allowed in the input line depends on where the JCL execution is when the `//INPUT` is encountered. For example, if the JCL is executing at the TRSDOS Ready level, then you can enter up to 80 characters, the same as for a normal TRSDOS command. If the `//INPUT` is encountered after going into BASIC, then you can enter up to 255 characters.

When you use the `//INPUT` macro, you should exercise some caution to assure that the command typed in is valid at the level it will be executed. For example, if you enter a program name incorrectly, the error message "Program not found" is displayed and the JCL execution aborts.

`//PAUSE [message string]`

When this macro is encountered in an executing JCL file, it is displayed on the screen along with a message. You can use the message to inform the operator why the pause was ordered. Press **ENTER** to resume JCL execution, or press **BREAK** to abort the JCL.

The `//DELAY`, `//WAIT`, and `//SLEEP` macros are similar to the `//PAUSE` macro, and are used to give JCL execution a specific delay period.

`//SLEEP hh:mm:ss`

Use this macro to put the system "to sleep" for the amount of time you specify.

`//SLEEP` adds the specified time to the current system time and waits until that time to begin or resume execution.

Suppose you have two programs that begin execution every morning at 10 o'clock and each program runs for two hours. You could execute the first program and have the `//SLEEP` macro "halt" execution of the second program for an hour lunch break. After the system "sleeps" for the specified hour, the second program is executed.

`//STOP`

Use this macro to halt execution of a JCL file and return keyboard control to the applications program that requests additional keyboard input.

If you do not use the `//STOP` macro, you automatically return to TRSDOS Ready or BASIC Ready. You can also use the `//ABORT` and `//EXIT` macros to force an end to the JCL execution and return to TRSDOS Ready or BASIC Ready.

//WAIT hh:mm:ss

The //WAIT macro is similar to //DELAY, except that the length of the delay depends on the setting of the system clock.

The //WAIT macro puts the entire system in a "sleep" state until the system clock matches the time you specified.

You can set the system clock with the TIME library command. You can also set the time from a JCL file by using a direct execution of the TIME library command, or with the //INPUT macro. Set the clock in the format hh:mm:ss.

Examples

The easiest JCL file to understand is one containing only commands.

Use the BUILD command to create the following JCL file named START/JCL:

```
DEVICE
FREE
```

If you issue a DO = START command (see the DO library command), your computer displays the device table, lists free space information about all enabled drives, and returns to TRSDOS Ready.

Because an execution macro cannot be the first line in a JCL file, you could use an execution comment to display an informative message as the JCL file begins to execute. An execution comment begins with a period, which must be in the first character position of the line. You could label START/JCL as follows:

```
. This program executes the DEVICE and FREE
commands.
DEVICE
FREE
//EXIT
```

This comment describing the file's purpose is displayed when the JCL executes. It shows the file's purpose. Notice that we added the termination macro //EXIT.

You can use the //PAUSE macro in START/JCL as follows:

```
. This program executes the DEVICE and FREE
library commands.
//PAUSE Be sure the correct disk is in Drive 0!
DEVICE
FREE
//EXIT
```

This example suspends the JCL before DEVICE executes, so you can be sure that the correct disk is in Drive 0. Press **ENTER** to continue the JCL.

You can use the //DELAY macro if you want to display an informative message to the operator. For example:

```
. BE SURE THAT THE PRINTER IS TURNED ON!  
//DELAY 50  
DEVICE (P)  
FREE (P)  
//EXIT
```

This example displays the above informative message and delays execution for approximately 5 seconds. After the delay, it executes DEVICE and FREE.

If you want your system to execute START/JCL at a certain time of the day, use the //WAIT macro as follows:

```
. This program runs at 2:15 a.m.  
//WAIT 02:15:00  
DEVICE  
FREE  
//EXIT
```

This example displays the comment and then waits until the system clock matches the time of 02:15:00 specified in the //WAIT macro. It would then execute DEVICE and FREE, and return to TRSDOS Ready.

```
. This program runs after a two-hour pause.  
//SLEEP 02:00:00  
DEVICE  
FREE  
//EXIT
```

This example displays the comment and then "sleeps" for two hours. It then executes DEVICE and FREE, and returns to TRSDOS Ready.

To use the //FLASH macro, modify START/JCL as follows:

```
. This program executes the DEVICE and FREE  
commands.  
DEVICE  
//FLASH 10 Starting execution of FREE  
FREE  
//EXIT
```

After DEVICE executes, the //FLASH line is displayed. It flashes on and off 10 times, as specified by the duration count. You can press **ENTER** to stop the flash and proceed to the next line. Pressing **BREAK** while the message is flashing aborts the JCL and displays the message "Job Aborted".

You can modify START/JCL to show several uses of //ALERT:

```
. This program shows several uses of //ALERT.
. TURN TO PAGE 4 AT THE TONE.
//ALERT 0,0,1,5,0,2
. PRESS ENTER TO BEGIN EXECUTION.
//ALERT (1,0,7,0)
DEVICE
FREE
//EXIT
```

The first tone tells you when to turn to page 4. The second tone repeats until you press **ENTER** to continue execution of the program or **BREAK** to abort the JCL.

The next example shows how you could build a menu using execution comments to display different program choices. Using the //KEYIN macro lets you press a single key to execute the desired program.

```
. START/JCL
. Program 1 is FREE :0
. Program 2 is FREE
. Program 3 is DEVICE
//KEYIN Select program, 1 - 3
//1
FREE :0
//EXIT
//2
FREE
//EXIT
//3
DEVICE
//EXIT
///
```

There are two new macros used in this example. They are *//number* and *///*.

//number is used to start a block of lines that corresponds to a value selected with the //KEYIN macro. This block extends until the next *//number* or to the *///*.

/// (the triple slash) is used to mark the end of all *//number* blocks. JCL stops looking for a match as soon as it encounters a *///*. Execution continues with the following line.

In the above example, pressing 1, 2, or 3 selects the corresponding block of lines and runs the appropriate command. If you press a key other than 1, 2, or 3, all three *//number* blocks are ignored, and execution continues with the line after the *///*.

The lines following the /// could contain other command options or an //ABORT macro to abort the JCL. One possible option could be to let the operator type in his own command.

Consider the following rewrite of START/JCL that uses the //INPUT macro to let the operator type in his own command:

```
. START/JCL
. Program 1 is FREE :0
. Program 2 is FREE
. Program 3 is DEVICE
//KEYIN Select Program, 1 - 3
//1
FREE :0
//EXIT
//2
FREE
//EXIT
//3
DEVICE
//EXIT
///
//INPUT Enter your own choice of command.
//EXIT
```

Now, if you press a key other than 1, 2, or 3 for the //KEYIN, the //INPUT line is displayed.

You can also enter information directly into the system at the JCL level. For example, the //WAIT macro description mentions that you can set the time for the system clock in the middle of a JCL file.

The following example prompts you to enter the TIME library command to set the system clock. After you input the time, the //WAIT macro pauses execution of the JCL file until the clock matches 02:15:00 and then continues execution.

```
. This program runs at 2:15 a.m.
//INPUT Enter the TIME command using HH:MM:SS format.
//WAIT 02:15:00
DEVICE
FREE
//EXIT
```

JCL Compiling

The previous section explained how to create and use execute JCL files. This section describes some basic functions of the JCL compiler and shows practical examples of JCL files.

While an execute JCL file is useful, you need to use the compile phase of JCL for extra features. These extra features are explained in four parts:

- Compilation Description and Terms
- Conditional Decisions
- Substitution Fields
- Combining Files

Compilation Description and Terms

You can compile and/or execute any JCL file using the DO library command. If your JCL file contains only execution comments, commands, or execution macros, then you can completely skip the compile phase (using the “=” control character with the DO command).

If, however, your JCL file contains “tokens” or labels, or must make logical decisions, then you must compile the file before executing it.

The compile phase reads in the JCL file line by line, checking for directly executable lines, keyboard responses, and execution macros. The compile phase also evaluates any compilation statements and writes *all* resultant lines to a file called SYSTEM/JCL. After the compile phase completes, control is normally passed to the execution phase, which executes the SYSTEM/JCL file.

As stated earlier, the JCL works by substituting lines in a file for keyboard entries. However, when you compile a JCL file, it can contain more than just a series of executable commands. (After the compile phase is completed, however, the SYSTEM/JCL file *does* contain only executable lines.)

You can include the following statements in a JCL file you intend to compile:

- Directly executable commands (DIR, BASIC, etc.)
- Pre-arranged keyboard responses
- JCL execution macros (listed in Table 1)
- JCL conditional macros (listed in Table 2)
- Labels
- Another JCL file. When a JCL file “calls” another JCL file, TRSDOS transfers control to the called file and doesn’t return control to the calling file.

We use several terms when discussing JCL compilation. They are:

1. Token

A token is a string of up to 8 alphanumeric characters. You can use both upper and lower case letters. Note: There is NO difference between upper and lower case letters for any JCL macro, token, or label.

You can use a token (1) as a true/false switch for logical decisions (see the //IF macro), and (2) as a character string value in substitution fields (see the SUBSTITUTION FIELDS section).

2. Logical operator

The simple logical operators are:

AND (represented by the ampersand symbol "&")

OR (represented by the plus symbol "+")

NOT (represented by the minus symbol "-")

3. Label

A JCL label is used to define the start of a JCL procedure, which allows many small JCL procedures to be combined into one large file. The format for a label is:

`@label`

The *label* can be up to 8 alphanumeric characters long.

Table 2/ Conditional Macros

Macro Group	Group Description	Macros	Macro Description
Compilation Comment		//Comment	Acts like a visual log of the JCL file because they are displayed during compilation. These comments are not written to SYSTEM/JCL.
Logical Macros	Define conditional "blocks."	//IF //END //ELSE	Defines the start of a conditional block. Defines the end of a conditional block. Defines the alternative to a false //IF.
Higher Order Logical Macros	Provide for higher conditional logic statements.	//SET //RESET //ASSIGN	Gives a token a logical true value. Gives a token a logical false value. Sets a token's value to true and assigns a character string value to the token.
Termination Macro		//QUIT	Aborts JCL compiling if an invalid condition is detected.
Merge Macro		//INCLUDE	Merges together two or more JCL files during compilation.

Conditional Decisions

Using //IF, //END, //ELSE

The logical compilation macros (//IF, //END, and //ELSE) are used to establish logical "blocks" in a JCL file. When a JCL file is being compiled, these blocks are evaluated as either true or false.

The //IF macro followed by a token determines if the block is true or false.

To set a token true, specify it on the DO command line. To set a token false, do NOT specify it on the DO command line.

These JCL macros produce the following results:

- | | |
|---|---|
| 1) If token is true . . . | 2) If token is false . . . |
| <pre>//IF token Include these lines. //END</pre> | <pre>//IF token Ignore these lines. //END</pre> |
| 3) If token is false, perform the alternative . . . | |
| <pre>//IF token Ignore these lines. //ELSE Include these lines. //END</pre> | |

With this type of logical decision capability, you can create a JCL file and then pick a course of action by typing in a "DO *filespec*" command with different tokens.

Examples

Consider the following JCL file named START/JCL.

```
. START/JCL for Program start-up
SET *FF to FORMS/FLT
FILTER *PR *FF
//IF PR1
FORMS (CHARS=80)
//ELSE
FORMS (CHARS=132)
//END
```

Assume that these are the first lines in a JCL file that begins execution of an applications program.

To make the //IF PR1 test as true, issue the following DO command:

```
DO START (PR1) ENTER
```

The 80 characters per line is selected.

If (PR1) is not specified on the DO command line, then the //IF test is false and the 132 characters per line is selected.

Using //SET and //RESET

JCL provides the //SET and //RESET macros to reduce the number of tokens in the DO command line.

One basic use for //SET is to let one token set the value of another. For example:

```
//IF KI
//SET P1
//END
```

This JCL file specifies that if KI is true, then P1 is set to a true condition also.

Suppose that the token P2 is already SET and you want to give it a new value. Consider this example:

```
//IF KI
//RESET P2
//END
```

This JCL file specifies that if KI is true, then P2 is reset to a false condition.

Consider the JCL file named MENU/JCL:

```
. MENU/JCL, revision 1
SET *FF TO FORMS/FLT
FILTER *PR *FF
//IF P1
//RESET P2
FORMS (CHARS=80)
//ELSE
//SET P2
FORMS (CHARS=132)
//END
```

If you issue either one of the following commands:

```
DO MENU (P1) (ENTER)
DO MENU (P1,P2) (ENTER)
```

the //IF macro tests P1 as true; therefore P2 is reset to false, and the *FF and 80-character mode are applied.

If you issue either one of the following commands:

```
DO MENU (ENTER)
DO MENU (P2) (ENTER)
```

the //IF macro tests false so the //ELSE macro sets P2 to true and the 132-character mode is applied.

As previously mentioned, the //SET macro can be used to reduce the number of tokens that have to be entered on the DO command line. Consider the following SYSOPT/JCL example:

```
. Establish TRSDOS system options
//IF ALL
//SET COMM
//SET PR
//SET SET
//SET SRES
//END
//IF KIALl
//SET COMM
//SET SET
//END
//IF COMM
set *cl to com/dvr
setcom (word=8)
//END
//IF PR
set *ff to forms/flt
filter *pr *ff
forms (chars=80)
//END
//IF SET
setki (rate=7)
//END
//IF SRES
system (sysres=2)
system (sysres=3)
system (sysres=10)
//END
```

This example shows how many different TRSDOS options can be established with a JCL file. The way it is structured, you can choose any or all of the options.

If you did not use //SET, you would have to enter four separate tokens on the DO command line to establish all of the options, as follows:

```
DO SYSOPT/JCL (COMM,PR,SET,SRES) ENTER
```

If you specify "ALL" in the DO command line, COMM, PR, SET, and SRES are set to true conditions.

If you specify "KIALl" in the DO command line, COMM and SET are set to true conditions.

Notice the use of upper and lower case. As stated earlier, either upper or lower case letters can be used in any JCL macro, token, or label. This is also true when the line is a TRSDOS command, as are the lower case lines in this example.

You can improve the readability of a JCL file by using upper case for macros and lower case for executable lines, such as TRSDOS commands, or vice versa.

Using //ASSIGN

JCL provides the //ASSIGN macro to set a token's logical value true, and to assign a character string value to a token.

The syntax for the //ASSIGN macro is:

```
//ASSIGN token=character string
```

character string can consist of up to 32 characters. Any character on the keyboard is allowed except a double-quotation mark (").

Error Conditions

Any time you use //ASSIGN, there must be at least one character assigned as a value or the compiling aborts.

Examples

In any of the previous examples that used the //SET macro, the //ASSIGN macro could have been substituted. The character string value assigned to the token has no effect on the JCL logic.

In the following example, if the token A is true, the tokens P1, KI, and PR are all set to true. This example assigns character string values to the tokens.

```
.TEST/JCL  
//IF A  
//ASSIGN P1=PROGRAM/BAS  
//ASSIGN KI=ALL  
//ASSIGN PR=80  
//END
```

Using //. Comment and //QUIT

Compilation comments (//. Comment) are not written to the SYSTEM/JCL file. They are displayed on the screen as they are encountered during compilation. Thus, they act as a visual status log of the compile.

The //QUIT macro aborts the compilation stage if the JCL detects an invalid condition. This macro lets you make sure all needed tokens are entered before any execution takes place.

Examples

```
. START/JCL
set *ff to forms/flt
filter *Pr *ff
forms (lines=60)
//IF KI
setki (rate=5)
//ELSE
//. RATE was not set!
//QUIT
//END
//EXIT
```

If this JCL file is compiled without the token KI being entered on the DO command line, the screen display shows:

```
//. RATE was not set!
//QUIT
```

No actual lines are executed from the SYSTEM/JCL file, because the compile phase was aborted before completion. The compilation comment tells the operator why the abort took place.

If you substitute //ABORT for //QUIT in the previous example and then compile the JCL file without the token KI, the following lines result:

```
//. RATE was not set!
. START/JCL
set *ff to forms/flt
filter *Pr *ff
forms (lines=60)
Job aborted
```

The comment line is displayed as the file is being compiled. However, since //ABORT is an execution macro, the SYSTEM/JCL file finishes compiling and then executes until it reaches the //ABORT line! The //QUIT macro should be used in such a case rather than the //ABORT.

Substitution Fields

One of the most powerful features of the JCL is its ability to substitute and concatenate (add together) character strings to create executable lines.

A substitution field is created by placing pound signs (#) around a token. When the file is compiled, this substitution token is replaced with its current value, either assigned on the DO command line or with the //ASSIGN macro.

Examples

```
. TEST/JCL
set *ff to forms/flt
filter *Pr *ff
forms (chars=#C#)
basic
run"#P1#"
//STOP
```

This example uses two substitution fields: one in the FORMS command line representing the number of characters, and one in the RUN command line.

If you issue the DO command:

```
DO TEST (C=132,P1=PROGRAM1) ENTER
```

the lines written to the SYSTEM/JCL file are:

```
. TEST/JCL
set *ff to forms/flt
filter *Pr *ff
forms (chars=132)
basic
run"PROGRAM1"
//STOP
```

The compile phase substitutes the character string value of the tokens into the actual command line!

The length of the replacement string does not have to be equal to the length of the token name between the # signs.

To reduce the number of tokens needed on the DO command line, and to increase the program options at the same time, use the //ASSIGN macro as follows:

```
. TEST/JCL
//ASSIGN c=80
//ASSIGN P1=Program1
//IF num2
//ASSIGN c=132
//ASSIGN P1=Program2
//END
set *ff to forms/flt
filter *Pr *ff
forms (chars=#C#)
basic
run"#P1#"
//STOP
```

Specifying NUM2 overrides the 80-character printer filter and PROGRAM1 defaults. The values of C and P1 are automatically set with the //ASSIGN tokens inside the //IF conditional block.

Another use for substitution fields is replacing drive numbers.

The following example shows how a FORMAT and BACKUP JCL file can be structured:

```
. FB/JCL, FORMAT with BACKUP
//PAUSE Insert disk to format in drive #D#
format :#D# (name="data1",q=n,ABS)
backup :#S# :#D#
//EXIT
```

The token D represents the destination drive, and the token S represents the source drive.

If you enter the command:

```
DD FB/JCL (S=1,D=2) (ENTER)
```

the system pauses and prompts you to insert a disk in Drive 2.

Press (ENTER) and the JCL file continues. It formats the disk in Drive 2, and then it executes the backup command with Drive 1 as the source drive and Drive 2 as the destination drive.

The substitution fields can be used in message lines and comments as well as in executable command lines.

Be careful when you want to display a single “#” in a comment or message. Consider the following example:

```
//PAUSE Insert a disk in drive #1
```

If the JCL file were executed only, this line would be properly displayed. However, if the JCL were compiled, an error would occur. For this line to be properly displayed in a compiled JCL, it would have to be written as:

```
//PAUSE Insert a disk in drive ##1
```

Another practical use for substitution fields is copying password protected files from one drive to another.

```
. MOVE/JCL file transfer
copy Program1,#P#:# :#D#
copy Program2,#P#:# :#D#
copy Program3,#P#:# :#D#
copy Program4,#P#:# :#D#
//EXIT
```

In this example, a group of files is copied from Drive 0 to a drive specified in the DD command. Also, you have to supply the proper

password for the copies to work. If you specify the wrong password, an error is displayed and the JCL aborts.

Substitution fields can also be concatenated, or added together, to create new fields. For example:

```
. ADD/JCL
COPY #F#/#E# : 1
COPY #F1#/#E# : 1
//EXIT
```

This example uses two substitution fields, one for the filename and one for the extension.

If you issue the DO command:

```
DO ADD (F=SORT,E=CMD,F1=SORT1) ENTER
```

the following SYSTEM/JCL file results after compiling:

```
. ADD/JCL
COPY SORT/CMD : 1
COPY SORT1/CMD : 1
//EXIT
```

As in previous examples, the //IF and //ASSIGN macros could be used to allow a single token to select the F, F1, and E tokens.

Combining Files

Most of the JCL examples in the previous sections have been very short. In a practical operating environment, this is often the case. However, each of these small files is taking up the minimum disk allocation of one gran and using one directory entry.

To combine small files and save disk space, use the Label feature of JCL. You can also use the //INCLUDE macro to duplicate a JCL file inside of another JCL file, without having to retype the lines.

Using //INCLUDE

The //INCLUDE macro is used to merge together two or more JCL files during the compile phase. The syntax is:

```
//INCLUDE filespec
```

filespec is a JCL file.

This command is similar to specifying the filespec in a DO command line. However, you cannot enter tokens or other information after the filespec.

If you need to pass tokens to the included program, they will have to be established in the program that is doing the //INCLUDE.

Error Conditions

An `//INCLUDE` macro CANNOT be the last line in a JCL file. If it is, an "End of File Encountered" error occurs, and the JCL aborts.

Examples

This example shows two JCL files and the results of the compile phase. The two JCL files are:

```
. TEST1/JCL          . TEST2/JCL
. comment line 1      . This comment is included
//INCLUDE TEST2
. comment line 2
//EXIT
```

If you issue the command

```
DO TEST1 ENTER
```

the following SYSTEM/JCL file is produced:

```
. TEST1/JCL
. comment line 1
. TEST2/JCL
. This comment is included
. comment line 2
//EXIT
```

The compiling starts with the file named in the DO command line. As soon as the `//INCLUDE` is reached, all lines in the second JCL file are processed, and then the compiling returns to the rest of the original file.

There is no limit to the number of non-nested `//INCLUDE` macros you can use, other than having enough disk space for the resulting SYSTEM/JCL file.

Using JCL Labels

The LABEL feature of JCL allows you to permanently merge together many small JCL procedures into one large file, and then access those procedures individually. This saves disk space and directory entry slots.

Examples

```
. TEST/JCL label example
@FIRST
. this is the first procedure
//exit
@SECOND
. this is the next procedure
@THIRD
. this is the last procedure
```

This file contains three labels. To select any procedure, specify the label on the DO command line.

The following rules determine how much of a labeled JCL file is included in the compile phase:

- 1) If no label is specified on the DO command line, all lines from the beginning of the file up to the first label are compiled.
- 2) If a label is specified, compiling includes all lines from the specified label until the next label or the end of the file is reached.

DOing the TEST/JCL file using the @FIRST label would write the comment ". this is the first procedure" and the //EXIT macro to the SYSTEM/JCL file for execution. Specifying either of the other labels would include only the appropriate single comment line.

If you compiled the file without specifying a label in the DO command, only the initial execution comment ". TEST/JCL label example" would be written in SYSTEM/JCL.

There is no limit to the size of a labeled procedure. They can range from one to as many lines as you can fit on your disk. The only requirement is that a JCL file containing labels must be compiled.

When you use labels in a JCL file, we recommend that you start the file with a comment line or some executable line other than a label.

Suppose @FIRST is the first line in the following file:

```
@FIRST
. Print this comment
```

If you issued a DO command for this file without specifying the @FIRST label, the compiling phase would receive the first line, see that it is a label, and quit. Since the compile is complete, the SYSTEM/JCL file would be executed! And since nothing was written to SYSTEM/JCL, its old contents are not erased. In other words, whatever lines had been compiled to the SYSTEM/JCL file from a previous DO command would now be executed.

Advanced JCL Compiling

The previous section on JCL compiling described the basic uses of tokens and compilation macros. If you do not understand the JCL Compiling section, please re-read it. If you actually type in and try the examples, you will get a better understanding of how to structure a JCL file for compiling.

This section describes additional features and shows different ways to accomplish logical decision branching. These additional features are explained in four parts:

-
- Using the Logical Operators
 - Using Nested //IF Macros
 - Using Nested //INCLUDE Macros
 - Using the Special % Symbol

Using the Logical Operators

The logical operators used with the //IF macro (AND, OR, and NOT) specify the type of logical testing, and they are represented as follows:

AND — ampersand (&)
OR — plus sign (+)
NOT — minus sign (-)

All previous examples of //IF tested the logical truth or falseness of a token. You can accomplish more complex and efficient testing by using the logical operators.

Consider the following series of examples using the tokens A and B:

```
//IF -A
. include these lines if A is not specified
//END
```

By using NOT (-), you can see if a token is false, which provides an alternative method to select a block of lines for compiling.

```
//IF A+B
. include these lines if A or B is specified
//END
```

```
//IF A&B
. include these lines if A and B are specified
//END
```

These examples show how multiple tokens may be tested in a single //IF statement. The first example is true if either A OR B is true. The second example is true only if both A AND B are true.

You can use any combination of logical operators in an //IF statement. The following rules apply:

- The expressions are evaluated from left to right.
- Do not use parentheses because they abort the JCL compiling.
- All logical operators have the same priority.

You can combine the logical operators to test almost any arrangement of tokens. You can combine the logical operators to set up default conditions and to check for missing tokens, as the following examples demonstrate.

```

, CHECK/JCL          , CHECK1/JCL
//IF -S              //IF -S+-D
//ASSIGN S=0         //, You MUST enter S and D!
//END                //QUIT
//IF -D              //END
//ASSIGN D=2
//END

```

The CHECK example tests S and D individually, and assigns them default values if they were not true (that is, if they were not specified in the DO command line).

The CHECK1 example is structured so that both S and D must be true (specified on the DO command line), or the JCL compiling aborts.

Using Nested //IF Macros

By definition, a conditional block begins with an //IF and concludes with an //END.

When the //IF evaluates true, the lines between the //IF and the //END or an //ELSE (if one exists) are compiled. It is also possible to include other //IF - //END blocks within the main conditional block (called nesting).

The //ELSE macro provides an alternative course of action in case an //IF evaluates false. It is also possible to have more //IF - //END statements following the //ELSE. Refer to the following examples:

```

, TEST/JCL
//IF A
, comment 1
//ELSE
//IF B
, comment 2
//END      (ends the //IF B statement)
//END      (ends the //IF A statement)

```

If A evaluates true, comment 1 is written out, and the //ELSE is ignored. If A is false, B is tested. The comment 2 is written out only if B is true. Notice the two //END macros. There must be one //END for every //IF.

You can document your own JCL files in the same way that we have documented these examples.

Documenting //END macros increases the readability of the files, especially when you edit a file that you have created some weeks (or months) previously.

```

//IF A
. Comment A
//IF B
. Comment B
//IF C
. Comment C
//END          (ends Third IF)
//END          (ends Second IF)
. Comment D
//END          (ends First IF)

```

If the first //IF is false, all lines up to the corresponding //END are ignored.

If the first //IF is true, Comment A and Comment D are written to SYSTEM/JCL.

If //IF B is true, Comment B is also written to SYSTEM/JCL. If B is false, all lines up to the corresponding //END are ignored.

The only time //IF C is considered is if both A and B test true. If C is true, Comments A through D are written to SYSTEM/JCL.

Although not shown in the example, you can use the logical operators when nesting //IFs.

Using Nested //INCLUDE Macros

When you use the //INCLUDE macro, the included file can also contain another //INCLUDE macro. This is called nesting. The following rules apply:

- The maximum nest level is five active //INCLUDE macros.
- An //INCLUDE macro cannot be the last line in a JCL file.

Example

The following example uses three files to show how the lines in nested //INCLUDE files are processed:

```

//. NEST0/JCL
. nested Procedure example (Nest 0)
//INCLUDE nest1
. this is the end of the Primary JCL (Nest 0)
//EXIT

//. NEST1/JCL
. this is the first nest (Nest 1)
//INCLUDE nest2
. this is the end of the first nest (Nest 1)

//. NEST2/JCL
. this is the second nest (Nest 2)

```

If you save these JCL files as NEST0/JCL, NEST1/JCL, and NEST2/JCL and then compile and execute NEST0/JCL, the following SYSTEM/JCL results:

```
//. NEST0/JCL
//. NEST1/JCL
//. NEST2/JCL
. nested procedure example (Nest 0)
. this is the first nest (Nest 1)
. this is the second nest (Nest 2)
. this is the end of the first nest (Nest 1)
. this is the end of the primary JCL (Nest 0)
```

The //INCLUDE macro can be used to compile a large JCL procedure from a series of smaller JCL routines. If the finished SYSTEM/JCL file is a procedure that will be executed many times, you can easily save it by copying SYSTEM/JCL to a file with another name.

Using the Special % Symbol

The % symbol is used to pass character values (in hex) to the system as though they came from the keyboard. The syntax is:

%character value

Below are some valid values and their results:

Hex Value	Result
09	Position to next tab stop (every 8 columns)
0A	Linefeed
1F	Clear screen

The value of any printable character can also be used, although control characters (characters with a value less than hex 20) are generally used. (See Appendix C for a list of characters, values, and actions performed on the video display.)

Examples

You should place the clear screen character at the start of a line. For example:

```
%1F//PAUSE Insert disk in drive 1, Press ENTER
```

clears the screen and displays the JCL line in the top left corner of the screen.

The tab and linefeed characters, used to position comments or lines on the screen, should always be placed AFTER the period in the comment line or the macro in an executable line. For example:

```
.%09%09 This comment is positioned at the
second tab stop.
//PAUSE %0A%0A%0A This line appears 3 lines down
```

If you place the character BEFORE the period, TRSDOS does not recognize it as a comment line and the JCL aborts.

If you place the character AFTER the macro, the //PAUSE is displayed and the remaining message line is displayed 3 lines lower on the screen.

Using the tab and linefeed characters in this manner can sometimes help to improve the readability of the messages displayed during JCL execution.

Using TRSDOS JCL To Interface With Applications Programs

This appendix describes how to use JCL to start up and control your applications programs.

Two languages are discussed: BASIC and Z-80 assembly.

Interfacing With BASIC

A JCL file is the perfect method to interface between the operating system and the BASIC language. JCL can be used to create procedures that require only the inserting of a diskette to start up a program. Additionally, you can utilize the features of JCL from within a BASIC program.

Examples

To use a JCL file to initiate an automatic start-up of a BASIC program, you can use the AUTO library command to execute a JCL file.

Assuming the JCL file is named BAS/JCL, issuing the command:

```
AUTO DD BAS/JCL (ENTER)
```

automatically executes the desired BASIC program every time the computer is booted with the AUTOed system disk.

In order to execute a BASIC program from a JCL file, lay out the JCL file as follows:

1. Establish any necessary drivers, filters, or other TRSDOS options.
2. Enter BASIC with any necessary parameters (such as memory size and number of files).
3. RUN the BASIC program.

-
4. Terminate the JCL execution with //STOP (which leaves control with BASIC).

You can also enter a DO command directly from the TRSDOS Ready prompt to execute a BASIC program.

To execute a JCL file once you have entered BASIC, the command format is:

```
SYSTEM"DO filename"
```

This command can be typed in directly or entered as a BASIC program line.

Also, any JCL file called from BASIC should contain the //EXIT termination macro, so that control will return to TRSDOS Ready when the JCL file is completed.

For example, suppose you want to use the JCL //ALERT macro to inform you when a lengthy BASIC procedure has completed. Following the lines containing the BASIC procedure, you could have a BASIC program line such as:

```
1000 SYSTEM "DO = ALERT/JCL:0"
```

which executes the ALERT/JCL file:

```
. Your procedure is complete. Press (ENTER) to  
resume.  
//ALERT (1,0,7,0)  
BASIC  
//STOP
```

When BASIC reaches line 1000, the JCL file ALERT/JCL is executed, sending a series of repeating tones out the tone generator.

You are notified that your BASIC procedure has completed. Pressing (ENTER) ends the JCL alert and returns you to BASIC.

There are two important points about this example. First, the comment line in the ALERT/JCL file is absolutely necessary, as a JCL file cannot start with an execution macro. Second, the "BASIC" statement will reload BASIC. If you want a particular program to be loaded and run, you can place its name on the command line or add the BASIC commands before the //STOP statement. The //STOP termination macro must be included to assure that keyboard control remains within BASIC.

Although the example demonstrates an execute only JCL file, you can also call compiled JCL procedures from BASIC. You can even construct a SYSTEM "DO filespec [(parameters)]" command using BASIC string substitution.

Any time you want to use a SYSTEM "DO filespec" command from BASIC to execute another BASIC program, you have to change the format of the command. To DO these types of JCL files from BASIC, use the commands:

```
SYSTEM (ENTER)
DO filespec [(parameters)] (ENTER)
```

Using this format for the command assures that a proper exit is made before the new JCL file is started.

Controlling a BASIC program

In some cases, the prompts in a BASIC program can be answered with a line from a JCL file. This is true if the program uses the INPUT or LINEINPUT BASIC statement to take the input.

If the program uses the INKEY\$ statement, response has to come from the keyboard rather than from a JCL file. If the program uses the proper input method, you can create a JCL for total hands-off operation as follows:

1. Run through the BASIC program, making a note of every prompt to be answered.
2. Create a JCL file to enter BASIC and run the program as explained above in the BAS/JCL example. Leave off the //STOP macro.
3. Add the responses to the prompts as lines in the JCL file.

Using this method provides automatic program execution. Terminating the JCL file depends on what needs to be done when the application program has completed.

If you want to run more programs, you could add the proper RUN"PROGRAM" line to the JCL file, followed by any required responses to program prompts.

If you want to return to the TRSDOS Ready mode, you could end the file with the //EXIT macro. If you want to return to the BASIC Ready mode, you could end the file with the //STOP macro.

Interfacing With Z-80 ASSEMBLY

It is very simple to interface an assembly language program with the DO processor. All programs that utilize the line input handler (identified as the @KEYIN supervisor call the "Technical Information" manual) are able to accept "keyboard" input from the JCL file, just as though you typed it in when the program ran.

This gives the capability of pre-arranging the responses to a program's requests for input, inserting the responses into the JCL file, initiating the procedure, then walking away from the machine while it goes about its business of running the entire job.

Keyboard input normally handled by the single-entry keyboard routines (@KBD, @KEY, and BASIC's INKEY\$) continue to be requested from the keyboard at program run time and do not utilize the JCL file data for input requests.

Practical Examples Of TRSDOS JCL Files

It is virtually impossible to show all the many uses of JCL files.

We give you two examples of how you can make your day-to-day TRSDOS operations even more efficient using JCL files.

1)

This example shows how to SYSRES system modules using a JCL file. The modules to be resided are 2, 3, and 10. These modules have to be resident in memory to perform a backup by class between two non-system diskettes in a two-drive system.

The JCL file to SYSRES these modules may look something like this:

```
. BURES/JCL - JCL used to SYSRES modules 2, 3,
and 10
SYSTEM (SYSRES=2
SYSTEM (SYSRES=3
SYSTEM (SYSRES=10
. end of BURES/JCL
```

When executed, this JCL file causes the system modules 2, 3, and 10 to be resided in high memory. Because this JCL uses no labels or compilation macros, the compilation phase can be skipped.

2)

This example shows how to back up a diskette using a JCL file.

A minimum of three drives are required. Drive 0 must contain a system diskette with the JCL file. Drive 1 contains the source diskette. Assume that the source diskette's name is MYDISK and its master password is PASSWORD. Also, assume that it is 40 track, and double density. Drive 2 contains the destination diskette.

The JCL file to perform the backup may look something like this:

```
. DUPDISK/JCL - Disk duplication JCL
//PAUSE Source in 1, Dest. in 2, ENTER when
ready
format :2 (name="mydisk",q=n,abs)
//PAUSE format ok? ENTER if yes, BREAK if no
backup :1 :2
. end of backup - will now restart JCL
do *
```

The second line of the JCL causes the computer to pause until the **ENTER** key is pressed. This allows you to insert the proper diskette into Drives 1 and 2. Once you insert the proper diskettes, press **ENTER** and the third line of the JCL is executed.

The format line passes the NAME parameter to the format utility. Note that the diskette name, and diskette password of the destination

diskette must be an exact match of the source disk. If they do not exactly match, the JCL aborts.

Also, note that the parameters Q=N and ABS are specified. Both are necessary. The Q=N parameter causes the computer to use the default of PASSWORD for the master password, by passing the "Master Password" prompt. The ABS parameter ensures that no prompt appears if the destination diskette contains data.

The pause after the format statement allows you to check whether or not the format is successful. If the destination diskette is properly formatted, press **(ENTER)** to continue the JCL.

After you press **(ENTER)** in response to the seconds pause, the backup takes place. When the backup completes, the comment line appears, and the DO * command executes. The command causes the SYSTEM/JCL file to execute. Realize that since this is a repeating JCL, the compilation phase cannot be skipped.

If tracks are locked out during the format, press **(BREAK)**. Pressing **(BREAK)** aborts the JCL, and you have to restart the JCL file.

Important: Be aware that if BACKUP or FORMAT is being executed by a JCL file, the following rules apply:

1. If the backup is mirror image, the source and destination disk Disk ID's must be the same or the backup aborts.
2. Backups with the (X) parameter, single-drive backups, and backups with the (QUERY) parameter are not allowed.
3. Single-drive formats are not allowed.

Appendix B/ Model 4/4P Hardware

The Keyboard Code Map

The keyboard code map shows the code that TRSDOS returns for each key, in each of the modes: control, shift, unshift, clear and control, clear and shift, clear and unshift.

For example, pressing **CLEAR**, **SHIFT**, and **1** at the same time returns the code X'A1'.

A program executing under TRSDOS — for example, BASIC — may translate some of these codes into other values. Consult the program's documentation for details.

BREAK Key Handling

The **BREAK** key (X'80') is handled in different ways, depending on the settings of three system functions. The table below shows what happens for each combination of settings.

Break Enabled	Break Vector Set	Type-Ahead Enabled	
Y	N	Y	If characters are in the type-ahead buffer, then the buffer is emptied. * If the type-ahead buffer is empty, then a BREAK character (X'80') is placed in the buffer. *
Y	N	N	A BREAK character (X'80') is placed in the buffer.
Y	Y	Y	The type-ahead buffer is emptied of its contents (if any), and control is transferred to the address in the BREAK vector (see @BREAK SVC). *
Y	Y	N	Control is transferred to the address in the BREAK vector (see @BREAK SVC).
N	X	X	No action is taken and characters in the type-ahead buffer are not affected.

Y means that the function is on or enabled
N means that the function is off or disabled
X means that the state of the function has no effect

Break is enabled with the SYSTEM (BREAK = ON) command (this is the default condition).

The break vector is set using the @BREAK SVC (normally off).

Type-ahead is enabled using the SYSTEM (TYPE = ON) command (this is the default condition).

* Because the **BREAK** key is checked for more frequently than other keys on the keyboard, it is possible for **BREAK** to be pressed after another key on the keyboard and yet be detected first.

B1	31	B2	32	B3	33	B4	34	B5	35	B6	36	B7	37	B8	38	B9	39	B0	30	BA	††	AD	2D	80	80	
	!	"	#	\$	%	&	'	()	+	*	=	B	R	†††											
A1	1	A2	2	A3	3	A4	4	A5	5	A6	6	A7	7	A8	8	A9	9	A0	0	AA	:	2A	BD	—	3D	80
B1	31	B2	32	B3	33	B4	34	B5	35	B6	36	B7	37	B8	38	B9	39	B0	30	BA	3A	AD	2D	80	K	

8B	0B	91	11	97	17	85	05	92	12	94	14	99	19	95	15	89	09	8F	0F	90	10	0	0	88	08	89	09			
↑	1B	F1	Q	51	F7	57	E5	F2	52	F4	54	F9	59	F5	55	E9	I	49	EF	0	50	E0	@	60	98	←	18	99	→	19
9B	0B	D1	71	D7	77	C5	65	D2	72	D4	74	D9	79	D5	75	C9	69	CF	6F	D0	70	C0	40	88	08	89	09			
8B	0A	81	01	93	13	84	04	86	06	87	07	88	08	8A	0A	8B	0B	8C	0C	1E	8D	1E	8D	1E	8D	1E	8D	1E	8D	1E
9A	↓	1A	A	E1	F3	53	E4	44	E6	46	E7	47	E8	EA	4A	EB	K	4B	EC	AC	7E	2B	7F	5F	0D	1D	0D	1D	0D	
8A	0A	C1	61	D3	73	C4	64	C6	66	C7	67	C8	68	CA	6A	CB	6B	CC	6C	5E	3B	5F	0D	1D	0D	1D	0D	1D	0D	

SHIFT	Z	5A	F8	X	58	E3	C	43	F6	V	56	E2	B	42	EE	N	4E	ED	M	4D	7B	<	3C	7D	.	3E	7C	/	3F
	DA	7A	D8		78	C3		63	D6		76	C2		62	CE		6E	CD		6D	5B	,	2C	5D		2E	5C		2F

C	T	R	L	A0	A0	A0
C	A	P	S	20	20	20

LEGEND:

Clear and Control

Clear and Left Shift
Clear and Unshift

•	•	Control
•	•	Shift
•	•	Unshift

Note: Pressing CONTROL, SHIFT, and

@ at the same time generates an EOF (end of file) — 'X'1C' with NZ return flag.

Whenever pressing CLEAR, SHIFT, and another key at the same time, be sure to use the left SHIFT key — not the right SH key.

+ Pressing SHIFT and 0 at the same time (or CAPS alone) turns the CAPS mode on or off.

++ Pressing CONTROL and : at the same time causes a screen print.

+++ Pressing SHIFT and BREAK at the same time deselects the last drive.

Codes for these keys are the same as for the main keyboard.

81	81	82	82	83	83
91	F1	91	92	F2	92
81	81	82	82	83	83
7	7	8	9	9	9
4	4	5	6	6	6
1	1	2	3	3	3
0	0	•	ENT	ENT	ENT

Specifications

Model 4

The Radio Shack TRS-80 Model 4 is a ROM/disk-based computer system with one major part:

- A display console/keyboard unit with one or two built-in, single-sided, double-density, floppy disk drives (disk system) or zero disk drives (cassette system)

The operating system software is loaded from ROM or an operating system disk in Drive 0 by a built-in read-only memory (ROM) "bootstrap" program.

Model 4P

The Radio Shack TRS-80 Model 4P is a disk-based computer system with one major part:

- A display console/keyboard unit with two built-in, single-sided, double-density, floppy disk drives

The operating system software is loaded from an operating system disk in Drive 0 by a built-in read-only memory (ROM) "bootstrap" program.

Console

Processor

Model 4

- The TRS-80 Model 4 is a Z-80A based high-speed microprocessor with 64K or optional 128K of memory (disk system) or 16K of memory (cassette system)
- The processor receives power-up and reset instructions from ROM.
- The Model 4 is compatible with existing Model III software.

Model 4P

- The TRS-80 Model 4P is a Z-80A based high-speed microprocessor with 64K or optional 128K of memory
- The processor receives power-up and reset instructions from ROM
- The Model 4P is compatible with existing Model III disk software.

Sound

The disk system can generate software-controlled tones, one at a time.

Video Display

Six Modes

- White on black (normal)
- Black on white (reversed)
- 64 characters by 16 lines Model III Mode
- 32 characters by 16 lines Model III Mode
- 80 characters by 24 lines Model 4 Mode
- 40 characters by 24 lines Model 4 Mode

Displayable Characters

- Full ASCII set
- 64 graphics characters

Keyboard

The keyboard has the standard typewriter keys, numeric keypad, and three function keys.

Three Modes

- Control
- Shift
- Caps

Floppy Disk Drives

Minimum

Model 4 : One built-in 5-1/4-inch, single-sided floppy drive (disk system) or zero drives (cassette system)

Model 4P: Two built-in 5-1/4-inch, single-sided floppy drives

Maximum

Model 4 : Two built-in and two external 5-1/4-inch, single-sided floppy drives

Model 4P: Two built-in 5-1/4-inch, single-sided floppy drives

Preventive Maintenance Interval

- Typical usage (3,000 power-on hours per year): Every 8,000 power-on hours
- Heavy usage (8,000 power-on hours per year): Every 5,000 power-on hours

Required Media

- Radio Shack single-sided, 5-1/4-inch floppy disks

The Data Transfer Rate is 250K bits per second.

Power Supply

Power Requirements

- 105-130 VAC, 60 Hz
- 240 VAC, 50 Hz (Australian)
- 220 VAC, 50 Hz (European)
- Grounded outlet

Maximum Current Drain

- 1.7 Amps

Typical Current Drain

- 1.5 Amps

Operating Temperature

- 55 to 80 degrees Fahrenheit
- 13 to 27 degrees Centigrade

Peripheral Interfaces

Standard

- Floppy disk input/output channel for connection of one or two external floppy disk drives (Model 4 only)
- I/O bus for connection of hard disk and other peripherals
- Cassette I/O jack (Model 4 only)

Optional

- High-resolution graphics board
- Serial port RS-232C
- Auto answer modem (Model 4P only)

Serial Interface

One Port:

- Allows asynchronous or synchronous transmission
- Conforms to the RS-232C standard
- Uses the DB-25 connector on the bottom of the Model 4 display console and on the back of the Model 4P

The DB-25 connector pin-outs and signals available are listed below:

Signal	Function	Pin#
PGND	Protective Ground	1
TD	Transmit Data	2
RD	Receive Data	3
RTS	Request to Send	4
CTS	Clear to Send	5
DSR	Data Set Ready	6
SGND	Signal Ground	7
CD	Carrier Detect	8
DTR	Data Terminal Ready	20
RI	Ring Indicator	22
STD†	Secondary Transmit Data (Model 4 only)	14
SUN†	Secondary Unassigned (Model 4 only)	18
SRTS†	Secondary Request to Send	19

† These signals are not used for secondary functions but are reserved for future use.

Parallel Interface

- Connection to a line printer via the 34-pin connector on the bottom of the Model 4 display console and on the back of the Model 4P.
- Eight data bits are output in parallel
- Eight data bits are input
- All levels are TTL compatible

The parallel printer pin-outs and signals available are listed below.

NOTE: If a signal name contains an asterisk (*), the signal is active-low.

Signal	Function	Pin #
STROBE*	1.5 microseconds pulse to clock the data from processor to printer	1
DATA 0	Bit 0 (lsb) of output data byte	3
DATA 1	Bit 1 of output data byte	5
DATA 2	Bit 2 of output data byte	7
DATA 3	Bit 3 of output data byte	9
DATA 4	Bit 4 of output data byte	11
DATA 5	Bit 5 of output data byte	13
DATA 6	Bit 6 of output data byte	15
DATA 7	Bit 7 (msb) of output data byte	17
BUSY	Input to computer from printer, high indicates busy	21
PAPER EMPTY	Input to computer from printer, high indicates no paper — If the printer doesn't provide this, the signal is forced low	23
BUSY* †	Inverse of BUSY (Pin 2)	25
FAULT*	Input to computer from printer, low indicates fault (paper empty, ribbon out, printer off-line, and so on)	28
GROUND	Common signal ground	2,4,6,8,10 12,14,16, 18,20,22, 24,27,31, 33
NC	Not connected or not used	19,26,29, 30,32,34

† Depending on the kind of printer used, this signal may be called "UNIT SELECT." See your printer manual for more information.

Communications

For hardwiring two Model 4/4P's without a modem, use Radio Shack's RS-232C cables (cat. no. 26-1490, -1491, -1492, -1493) and null modem adapter (cat. no. 26-1496).

Appendix C/ Character Codes

Text, control functions, and graphics are represented in the computer by codes. The character codes range from zero through 255.

Code 0 is a prefix code. It tells the video driver to display the special character for codes 1 - 31. These codes are normally treated as cursor control commands.

Codes 1 through 31 normally represent certain control functions. For example, code 13 represents a carriage return or "end of line." These same codes also represent special display characters. To display the special character that corresponds to a particular code (1 - 31), precede the code with a code zero. (Note: Some screen control characters cannot be entered from the TRSDOS Ready or BASIC Ready prompts, but can be directed to the screen by program control. See the CHR\$ and ASC functions in the BASIC portion of this manual.)

Codes 32 through 127 represent the text characters — all those letters, numbers, and other characters that are commonly used to represent textual information.

Codes 128 through 191, when output to the video display, represent 64 graphics characters.

Codes 192 through 255, when output to the video display, represent either space compression codes or special or alternate characters, as determined by software. Toggling between these modes is done via codes 21 and 22.

Code 21 toggles the video driver between space compression codes and the special/alternate character set. Code 22 toggles the video driver between the special character set and the alternate character set. The setting of the toggle controlled by code 21 determines if the code 22 toggle will have any effect on what is subsequently displayed.

The following chart illustrates the power-up and first toggle states for codes 21 and 22:

	Code 21	Code 22
Power-up state	space compression characters	special characters
First toggle state	special/alternate characters	alternate characters





At power-up, codes in the range 192 to 255 will produce one or more spaces (space compression mode). From this point, you can enter the special character set by outputting a code 21 to the display. You can then enter the alternate character set by outputting a code 22 to the display. To switch back to the special set, output another code 22. To switch back to space compression codes from either the special or alternate character set, output a code 21.

When you are in space compression mode, outputting a code 22 still toggles between special and alternate character sets, even though it does not affect the characters subsequently displayed. Any characters in the range 192-255 that are already on the display will toggle between special and alternate character sets each time a code 22 is received.

Note: Special and alternate characters are not available if reverse video (code 16) is enabled.

ASCII Character Set

Code		ASCII		Video Display
Dec.	Hex.	Abbrev.	Keyboard	
0	00	NUL	CTRL @	Next character is treated as displayable; if in the range 1 - 31, a special character is displayed (see list of special characters later in this Appendix)
1	01	SOH	CTRL A	
2	02	STX	CTRL B	
3	03	ETX	CTRL C	
4	04	EOT	CTRL D	
5	05	ENQ	CTRL E	
6	06	ACK	CTRL F	
7	07	BEL	CTRL G	
8	08	BS	Left Arrow CTRL H	Backspace and erase
9	09	HT	Right Arrow CTRL I	Move cursor to the next tab stop (located every 8 columns)
10	0A	LF	Down Arrow CTRL J	Move cursor to start of next line
11	0B	VT	Up Arrow CTRL K	
12	0C	FF	CTRL L	
13	0D	CR	ENTER CTRL M	Move cursor to start of next line
14	0E	SO	CTRL N	Cursor on
15	0F	SI	CTRL O	Cursor off

Code		ASCII			
Dec.	Hex.	Abbrev.	Keyboard		Video Display
16	10	DLE	CTRL P	Enable reverse video and set high bit routine on*	
17	11	DC1	CTRL Q	Set high bit routine off*	
18	12	DC2	CTRL R		
19	13	DC3	CTRL S		
20	14	DC4	CTRL T		
21	15	NAK	CTRL U	Swap space compression/ special characters	
22	16	SYN	CTRL V	Swap special/alternate characters	
23	17	ETB	CTRL W	Set to 40 characters per line	
24	18	CAN	SHIFT  CTRL X	Backspace without erasing	
25	19	EM	SHIFT  CTRL Y	Advance cursor	
26	1A	SUB	SHIFT  CTRL Z	Move cursor down	
27	1B	ESC	SHIFT  CTRL ,	Move cursor up	
28	1C	FS	CTRL /	Move cursor to upper left corner. Disable reverse video and set high bit routine off.* Set to 80 characters per line.	
29	1D	GS	CTRL ENTER	Erase line and start over	
30	1E	RS	CTRL ;	Erase to end of line	
31	1F	VS	SHIFT CLEAR	Erase to end of display	
32	20	SPA	SPACE BAR	(blank)	
33	21		!	!	
34	22		"	"	
35	23		#	#	
36	24		\$	\$	

* When the high bit routine is on, characters 20 - 127 are converted to characters 148 - 255. When reverse video is enabled, characters 128 - 191 are displayed as standard ASCII characters in reverse video.

Code		Keyboard	Video Display
Dec.	Hex.		
37	25	%	%
38	26	&	&
39	27	,	,
40	28	((
41	29))
42	2A	*	*
43	2B	+	+
44	2C	,	,
45	2D	-	-
46	2E	.	.
47	2F	/	/
48	30	0	0
49	31	1	1
50	32	2	2
51	33	3	3
52	34	4	4
53	35	5	5
54	36	6	6
55	37	7	7
56	38	8	8
57	39	9	9
58	3A	:	:
59	3B	;	;
60	3C	<	<
61	3D	=	=
62	3E	>	>
63	3F	?	?
64	40	@	@
65	41	*A	A

* A - Z (codes 65 - 90) are shifted functions. Hold down **SHIFT** and then press the desired key.

Code		Keyboard	Video Display
Dec.	Hex.		
66	42	B	B
67	43	C	C
68	44	D	D
69	45	E	E
70	46	F	F
71	47	G	G
72	48	H	H
73	49	I	I
74	4A	J	J
75	4B	K	K
76	4C	L	L
77	4D	M	M
78	4E	N	N
79	4F	O	O
80	50	P	P
81	51	Q	Q
82	52	R	R
83	53	S	S
84	54	T	T
85	55	U	U
86	56	V	V
87	57	W	W
88	58	X	X
89	59	Y	Y
90	5A	Z	Z
91	5B	CLEAR ,	[
92	5C	CLEAR /	\
93	5D	CLEAR .]
94	5E	CLEAR ;	^
95	5F	CLEAR ENTER	—
96	60	SHIFT @	'

Code		ASCII	Keyboard	Video Display
Dec.	Hex.	Abbrev.		
97	61		A	a
98	62		B	b
99	63		C	c
00	64		D	d
101	65		E	e
102	66		F	f
103	67		G	g
104	68		H	h
105	69		I	i
106	6A		J	j
107	6B		K	k
108	6C		L	l
109	6D		M	m
110	6E		N	n
111	6F		O	o
112	70		P	p
113	71		Q	q
114	72		R	r
115	73		S	s
116	74		T	t
117	75		U	u
118	76		V	v
119	77		W	w
120	78		X	x
121	79		Y	y
122	7A		Z	z
123	7B		CLEAR SHIFT ,	{
124	7C		CLEAR SHIFT /	
125	7D		CLEAR SHIFT .	}
126	7E		CLEAR SHIFT ;	~
127	7F	DEL	CLEAR SHIFT ENTER	±

Extended (non-ASCII) Character Set

Code		ASCII	Video Display
Dec.	Hex.	Keyboard	
128	80	BREAK	See Special Character Table
129	81	CLEAR CTRL A F1	"
130	82	CLEAR CTRL B F2	"
131	83	CLEAR CTRL C F3	"
132	84	CLEAR CTRL D	"
133	85	CLEAR CTRL E	"
134	86	CLEAR CTRL F	"
135	87	CLEAR CTRL G	"
136	88	CLEAR CTRL H	"
137	89	CLEAR CTRL I	"
138	8A	CLEAR CTRL J	"
139	8B	CLEAR CTRL K	"
140	8C	CLEAR CTRL L	"
141	8D	CLEAR CTRL M	"
142	8E	CLEAR CTRL N	"
143	8F	CLEAR CTRL O	"
144	90	CLEAR CTRL P	"
145	91	CLEAR CTRL Q SHIFT F1	"
146	92	CLEAR CTRL R SHIFT F2	"
147	93	CLEAR CTRL S SHIFT F3	"
148	94	CLEAR CTRL T	"
149	95	CLEAR CTRL U	"
150	96	CLEAR CTRL V	"
151	97	CLEAR CTRL W	"
152	98	CLEAR CTRL X	"

Code		ASCII	Video Display
Dec.	Hex.	Keyboard	
153	99	CLEAR CTRL Y	See Special Character Table
154	9A	CLEAR CTRL Z	"
155	9B	CLEAR SHIFT up arrow	"
156	9C		"
157	9D		"
158	9E		"
159	9F		"
160	A0	CLEAR SPACE	"
161	A1	CLEAR SHIFT 1	"
162	A2	CLEAR SHIFT 2	"
163	A3	CLEAR SHIFT 3	"
164	A4	CLEAR SHIFT 4	"
165	A5	CLEAR SHIFT 5	"
166	A6	CLEAR SHIFT 6	"
167	A7	CLEAR SHIFT 7	"
168	A8	CLEAR SHIFT 8	"
169	A9	CLEAR SHIFT 9	"
170	AA	CLEAR SHIFT :	"
171	AB		"
172	AC		"
173	AD	CLEAR -	"
174	AE		"
175	AF		"
176	B0	CLEAR 0	"
177	B1	CLEAR 1	"
178	B2	CLEAR 2	"
179	B3	CLEAR 3	"
180	B4	CLEAR 4	"
181	B5	CLEAR 5	"
182	B6	CLEAR 6	"

Code Dec.	ASCII		Video Display
	Hex.	Keyboard	
183	B7	CLEAR 7	See Special Character Table
184	B8	CLEAR 8	"
185	B9	CLEAR 9	"
186	BA	CLEAR :	"
187	BB		"
188	BC		"
189	BD	CLEAR SHIFT -	"
190	BE		"
191	BF		"
192	C0	CLEAR @ *	"
193	C1	CLEAR A **	"
194	C2	CLEAR B **	"
195	C3	CLEAR C **	"
196	C4	CLEAR D **	"
197	C5	CLEAR E **	"
198	C6	CLEAR F **	"
199	C7	CLEAR G **	"
200	C8	CLEAR H **	"
201	C9	CLEAR I **	"
202	CA	CLEAR J **	"
203	CB	CLEAR K **	"
204	CC	CLEAR L **	"
205	CD	CLEAR M **	"
206	CE	CLEAR N **	"
207	CF	CLEAR O **	"
208	D0	CLEAR P **	"
209	D1	CLEAR Q **	"
210	D2	CLEAR R **	"

* Empties the type-ahead buffer.

** Used by Keystroke Multiply, if KSM is active.

































































Code		ASCII	Video Display
Dec.	Hex.	Keyboard	
211	D3	CLEAR S **	See Special Character Table
212	D4	CLEAR T **	"
213	D5	CLEAR U **	"
214	D6	CLEAR V **	"
215	D7	CLEAR W **	"
216	D8	CLEAR X **	"
217	D9	CLEAR Y **	"
218	DA	CLEAR Z **	"
219	DB		"
220	DC		"
221	DD		"
222	DE		"
223	DF		"
224	E0	CLEAR SHIFT @	"
225	E1	CLEAR SHIFT A	"
226	E2	CLEAR SHIFT B	"
227	E3	CLEAR SHIFT C	"
228	E4	CLEAR SHIFT D	"

** Used by Keystroke Multiply, if KSM is active.


Code Dec.	Hex.	ASCII Keyboard	Video Display
229	E5	CLEAR SHIFT E	See Special Character Table
230	E6	CLEAR SHIFT F	"
231	E7	CLEAR SHIFT G	"
232	E8	CLEAR SHIFT H	"
233	E9	CLEAR SHIFT I	"
234	EA	CLEAR SHIFT J	"
235	EB	CLEAR SHIFT K	"
236	EC	CLEAR SHIFT L	"
237	ED	CLEAR SHIFT M	"
238	EE	CLEAR SHIFT N	"
239	EF	CLEAR SHIFT O	"
240	F0	CLEAR SHIFT P	"
241	F1	CLEAR SHIFT Q	"
242	F2	CLEAR SHIFT R	"
243	F3	CLEAR SHIFT S	"
244	F4	CLEAR SHIFT T	"
245	F5	CLEAR SHIFT U	"
246	F6	CLEAR SHIFT V	"
247	F7	CLEAR SHIFT W	"

Code		ASCII Keyboard	Video Display
Dec.	Hex.		
248	F8	CLEAR SHIFT X	See Special Character Table
249	F9	CLEAR SHIFT Y	"
250	FA	CLEAR SHIFT Z	"
251	FB		"
252	FC		"
253	FD		"
254	FE		"
255	FF		"


Graphics Characters (Codes 128-191)

	128		136		144		152		160		168		176		184
	129		137		145		153		161		169		177		185
	130		138		146		154		162		170		178		186
	131		139		147		155		163		171		179		187
	132		140		148		156		164		172		180		188
	133		141		149		157		165		173		181		189
	134		142		150		158		166		174		182		190
	135		143		151		159		167		175		183		191


Special Characters (0-31, 192-255)




0 1 2 3 4 5 6 7



8 9 10 11 12 13 14 15




16 17 18 19 20 21 22 23




24 25 26 27 28 29 30 31




192 193 194 195 196 197 198 199




200 201 202 203 204 205 206 207




208 209 210 211 212 213 214 215




216 217 218 219 220 221 222 223




224 225 226 227 228 229 230 231



232 233 234 235 236 237 238 239



240 241 242 243 244 245 246 247



248 249 250 251 252 253 254 255

Appendix D/ Error Messages and Problems

In Case Of Difficulty

Your TRSDOS operating system was designed and tested to provide you with trouble-free operation. If you do experience problems, there is a good chance that something other than the TRSDOS system is at fault. This section discusses some of the most common user problems, and suggests general cures for these problems.

Problem 1 . . . The system seems to access the wrong disk drives, or cannot read the diskettes.

If you have trouble reading Model I and III TRSDOS diskettes, refer to the REPAIR and CONV Utilities. Those sections explain how to make these types of disks readable.

If your system seems to access the wrong disk, reset your computer. You may have selected some combination of options that are preventing the system from functioning properly.

Remember that when you specify a drive number, you are specifying a logical drive number which, based on your system's configuration, may point at drives in another order. If you have SYSGENed these settings, you will have to hold **CLEAR** down while you reset your computer.

Problem 2 . . . RS-232C communications do not work, or function incorrectly.

If you experience RS-232C problems, the first thing you should do is to make sure both "ends" are operating with the same RS-232C parameters (baud rate, word length, stop bits, and parity). If these parameters are not the same at each end, the data sent and received appears scrambled.

Some hardware, such as serial printers, require "handshaking" when running above a certain baud rate. It may be necessary to hook the hardware's handshake line (such as the BUSY line) to an appropriate RS-232C lead, such as CTS.

Problem 3 . . . Random system crashes, recurring disk I/O errors, system lock-up, and other random glitches keep happening.

If you encounter these types of problems, the first thing to check is the cable connections between the TRS-80 and the peripherals.

If you experience constant difficulty in disk read/write operations, it is possible that the disk drive heads need cleaning. There are kits available from Radio Shack to clean disk heads, or you may wish to have the disk drive serviced at a repair facility. If you need to frequently clean the disk heads, you might be using some defective disk media. Check the diskettes for any obvious signs of flaking or excess wear, and dispose of any that appear

even marginal. Tobacco smoke and other airborne contaminants can build up on disk heads, and can cause read/write problems. Disk drives in "dirty" locations may need to have their heads cleaned as often as once a week.

One common and often overlooked cause of random-type problems is static electricity. In areas of low humidity, static electricity is present, even if actual static discharges are not felt by the computer operator. Be aware that static discharges can cause system glitches, as well as physically damage computer hardware and disk media.

Error Messages

If the computer displays one of the messages listed in this appendix, an operating system error occurred. Any other error message refers to an application program error, and you should see your application program manual for an explanation.

When an error message is displayed:

- Try the operation several times.
- Look up operating system errors below and take any recommended actions. (See your application program manual for explanations of application program errors.)
- Try using other diskettes.
- Reset the computer and try the operation again.
- Check all the power connections.
- Check all interconnections.
- Remove all diskettes from drives, turn off the computer, wait 15 seconds, and turn it on again.
- If you try all these remedies and still get an error message, contact a Radio Shack Service Center.

NOTE: If there is more than one thing wrong, the computer might wait until you correct the first error before displaying the second error message.

This list of error messages is alphabetical, with the decimal and hexadecimal error numbers in parentheses. Following it is a quick reference list of the messages arranged in numerical order.

TRSDOS Error Messages

Attempted to read locked/deleted data record (Error 7, X'07')

Check for an error in your application program.

Attempted to read system data record (Error 6, X'06')

Check for an error in your application program.

Data record not found during read (Error 5, X'05')

Try the operation again. If it fails, use a different disk. Reformat the old disk; this should lock out the flaw. To retrieve your files from the flawed disk, perform a backup by class (see the BACKUP command). You may have to remove the files that have errors so BACKUP will work.

Data record not found during write (Error 13, X'0D')

Try the operation again. If it still fails, use a different disk.

Device in use (Error 39, X'27')

RESET the device in use before REMOVEing it.

Device not available (Error 8, X'08')

Make sure you enter the correct device specification and that the device peripheral is ready. You can use the DEVICE (B=ON) command to display all devices available to the system.

Directory full — can't extend file (Error 30, X'1E')

All directory slots are being used. Use BACKUP to copy some of the disk's files to a newly formatted disk.

Directory read error (Error 17, X'11')

Try the operation again, using a different drive. If it fails, use a different disk. You can try to get the files off a flawed disk by doing a backup by class. If this doesn't work, you must use your backup of the disk.

Directory write error (Error 18, X'12')

The directory may no longer be reliable. If the problem recurs, use a different diskette.

Disk space full (Error 27, X'1B')

While a file was being written, all available disk space was used. The file contains only the data written before the error occurred. Write the file to a disk that has more available space. Then, REMOVE the partial copy to recover disk space.

End of file encountered (Error 28, X'1C')

You tried to read past the end of file pointer. Use the DIR command to check the size of the file. Check for an error in your application program.

Extended error (Error 63)

An error has occurred and the extended error code is in the HL register pair.

File access denied (Error 25, X'19')

You specified a password for a file that is not password protected or you specified the wrong password for a file that is password protected.

File already open (Error 41, X'29')

Use the RESET library command to close the file before trying to open it.

File not in directory (Error 24, X'18')

Check the spelling of the filespec. Use the DIR command to see if the file is on the disk.

File not open (Error 38, X'26')

Open the file before trying to access it.

GAT read error (Error 20, X'14')

Try the operation again, using a different drive. If this fails, use a backup by class to move all files to a different disk. Then, try the operation again, using the new disk.

GAT write error (Error 21X'15')

The Granule Allocation Table may no longer be reliable. If the problem recurs, try the operation again, using a different drive. If it still fails, use a different disk.

HIT read error (Error 22, X'16')

Try the operation again, using a different drive. If this still fails, use a backup by class to copy the files to a different disk.

HIT write error (Error 23, X'17')

The Hash Index Table may no longer be reliable. If the problem recurs, try the operation again, using a different drive. If it still fails, use a different disk.

Illegal access attempted to protected file (Error 37, X'25')

The USER password was given for access to a file, but the requested access required the OWNER password. (See the ATTRIB command.)

Illegal drive number (Error 32, X'20')

The specified disk drive is not included in your system or is not ready for access (no diskette, non-TRSDOS Version 6 diskette, drive door open, and so on). See the DEVICE command.

Illegal file name (Error 19, X'13')

The specified filespec does not meet TRSDOS filespec requirements. See Chapter 1 for proper filespec syntax.

Illegal logical file number (Error 16, X'10')

Your program probably has altered the File Control Block improperly. Check for an error in your application program.

Load file format error (Error 34, X'22')

An attempt was made to load a file that cannot be loaded by TRSDOS. The file was probably a data file or a BASIC program file.

Lost data during read (Error 3, X'03')

Information was not transferred in the time allotted; therefore, it was lost. Try the operation again, using a different drive. If it still fails, use a different disk.

Lost data during write (Error 11, X'0B')

Information was not transferred in the time allotted; therefore, it was lost. Try the operation again, using a different drive. If it still fails, use a different disk.

LRL open fault (Error 42, X'2A')

The logical record length specified when the file was opened is different than the LRL used when the file was created. COPY the file to another file that has the specified LRL.

No device space available (Error 33, X'21')

You tried to SET a driver or filter and all of the Device Control Blocks were in use. Use the DEVICE command to see if any non-system devices can be removed to provide more space.

No directory space available (Error 26, X'1A')

You tried to open a new file and no space was left in the directory. Use a different disk or REMOVE some files you no longer need.

No error (Error 0)

The @ERROR supervisor call was called without any error condition being detected. A return code of zero indicates no error. Check for an error in your application program.

Parity error during header read (Error 1, X'01')

Try the operation again, using a different drive. If it still fails, use a different disk.

Parity error during header write (Error 9, X'09')

Try the operation again, using a different drive. If it still fails, use a different disk.

Parity error during read (Error 4, X'04')

Try the operation again, using a different drive. If it still fails, use a different disk.

Parity error during write (Error 12, X'0C')

Try the operation again, using a different drive. If it still fails, use a different disk.

Program not found (Error 31, X'1F')

Check the spelling of the filespec (you must include the /CMD extension). If this is not the problem, make sure the disk that contains the file is loaded.

Protected system device (Error 40, X'28')

You cannot REMOVE any of the following devices: *KI, *DO, *PR, *JL, *SI, *SO.

Record number out of range (Error 29, X'1D')

Correct the record number or try the operation again, using another copy of the file.

Seek error during read (Error 2, X'02')

Try the operation again, using a different drive. If it still fails, use a different disk.

Seek error during write (Error 10, X'0A')

Try the operation again, using a different drive. If it still fails, use a different disk.

— Unknown error code

The @ERROR supervisor call was called with an error number that is not defined. Check for an error in your application program.

Write fault on disk drive (Error 14, X'0E')

Try the operation again, using a different drive. If it still fails, use a different disk. If the problem continues, contact a Radio Shack Service Center.

Write protected disk (Error 15, X'0F')

Remove the write-protect tab, if the diskette has one. If it does not, use the DEVICE command to see if the drive is set as write protected. If it is, you can use the SYSTEM command with the (WP=OFF) parameter to write enable the drive. If the problem recurs, check the drive connections on the external drives, even if the error is occurring on an internal drive. Or, use a different drive or diskette.

TRSDOS ERROR MESSAGES

Decimal	Hex	Message
0	X'00'	No Error
1	X'01'	Parity error during header read
2	X'02'	Seek error during read
3	X'03'	Lost data during read
4	X'04'	Parity error during read
5	X'05'	Data record not found during read
6	X'06'	Attempted to read system data record
7	X'07'	Attempted to read locked/deleted data record
8	X'08'	Device not available
9	X'09'	Parity error during header write
10	X'0A'	Seek error during write
11	X'0B'	Lost data during write
12	X'0C'	Parity error during write
13	X'0D'	Data record not found during write
14	X'0E'	Write fault on disk drive
15	X'0F'	Write protected disk
16	X'10'	Illegal logical file number
17	X'11'	Directory read error
18	X'12'	Directory write error
19	X'13'	Illegal file name
20	X'14'	GAT read error
21	X'15'	GAT write error
22	X'16'	HIT read error
23	X'17'	HIT write error
24	X'18'	File not in directory
25	X'19'	File access denied
26	X'1A'	Full or write protected disk
27	X'1B'	Disk space full
28	X'1C'	End of file encountered
29	X'1D'	Record number out of range
30	X'1E'	Directory full — can't extend file
31	X'1F'	Program not found
32	X'20'	Illegal drive number
33	X'21'	No device space available
34	X'22'	Load file format error
37	X'25'	Illegal access attempted to protected file
38	X'26'	File not open
39	X'27'	Device in use
40	X'28'	Protected system device
41	X'29'	File already open
42	X'2A'	LRL open fault
43	X'2B'	SVC parameter error
63	X'3F'	Extended error
—		Unknown error code

BASIC ERROR CODES AND MESSAGES

Number	Message
1	NEXT without FOR A variable in a NEXT statement does not correspond to any previously executed FOR statement variable.
2	Syntax error BASIC encountered a line that contains an incorrect sequence of characters (such as unmatched parenthesis, misspelled statement, incorrect punctuation, etc.). BASIC automatically enters the edit mode at the line that caused the error.
3	RETURN without GOSUB BASIC encountered a RETURN statement for which there is no matching GOSUB statement.
4	Out of DATA BASIC encountered a READ statement, but no DATA statements with unread items remain in the program.
5	Illegal function call A parameter that is out of range was passed to a math or string function. An FC error may also occur as the result of: <ul style="list-style-type: none">a. A negative or unreasonably large subscript.b. A negative or zero argument with LOG.c. A negative argument to SQR.d. A negative mantissa with a noninteger exponent.e. A call to a USR function for which the starting address has not yet been given.f. An improper argument to MID\$, LEFT\$, RIGHT\$, PEEK, POKE, TAB, SPC, STRING\$, SPACE\$, INSTR, or ON . . . GOTO.

-
- | | |
|----|--|
| 6 | Overflow

The result of a calculation was too large to be represented in BASIC numeric format. If underflow occurs, the result is zero and execution continues without an error. |
| 7 | Out of memory

A program is too large, or has too many FOR loops or GOSUBs, too many variables, or expressions that are too complicated. |
| 8 | Undefined line number

A nonexistent line was referenced in a GOTO, GOSUB, IF . . . THEN . . . ELSE, or DELETE statement. |
| 9 | Subscript out of range

An array element was referenced either with a subscript that is outside the dimensions of the array, or with the wrong number of subscripts. |
| 10 | Duplicate Definition

Two DIM statements were given for the same array, or a DIM statement was given for an array after the default dimension of 10 has been established for that array. |
| 11 | Division by zero

An expression includes division by zero, or the operation of involution results in zero being raised to a negative power. BASIC supplies machine infinity with the sign of the numerator as the result of the division, or it supplies positive machine infinity as the result of the involution. Execution then continues. |
| 12 | Illegal direct

A statement that is illegal in direct mode was entered as a direct mode command. |
| 13 | Type mismatch

A string variable name was assigned a numeric value or vice versa. A numeric function was given a string argument or vice versa. |
-

-
- | | |
|----|--|
| 14 | Out of string space
String variables have caused BASIC to exceed the amount of free memory remaining. BASIC allocates string space dynamically, until it runs out of memory. |
| 15 | String too long
An attempt was made to create a string more than 255 characters long. |
| 16 | String formula too complex
A string expression is too long or too complex. The expression should be broken into smaller expressions. |
| 17 | Can't continue
An attempt was made to continue a program that: <ul style="list-style-type: none">a. Has halted due to an error.b. Has been modified during a break in execution.c. Does not exist. |
| 18 | Undefined user function
AUSR function was called before providing a function definition (DEF statement). |
| 19 | No RESUME
An error-handling routine was entered without a matching RESUME statement. |
| 20 | RESUME without error
A RESUME statement was encountered prior to an error-handling routine. |
| 21 | Unprintable error
An error message is not available for the error that occurred. |
| 22 | Missing operand
An expression contains an operator with no operand. |
| 23 | Line buffer overflow
An attempt was made to input a line with too many characters. |
-

-
- | | |
|----|---|
| 26 | FOR without NEXT
A FOR statement was encountered without a matching NEXT. |
| 29 | WHILE without WEND
A WHILE statement does not have a matching WEND. |
| 30 | WEND without WHILE
A WEND statement was encountered without a matching WHILE. |

Disk Errors

- | | |
|----|---|
| 50 | FIELD overflow
A FIELD statement is attempting to allocate more bytes than were specified for the record length of a direct-access file. |
| 51 | Internal error
An internal malfunction has occurred in BASIC. Report to Radio Shack the conditions under which the message appeared. |
| 52 | Bad file number
A statement or command references a file with a buffer number that is not OPEN or is out of the range of file numbers specified at initialization. |
| 53 | File not found
A LOAD, KILL, or OPEN statement references a file that does not exist on the current disk. |
| 54 | Bad file mode
An attempt was made to use PUT, GET, or LOF with a sequential file, to LOAD a direct file, or to execute an OPEN statement with a file mode other than I, O, R, E or D. |
| 55 | File already open
An OPEN statement for sequential output was issued for a file that is already open; or a KILL statement was given for a file that is open. |
-

57	Device I/O error
	An Input/Output error occurred. This is a fatal error; the operating system cannot recover from it.
58	File already exists
	The filespec specified in a NAME statement is identical to a filespec already in use on the disk.
61	Disk full
	All disk storage space is in use.
62	Input past end
	An INPUT statement was executed after all the data in the file had been INPUT, or for a null (empty) file. To avoid this error, use the EOF function to detect the end-of-file.
63	Bad record number
	In a PUT or GET statement, the record number is either greater than the maximum allowed (65,535) or equal to zero.
64	Bad file name
	An illegal filespec (file name) was used with a LOAD, SAVE, KILL, or OPEN statement (for example, a filespec with too many characters).
66	Direct statement in file
	A direct statement was encountered while LOADING an ASCII-format file. The LOAD is terminated.
67	Too many files
	An attempt was made to create a new file (using SAVE or OPEN) when all directory entries are full.
68	Disk write protected
69	File access denied
70	Command Aborted

Appendix E/ Converting TRSDOS Version 1 BASIC Programs to TRSDOS Version 6 BASIC Programs

You can run a TRSDOS Version 1 applications program on TRSDOS Version 6. However, you may need to make a few changes to the program. The differences between the two BASICs are listed below. (From here on, we will refer to TRSDOS Version 6 as TRSDOS 6, and to TRSDOS Version 1 as TRSDOS 1).

1. **ROM Subroutines.** TRSDOS 1 BASIC is a ROM and RAM-based language. TRSDOS 6 BASIC is strictly a RAM language; therefore, it cannot access any of TRSDOS 1's ROM subroutines.
2. **Disk Files.** TRSDOS 6 BASIC does not provide cassette support. It is exclusively a "disk system", that is, you can only use it with floppy diskettes or with a hard disk system. If you have learned BASIC through "Getting Started with TRS-80 BASIC", or have never worked with a disk system before, read about "Disk Files" in Chapter 5. This chapter explains how you can store and access data on disk. You also need to read Chapter 1, "Sample Session", which describes how to load disk BASIC and how to save a program on disk.
3. **Characters per Line.** Both TRSDOS 1 and TRSDOS 6 BASIC allow you to type up to 255 characters per line. However, there is a slight difference. With TRSDOS 6, you can type up to 249 characters per line. The other six characters are reserved for the line number and the space following the line number. With TRSDOS 1, you can type up to 240 characters in the command mode, and add the extra 15 characters in the edit mode.
4. **Variable Names.** TRSDOS 1 BASIC only recognizes the first two letters of a variable name; TRSDOS 6 BASIC allows variable names of up to 40 characters, all of which are significant.
5. **Converting to Integers.** In converting a single or double-precision number to integer value, TRSDOS 1 BASIC truncates the number; TRSDOS 6 BASIC rounds the number. This difference in conversions also affects assignment statements and function or statement evaluations. For example, if you typed `I% = 2.5`, TRSDOS 1 BASIC would convert 2.5 to 2; TRSDOS 6 BASIC would convert it to 3. If you typed `TAB(4.5)`, TRSDOS 1 would move to the fourth tab position; TRSDOS 6 would move to the fifth tab position.

If you enter a number as a constant in response to a command that calls for an integer, and the number is out of integer range, BASIC converts it to single or double precision. When the number is printed, it appears with a type-declaration tag at the end.

6. **Print Zones.** TRSDOS 1 BASIC includes 16 spaces between print zones; TRSDOS 6 BASIC includes 20 spaces. This is because TRSDOS 1's screen displays up to 64 characters horizontally,

while TRSDOS 6's screen displays up to 80 characters horizontally.

7. **Ports.** If your program uses PEEKs or POKEs, it is probably accessing Model III ports. The Model 4 and Model 4P assigned ports are different. For information about these ports, refer to the Technical Reference Manual.

8. **BASIC Keywords.** The following TRSDOS 1 BASIC keywords are not supported by TRSDOS 6 BASIC: CSAVE, CLOAD, POINT, CLOCK, CMD, POSN, RENAME, and VERIFY.

The following TRSDOS 6 BASIC keywords are not supported by TRSDOS 1 BASIC: COMMON, ERR\$, OCT\$, OPTION BASE, RENUM, ROW, SPACE\$, SPC, SWAP, WAIT, WHILE . . . WEND, WIDTH, and WRITE#.

9. **Reserved Words.** TRSDOS 6 BASIC **requires that all reserved words be delimited by spaces.** Only those characters which may be part of the keyword's syntax can be typed immediately after or before the keyword. For all other characters, leave a space between the keyword and the character. (For example, you cannot type DEFUSR; you must leave a space between DEF and USR.) Appendix F includes a listing of Reserved Words.
10. **Error Messages.** TRSDOS 6 BASIC Error Codes, Character Codes and Internal Codes for BASIC keywords differ from TRSDOS 1 BASIC codes. See the Appendices for more information on TRSDOS 6 BASIC codes.
11. **String Space.** TRSDOS 6 BASIC allocates string space dynamically; you do not need to allocate string space with the CLEAR statement. Instead, use CLEAR to set the maximum memory location BASIC may access and the amount of stack space. For more information, see CLEAR in Chapter 7.
12. **Printing Single and Double-Precision Numbers.** The rules for printing single and double-precision numbers are different. For more information, see PRINT in Chapter 7.
13. **Division by Zero.** Contrary to TRSDOS 1 BASIC, TRSDOS 6 BASIC does not produce a fatal error if it encounters division by zero or overflow. Instead, it prints an error message and continues executing your program.
14. **FOR . . . NEXT.** TRSDOS 6 BASIC skips the body of a FOR . . . NEXT loop if the initial value of the loop, times the sign of the STEP, exceeds the final value of the loop, times the sign of the STEP. For a more detailed explanation, see FOR . . . NEXT in Chapter 7.
15. **Nested Subroutines.** If your program has nested subroutines or nested FOR . . . NEXT loops, an "Out of memory" error may

occur. To avoid this, use the CLEAR statement to set aside "stack space" for your subroutines. See CLEAR in Chapter 7 for more information.

16. **IF . . . THEN . . . or IF THEN . . . ELSE.** With TRSDOS 1 BASIC, the word "THEN" is optional in both of these statements. With TRSDOS 6 BASIC, it is required.
17. **PRINT@ and PRINT TAB.** If a string is too long to fit on the current line, TRSDOS 6 BASIC prints the entire string on the next line. TRSDOS 1 BASIC prints as many characters as possible on the first line, and the rest on the second line.

In a PRINT TAB(*n*) statement, if *n* is greater than 80, TRSDOS 6 BASIC divides *n* by 80. The remainder of this division is used as the tab position. For example, if you typed TAB(91), TRSDOS 6 BASIC would tab to position 11 on the screen. TRSDOS 1 BASIC would tab to position 91.

18. **Self-Documenting Programs.** TRSDOS Version 6 BASIC programs can be self-documenting, as in the following example:

```
100 INPUT EFFORT
110 INPUT DISTANCE
120 FORCE = EFFORT * DISTANCE
130 PRINT FORCE
140 END
```

Under TRSDOS Version 6 BASIC, the reserved words (FOR and TAN in the above example) in the variable names will not cause a syntax error. This is because in order to be recognized as reserved words, they must be delimited by surrounding spaces.

TRSDOS Version 1 would return syntax errors in this example.

19. **Graphics Characters.** Under TRSDOS Version 6, the size of the graphics characters is different than under TRSDOS Version 1. The lowest portions of the TRSDOS Version 6 graphics characters are smaller than their TRSDOS Version 1 equivalents.

Appendix F/ BASIC Keywords and Derived Functions

Reserved BASIC Words

ABS	FN	OR	VAL
AND	FRE	OUT	VARPTR
ASC	GET	PEEK	WAIT
ATN	GOSUB	POKE	WEND
AUTO	GOTO	POS	WHILE
CALL	HEX\$	PRINT	
CDBL	IF	PUT	WRITE
CHAIN	IMP	RANDOM	XOR
CHR\$	INKEY\$	READ	+
CLEAR	INP	REM	-
CLOSE	INPUT	RENUM	*
CLS	INSTR	RESTORE	/
COMMON	INT	RESUME	^
CONT	KILL	RETURN	\
COS	LEFT\$	RIGHT\$,
CSNG	LEN	RND	>
CVD	LET	ROW	=
CVI	LINE	RSET	<
CVS	LIST	RUN	
DATA	LLIST	SAVE	
DATE\$	LOAD	SGN	
DEF	LOC	SIN	
DEFDBL	LOF	SOUND	
DEFINT	LOG	SPACE\$	
DEFSNG	LPOS	SPC	
DEFSTR	LPRINT	SQR	
DELETE	LSET	STEP	
DIM	MEM	STOP	
EDIT	MERGE	STR\$	
ELSE	MID\$	STRING\$	
END	MKD\$	SWAP	
EOF	MKI\$	SYSTEM	
EQV	MKS\$	TAB	
ERASE	MOD	TAN	
ERL	NAME	THEN	
ERR	NEW	TIMES	
ERROR	NEXT	TO	
ERRS\$	NOT	TROFF	
EXP	OCT\$	TRON	
FIELD	ON	USING	
FIX	OPTION	USR	

Internal Codes for BASIC Keywords

ABS	65414	GOTO	137
AND	248	HEX\$	65434
ASC	65429	IF	139
ATN	65422	IMP	252
AUTO	171	INKEY\$	224
CALL	182	INP	65424
CDBL	65438	INPUT	133
CHAIN	185	INSTR	219
CHR\$	65430	INT	65413
CINT	65436	KILL	200
CLEAR	146	LEFT\$	65409
CLOSE	195	LEN	65426
CLS	159	LET	136
COMMON	184	LINE	177
CONT	153	LIST	147
COS	65420	LLIST	158
CSNG	65437	LOAD	196
CVD	65452	LOC	65454
CVI	65450	LOF	65455
CVS	65451	LOG	65418
DATA	132	LPOS	65435
DATE\$	222	LPRINT	157
DEF	151	LSET	201
DEFDBL	176	MEM	225
DEFINT	174	MERGE	197
DEFSNG	175	MID\$	65411
DEFSTR	173	MKD\$	65458
DELETE	170	MKI\$	65456
DIM	134	MKS\$	65457
EDIT	167	MOD	253
ELSE	162	NAME	199
END	129	NEW	148
EOF	65453	NEXT	131
EQV	251	NOT	214
ERASE	166	OCT\$	65433
ERL	215	ON	149
ERR	216	OPEN	191
ERROR	168	OPTION	186
ERRS\$	223	OR	249
EXP	65419	OUT	156
FIELD	192	PEEK	65431
FIX	65439	POKE	152
FN	212	POS	65425
FOR	130	PRINT	145
FRE	65423	PUT	194
GET	193	RANDOM	187
GOSUB	141	READ	135

REM	143	TIMES	226
RENUM	172	TO	207
RESTORE	140	TROFF	164
RESUME	169	TRON	163
RETURN	142	USING	218
RIGHT\$	65410	USR	211
RND	65416	VAL	65428
ROW	65459	VARPTR	221
RSET	202	WAIT	150
RUN	138	WEND	181
SAVE	203	WHILE	180
SGN	65412	WIDTH	161
SIN	65417	WRITE	183
SOUND	205	XOR	250
SPACE\$	65432	+	243
SPC	213	-	244
SQR	65415	*	245
STEP	210	/	246
STOP	144	^	247
STR\$	65427	\	254
STRING\$	217	,	220
SWAP	165	>	240
SYSTEM	189	=	241
TAB	209	<	242
TAN	65421		
THEN	208		

Derived BASIC Functions

Functions which are not intrinsic to BASIC may be calculated as follows:

Function	BASIC Equivalent
SECANT	$\text{SEC}(X) = 1/\text{COS}(X)$
COSECANT	$\text{CSC}(X) = 1/\text{SIN}(X)$
COTANGENT	$\text{COT}(X) = 1/\text{TAN}(X)$
INVERSE SINE	$\text{ARCSIN}(X) = \text{ATN}(X/\text{SQR}(-X*X + 1))$
INVERSE COSINE	$\text{ARCCOS}(X) = \text{ATN}(X/\text{SQR}(-X*X + 1)) + 1.5708$
INVERSE SECANT	$\text{ARSCEC}(X) = \text{ATN}(X/\text{SQR}(X*X - 1)) + \text{SGN}(\text{SGN}(X) - 1)*1.5708$
INVERSE COSECANT	$\text{ARCCSC}(X) = \text{ATN}(X/\text{SQR}(X*X - 1)) + (\text{SGN}(X) - 1)*1.5708$
INVERSE COTANGENT	$\text{ARCCOT}(X) = \text{ATN}(X) + 1.5708$
HYPERBOLIC SINE	$\text{SINH}(X) = (\text{EXP}(X) - \text{EXP}(-X))/2$
HYPERBOLIC COSINE	$\text{COSH}(X) = (\text{EXP}(X) + \text{EXP}(-X))/2$
HYPERBOLIC TANGENT	$\text{TANH}(X) = (\text{EXP}(-X)/\text{EXP}(X) + \text{EXP}(-X))*2 + 1$
HYPERBOLIC SECANT	$\text{SECH}(X) = 2/(\text{EXP}(X) + \text{EXP}(-X))$
HYPERBOLIC COSECANT	$\text{CSCH}(X) = 2/(\text{EXP}(X) - \text{EXP}(-X))$
HYPERBOLIC COTANGENT	$\text{COTH}(X) = (\text{EXP}(-X)/(\text{EXP}(X) - \text{EXP}(-X))*2 + 1$
INVERSE HYPERBOLIC SINE	$\text{ARCSINH}(X) = \text{LOG}(X + \text{SQR}(X*X + 1))$
INVERSE HYPERBOLIC COSINE	$\text{ARCCOSH}(X) = \text{LOG}(X + \text{SQR}(X*X - 1))$
INVERSE HYPERBOLIC TANGENT	$\text{ARCTANH}(X) = \text{LOG}((1 + X)/(1 - X))/2$
INVERSE HYPERBOLIC SECANT	$\text{ARCSECH}(X) = \text{LOG}((\text{SQR}(-X*X + 1) + 1)/X)$
INVERSE HYPERBOLIC COSECANT	$\text{ARCCSCH}(X) = \text{LOG}((\text{SGN}(X)*\text{SQR}(X*X + 1) = 1)/X)$
INVERSE HYPERBOLIC COTANGENT	$\text{ARCCOTH}(X) = \text{LOG}((X + 1)/(X - 1))/2$

Appendix G/ Video Display Worksheet

[illegible]

Appendix H/ Glossary

alphanumeric — consisting of only the letters A-Z, a-z, and the numerals 0-9.

ASCII — The alphanumeric representation of controls and characters as a single byte, falling within a range from 1 to 127 (sometimes including 0).

ASCII files — Files that are readable by LISTing the file. Source, text, and data files are usually ASCII files.

background task — A job performed by the computer that is not apparent to the user or does not require interaction with the user. Some examples are the REAL TIME CLOCK, the SPOOLer, and the TRACE function.

baud — Refers to the rate of serial data transfer.

bit — One eighth of a byte; one binary digit.

boot — The process of resetting your computer and loading in the resident operating system from the system drive.

buffer — An area in RAM that temporarily holds information that is being passed between devices or programs.

byte — The unit that represents one character to the Model 4. It is composed of eight binary "bits" that are either ON (1) or OFF (0). One byte can represent a number from 0 to 255.

COMM — A communications program capable of interacting with: disk, printer, video display, keyboard, and the RS232 interface. COMM dynamically buffers all of the system devices.

concatenate — To add one variable or string onto the end of another.

configuration — The status of the system and physical devices that are available to it. This configuration can be dynamically changed with several library commands, and can be saved with the SYSGEN library command. If the system is SYSGENed, the SYSGENed configuration is re-established each time the machine is reset or re-started.

cursor — The location on the video display where the next character is printed. It is marked by the presence of a cursor character.

cylinder — All tracks of the same number on a disk drive. On single sided drives, cylinders are the same as tracks.

DAM (Data Address Mark) — A control byte that prefixes each sector on a disk. This byte indicates the type of sector that is about to be read. It can mark a sector as being deleted or undeleted, a user sector or a system sector.

DCB — Device Control Block, a small piece of memory used to control the status, input, and output of data between the system and the devices.

DCT — Drive Code Table, a piece of memory containing information about the disk drives and/or diskettes in them.

density — Refers to the density of the data written to a diskette. Double density provides approximately 80% more capacity than single density.

device — The two types of devices are Logical and Physical.

A logical device is one that is referred to in TRSDOS. Logical devices have devspecs, a 2-character name that is prefixed with an asterisk (*). An example of a logical device is *PR, which is normally used to send data to the printer.

A physical device is a piece of hardware, such as the video display or printer. A piece of software called a "driver" connects the logical device to the physical device by translating data from the format used by logical devices into the format required by the hardware, and vice versa.

devspec — The name associated with a device by which it is referenced. A devspec always consists of three characters: an asterisk followed by two alphabetic characters.

directory — An area of a disk that contains the names of the files on the disk, information on where the data in those files is stored on the disk, and other information such as any password, the logical record length, the modification date, and so on.

disk I.D. — A disk's name and master password assigned when it is formatted.

***DO** — The Video Display device.

:drive — Indicate that a drive number can be inserted where this is used. A drive number must always be preceded immediately by a ":".

driver — A program that interfaces a physical device (a piece of hardware) to a logical device, which can be referenced by TRSDOS.

EOF — End of File, a marker used to denote the end of a program or data file.

/ext — The extension of a filespec. The use of /ext is sometimes optional. An extension's first character must be a "/" (slash) which is followed by one to three alphanumeric characters, the first of which must be a letter.

FCB — File Control Block, a small piece of memory used to control the status and I/O of data between the operating system and disk files.

filename — The mandatory name used to reference a disk file. A filename consists of one to eight alphanumeric characters, the first of which must be alphabetic.

filespec — A disk file's name. A filespec consists of four fields and two switches. The first field is always mandatory. A filespec is in the following format:

!filename/ext.password:drive!

"!" — (preceding filename) is an optional switch. If you specify this switch, you can build a file with the same name as a TRSDOS command or utility. For example, you can issue the command: LIST !DEVICE and TRSDOS will list the user-created file named DEVICE.

filename — The mandatory name of the file.

/ext — The optional file extension.

.password — The optional file password.

:drive — The optional drive number.

"!" — (following :d) is an optional switch. If this switch is set, the end of file marker for filespec is updated after every write to the file.

filter — A machine language program that monitors and/or alters I/O that passes through it. FILTER is also the library command that establishes a FILTER routine.

/FIX — The desired file extension for a PATCH file.

foreground task — Jobs performed by the computer that are apparent to the user, such as running an applications program.

gran — The abbreviation of granule. A gran is the minimum amount of storage used for a disk file. As files are extended, file allocation is increased in increments of grans. The size of a gran varies with the size and density of a diskette.

HIGH\$ — The name of a memory location in the operating system that contains the address of the highest unprotected memory address available for use. Programs that are above this location are protected from other programs. You can display or change the value of HIGH\$ by using the MEMORY command or the @HIGH\$ SVC.

interrupt — A signal generated by the hardware which causes the system to stop what it is doing to perform some other service. These interruptions are used to perform background tasks such

as checking the keyboard for input and supplying data to the printer if the spooler is running.

I/O — The abbreviation for Input/Output.

/JCL — The desired file extension for a DO file. JCL is the abbreviation for Job Control Language.

***JL** — The Joblog device.

***KI** — The Keyboard device.

/KSM — The desired file extension for a ksm file. KSM is an abbreviation for Key-Stroke Multiply.

library — A set of commands that perform most of the operating system functions.

load module format — A file format that loads directly to a specified RAM address.

LSB — The Least Significant Byte. In a hexadecimal word, it is sometimes referred to as the "low order byte".

macro — Predetermined lines of code used in JCL.

mod date — The date a file was last written to.

mod flag — A "+" sign placed after a filename that indicates it was written to since its last backup.

MSB — The Most Significant Byte. In a hexadecimal word, it is sometimes referred to as the "high order byte".

NIL — A "dummy" device which a logical device can be linked or routed to. When you reset a user-defined device, it points at NIL. NIL discards any data that is sent to it and returns a null (ASCII 0) when data is requested from it. It is useful when you want to discard output from a program during a test run.

NRN — Next Record Number.

parameter — an optional value that you supply to a command line. Parameters may follow a command or utility and are enclosed in parentheses ().

parse — The process of breaking a command into individual parameters.

partspec — A way to represent a group of one or more files by entering only part of the file specification. Partspecs are allowed in some TRSDOS library and utility commands so that a group of files can be specified. A partspec can consist of any combination of the four fields that make up a filespec.

In a partspec, a dollar sign (\$) can be used to represent any character in a given position in a filespec. This is called "wildcarding."

By prefixing a partspec with a minus sign (-), you can cause all the files *except* those that match the partspec to be considered in the given command.

.password — The optional password associated with a filespec. A password's first character is a period (.) and it is followed by one to eight alphanumeric characters, the first of which must be a letter.

PATCH — A utility that makes minor alterations to disk files.

***PR** — The Line Printer device.

RAM — Random Access Memory. This type of memory can be accessed in any order, and any byte can be read or written at any time.

ROM — Read Only Memory. This type of memory stores information that will not change. ROM does not require power to maintain its data.

sector — A contiguous 256-byte block of disk storage. Each sector has an I.D. field which contains its track and sector number. This allows the hardware to use the proper area of the disk when reading or writing to the disk.

A sector is the smallest amount of data the operating system will read from or write to a disk. Several sectors make up a track. One or more tracks make up a cylinder.

***SI** — The Standard Input device. Programs that read data from this device normally receive data from the keyboard. You can change this to have data read from a file or another device by issuing a ROUTE command. This allows a program to accept input from any device without the need to modify the program.

***SO** — The Standard Output Device. Data that is output to this device by a program is normally displayed on the screen. You can change this to have the data written to a file or another device by issuing a ROUTE command. This allows a program to perform output to any device without the need to change the program.

switch — A parameter with a definite setting, such as ON/OFF or YES/NO.

token — A variable used in JCL.

utility — A program that provides a service to the user. Utilities differ from library commands as they are usually larger programs and require memory that is usually reserved for the user.

word — A 16-bit value which is stored in two contiguous 8-bit bytes. A word may be specified in hexadecimal format X'nnnn' or in decimal format nnnnn where nnnnn is a value from 0 to 65535.

Appendix I/TRSDOS Programs

This appendix contains five TRSDOS programs that you can use with the SET, SYSTEM, and FILTER library commands. There is a short explanation and examples for each program.

JOBLOG

```
ROUTE *JL [TO] filespec
ROUTE *JL [TO] devspec
```

Establishes the TRSDOS Joblog device (*JL), which collects certain information and sends it to a *filespec* or *devspec*.

You can use JOBLOG to create a file that contains a list of commands that you issue.

The information sent to *filespec* or *devspec* consists of all commands entered or received and the time (according to the system clock) that the commands occur.

When you issue a RESET *JL command, the Joblog function ceases and *filespec* closes. See the ROUTE library command for additional information.

To view the contents of a Joblog file, issue a RESET *JL command to close the file, and then a LIST command to list the file's contents.

To view the contents of a Joblog disk file when it is open, add a "trailing exclamation point" (!) to *filespec* (see "filespec" in the GLOSSARY). Then use the LIST library command to list the file to the screen or printer.

NOTE: If *filespec* already exists, information sent to it is appended to the end of the file.

Examples

```
ROUTE *JL TO LISTER/JBL (ENTER)
```

sends a log of all commands entered and received to the file LISTER/JBL.

```
ROUTE *JL TO *PR (ENTER)
```

sends a log of all commands entered and received to the printer.

KSM/FLT

SET <i>devspec</i> KSM/FLT [USING] <i>filespec</i> [(<i>parameter</i>)] FILTER *KI <i>devspec</i>
--

Filter

Establishes the KSM (Key Stroke Multiply) filter.

You can use KSM/FLT to assign repetitive tasks (such as issuing a TRSDOS command) to one key, so that you only have to press **CLEAR** and the assigned key to execute the task.

devspec is any user-created *devspec*.

filespec contains up to 26 "key equivalents." The KSM filter loads the key equivalents from *filespec* into high memory.

The *parameter* is:

ENTER = *value* specifies *value* as the character TRSDOS recognizes as an **ENTER** character in a KSM file. *value* is a number in the hexadecimal format X'nn', a decimal number, or a single character such as a colon (:).

Each key equivalent is associated with the **CLEAR** key and an alphabetic key. When you press **CLEAR** and a key, TRSDOS executes the phrase associated with that key.

Building a KSM File

You can use the BUILD library command to build a /KSM file. To build a KSM file named ROUTINE/KSM, type:

BUILD ROUTINE/KSM **ENTER**

TRSDOS then lets you enter up to 26 key equivalents with the prompts:

A = >
B = >
C = >
,
,
,
Z = >

To assign a character, type in the desired command; then terminate the line by pressing **ENTER** (or the character you specified with the ENTER parameter). To skip a character, press **ENTER** at the prompt. Pressing **ENTER** does not place an **ENTER** character at the end of the key equivalent, but merely terminates your input for that key. To place an **ENTER** character in a key equivalent, type a semicolon (;) where you wish an **ENTER** press to be executed. Each line can be up to 255 characters long.

When you have assigned all 26 characters, the file is closed and the BUILD terminates. Pressing **CONTROL****(SHIFT)****@** terminates the BUILD at any time.

If you want to create characters or strings that are not available from the keyboard, use the (HEX) parameter of the BUILD command.

It is not absolutely necessary to use the BUILD command with the /KSM extension to create a KSM file. The KSM/FLT program can use any file in ASCII format. TRSDOS uses the same rules concerning **ENTER** and the semicolon for a file in an ASCII format.

If you wish to deactivate the KSM filter, issue the command:

```
RESET *KI ENTER
```

If you wish to change to a different KSM file, issue the commands:

```
RESET *KI ENTER  
RESET devspec ENTER
```

And re-issue the commands for the new file:

```
SET devspec KSM/FLT [USING] filespec ENTER  
FILTER *KI devspec ENTER
```

Examples

```
A=>DIR :0 ENTER
```

specifies the key equivalent of A as "DIR :0". The command DIR :0 is displayed on the screen when the **CLEAR** and **A** keys are pressed together. The command is not executed until you press the **ENTER** key.

```
B=>FREE ; ENTER
```

specifies the key equivalent of B as "FREE;". A semicolon in a key equivalent represents an **ENTER** character. So, when you press **CLEAR** and **B**, the FREE library command is executed immediately (since the last character of the phrase is a semicolon).

```
F=>FREE ;DEVICE ; ENTER
```

specifies the key equivalent of F as "FREE;DEVICE;". A semicolon in a key equivalent represents an **ENTER** character. So, when you press

CLEAR and **B**, the FREE and DEVICE library commands are executed immediately.

Error Conditions

Attempting to SET a device to the KSM/FLT when it is already active on another device results in an error.

When you install an additional KSM, the new KSM file cannot be larger than the first KSM file installed.

COM/DVR

SET *CL TO COM/DVR

Driver

In order to use the Communications Line device (*CL), you must SET it to this driver program.

You can use COM/DVR to prepare the Communications Line (*CL) for use.

COM/DVR sets *CL to the RS-232C hardware.

After you SET *CL to the RS-232C hardware, you can alter the parameters of the RS-232C port with the SETCOM command.

Example

```
SET *CL TO COM/DVR
```

sets *CL to its driver program.

```
SETCOM (WORD=8,PARITY=OFF) ENTER
```

configures the RS-232C port using the values specified.

Technical Information

When you set the COM/DVR, it will be placed in high memory if there is not enough room in low memory. (Low memory is within TRSDOS and does not take away from the memory available for your programs.) If this happens, a message similar to the following appears:

Note: driver installed in high memory.

If you want to use Memdisk while you are using COM/DVR, be sure to install Memdisk first.

FORMS/FLT

SET *FF TO FORMS/FLT FILTER *PR *FF	Filter
--	---------------

You can use FORMS/FLT to prepare the printer filter (*FF) for use.

In order to use the printer filter (*FF), you must SET it to this filter program, and activate it with the FILTER command.

After you SET *FF to FORMS/FLT, you can set up the parameters of the printer filter with the FORMS command.

Example

```
SET *FF TO FORMS/FLT (ENTER)
```

sets *FF to its filter program.

```
FILTER *PR *FF
```

filters the printer to the printer filter program.

```
FORMS (MARGIN=12,CHARS=70,INDENT=17) (ENTER)
```

configures the printer filter by causing all lines to start 12 spaces in from the normal left-hand starting position. Any line longer than 70 characters is indented 17 spaces (5 spaces past the margin) when wrapped around, so it is printed starting at position 7.

Technical Information

When you set the FORMS/FLT, it will be placed in high memory if there is not enough room in low memory. (Low memory is within TRSDOS and does not take away from the memory available for your programs.) If this happens, a message similar to the following appears:

Note: filter installed in high memory.

If you want to use Memdisk while you are using FORMS/FLT, be sure to install Memdisk first.

MEMDISK/DCT

SYSTEM (DRIVE = <i>drive</i>, DRIVER = "MEMDISK")	Driver
--	---------------

Lets you add a pseudo floppy drive to the system which keeps its files in memory. Files stored on this drive can be accessed, read, and written more rapidly than files on a floppy. Only one Memdisk can be installed at a time.

All TRSDOS utilities treat the Memdisk drive as any other drive, so you can COPY, BACKUP, REMOVE, PURGE, ATTRIB, and display the DIRectory of the files on the Memdisk.

drive is the drive number you wish Memdisk to be. If you specify a drive number that is already defined, it is disabled and the Memdisk takes its place. *drive* is a number from 1 to 7.

To Install the Memdisk

When you start Memdisk, the following menu is displayed:

```
<A> Bank 0 (Primary Memory)
<B> Bank 1
<C> Bank 2
<D> Banks 1 and 2
<E> Disable MemDISK
```

```
Which type of allocation -
<A>, <B>, <C>, <D>, or <E>?
```

Each bank contains 32K of memory. If your system has only 64K of memory, then you do not have Banks 1 and 2.

Bank 0 is the top half of user memory. (See the Memory Map in the Technical Reference Manual.) It is shared by programs, drivers, filters, and Memdisk.

Because it is shared, if you select Bank 0 you are prompted for the number of cylinders that are to be used for the Memdisk in Bank 0. Selecting the number of cylinders allows you to use Memdisk but still have enough memory for the programs you want to run. You must select at least 3 cylinders. If you format Memdisk, the amount of memory used by each cylinder is shown below:

Double Density $256 \times 18 = 4608$ bytes per cylinder (4.5K)
Single Density $256 \times 10 = 2560$ bytes per cylinder (2.5K)

If you specify Banks 1 or 2, then all of the bank (32K) is used. If you specify option **(D)**, then Memdisk uses Banks 1 and 2 (64K).

After selecting which bank you want to use, you see:

```
Single or Double Density <S,D>?
```

This allows you to adjust the way memory is formatted. You get the same amount of space at single density as you do at double density, but the number of sectors per cylinder differs.

This feature allows mirror image backups to be performed, which allows data to be loaded into and out of Memdisk much faster.

Memdisk looks exactly like a floppy disk to a program.

If you selected Bank 0 (Double Density), the following message is displayed:

```
Note: Each Cylinder equals 4.50K of space.  
Number of free cylinders 1-N ?
```

N can be from 1 to 12. The value of N varies according to the number of other drivers resident in memory.

If you specified Bank 0 (Single Density), the following message is displayed:

```
Note: Each Cylinder equals 2.50K of space.  
Number of free cylinders 3-N ?
```

Enter the number of cylinders you want Memdisk to use in Bank 0, using the formula on the previous page. N can be from 3 to 7.

After you enter the configuring information, the following prompt is displayed:

```
Do you wish to Format it <Y,N>?
```

If you have not used Memdisk before, press **(Y)**. Formatting is not optional upon initial installation. MEMDISK is not initially installed unless you format it.

If you have used Memdisk and the system failed for some reason, press **(N)** to retrieve files that were left in Memdisk when it was last used. Remember that if the power went off, the Memdisk contents were erased.

If you answered the format question with **(Y)**, you see the message:

```
Verifying RAM Cylinder NN
```

```
Verifying Complete, RAM good  
Directory has been placed on Cylinder 1
```

MemDISK Successfully Installed

At this point, the Memdisk has been added to your system. The disk name is MEMDISK. It can be treated just like a floppy disk drive until you disable it or you reset the system.

To Disable the Memdisk

If you want to disable the Memdisk, then you must issue the command:

```
SYSTEM (DRIVE=drive,DRIVER="MEMDISK") (ENTER)
```

Then, at the menu select the **(E)** option. Memdisk displays one of the following messages:

```
MemDISK disabled, memory now available  
MemDISK disabled, Unable to reclaim high memory  
MemDISK disabled, Unable to reclaim driver area  
MemDISK disabled, Unable to reclaim high memory  
and driver area
```

If you receive the first message, Memdisk was disabled and was able to reclaim all memory (driver area, high memory (Bank 0), and alternate memory banks 1 and 2) that it was using.

If you receive the second message, Memdisk was unable to reclaim high memory (Bank 0) because another driver or filter was installed after Memdisk was set up and the other program is still in the way. This is known as memory fragmentation. If you need to use this area of memory, then you must reset the system.

If you receive the third message, Memdisk was disabled and able to claim high memory or alternate bank memory, but it could not reclaim the driver area.

If you receive the fourth message, Memdisk was disabled, but it could not reclaim any memory.

Error Conditions

Memdisk should be installed *before* COM/DVR or FORMS/FLT are. Filters and drivers can be loaded into an area within TRSDOS called low memory. (This area does not take away from the memory available for your programs.) However, not all of the drivers and filters can fit into this area at the same time. If there is no room left in low memory, most of the drivers and filters can be loaded in high memory. Since low memory works on a first come, first served basis and Memdisk is the only driver or filter that *must* load into low memory, you should install Memdisk before the other drivers and filters. This ensures that there is space available in low memory for Memdisk to reside.

If you attempt to re-install Memdisk in a different area of memory than the area that it was originally installed in, you get the error message "MemDISK already Active." Memdisk must always be re-installed as it was initially installed.

If you specify the wrong drive number (in the SYSTEM (DRIVE = *drive*, DRIVER = "MEMDISK") command) and you attempt to disable the Memdisk, then you receive the error message "Target Drive not a MemDISK."

If you attempt to disable a Memdisk and there is no MemDISK in the system to disable, then you receive the error message "MemDISK not present."

Technical Information

A Bank 0 Memdisk and BASIC use the same area of memory (RAM). Since a Bank 0 Memdisk and BASIC use the same area of memory, we recommend that you do not use BASIC when Memdisk is resident in Bank 0.

If you are going to use Memdisk as the system drive, you must COPY SYS0/SYS to it before it becomes the system drive. After Memdisk becomes the system drive, you can REMOVE SYS0/SYS from the Memdisk.

FLOPPY/DCT

	Driver
--	---------------

FLOPPY/DCT is used in Radio Shack hard disk installations. See your hard disk manual for an explanation on how to use this driver.

CLICK/FLT

Filter

SET *devspec* CLICK/FLT
FILTER *KI *devspec*

You can use the key-click filter to produce a tone from the sound generator inside your computer.

In order to use the click filter, you must SET it to this filter program, and activate it with the FILTER command.

After you have set and activated the click filter, each time you press a key on the keyboard, your computer produces a tone. You can use this tone as an "auditory feedback".

You can change the pitch and duration of the tone produced by the key-click filter. To do this, you must apply a patch to the values that control the pitch and duration of the sound in CLICK/FLT.FILTER (see the PATCH command).

The patch is:

D00,7E = xx,yy;F00,7E = 03,00

xx is the duration of the tone. xx can be 1 - FF. 1 is the shortest duration and FF is the longest.

yy is the pitch of the tone. yy can be 0 - FF. 1 is the highest pitch and 0 or FF is the lowest.

Appendix J/ BASIC Memory Map

0000H to 25FFH	Operating System	Reserved for TRSDOS operations.
2600H to 2FFFH	Overlay Area	Used alternately by TRSDOS and BASIC. Whenever you use a TRSDOS library command, TRSDOS uses this area to store the program that will perform the command. BASIC reloads this area with its data when you return from TRSDOS.
3000H to 85FFH	BASIC	Reserved for BASIC.
8600H to Bottom of Stack	User's BASIC Program	Reserved for your programs, variables, strings, and arrays.
Bottom of Stack to HIGH\$ or User-Defined top of memory (M)	BASIC stack and File Control Block(s)	Contains the stack used by BASIC and the File Control Block(s) (FCBs). Each FCB requires 564 bytes of storage. The number of FCBs that your system has is selected with the command: BASIC (F = n), where 'n' specifies the number of files that can be open at any one time. (One additional 564-byte block is always allocated and is reserved for use by BASIC.)
User-Defined top of memory (M) or HIGH\$ to HIGH\$	Assembly language routines callable from BASIC.	This area exists only if you create it with the command, BASIC (M = address) where 'address' specifies the last address that BASIC will use. The area between "M" and HIGH\$ is used to store assembly language routines that are called by BASIC programs.

HIGH\$ to
FFFFH

Driver/Filter/User
or System tasks

Area in which drivers, filters, and tasks that are continuously used by the system are stored. Items in this area include the spooler, drivers and filters that cannot fit into the area reserved within TRSDOS, and MEMDISK (when it resides in Bank 0). Assembly language routines that are to be called from BASIC may be placed here as long as the programs follow the rules outlined in the *Technical Reference Manual*.

User Program

Your User Program space is dynamic. It is dependent on the number of data files you requested when loading BASIC (called "concurrent" files), the HIGH\$ marker, the amount of stack space, and the highest memory location you specified when loading BASIC. For information on how to load BASIC, see Chapter 1.

Assuming that the HIGH\$ marker is at the top of physical memory (FFFFH) and that the highest memory location (the 'M' option) was not specified when BASIC was loaded, then four or less concurrent files do not alter the amount of User Program space. The fifth concurrent file decreases it by 312 bytes, and six or more decrease it by 564 bytes each.

IF HIGH\$ is not at FFFF\$, or if M was specified when BASIC was loaded, then use the PRINT FRE(0) command to see the amount of User Program space available.

The number of concurrent data files also determines where the top of the stack will be. BASIC uses the following formula:

$$M - (564 \times \text{number of concurrent files}) - 564 = \text{location value}$$

The location value given by this formula is set as the top of the stack. You can set aside additional stack space by using the CLEAR statement. However, the more stack space you use, the less User Program space you will have.

Appendix K/ Using The Device-Related Commands

The advanced, device-related commands affect the assigned TRSDOS devices and the devices that you create. They are:

DEVICE, FILTER, LINK, SET, ROUTE, RESET

DEVICE is different from the other commands because instead of directly affecting the devices, DEVICE actually shows how each device is set up and what connections between devices (and files) exist. So, each time you issue one of the above commands, you should issue a DEVICE (B=ON) command to make sure the devices are set the way you want them.

Creating an Unfiltered Link

An unfiltered link is different from a filtered link because there is not an in-between program (a filter) that affects the data flowing between the two devices.

Creating an unfiltered link between a device and a file involves the ROUTE and LINK commands.

ROUTE can create a user device and routes it to a file.

LINK creates a link between two devices.

Remember that it is a good idea to issue a DEVICE command before you create a link. In the following example, we are going to route the printer. On start-up, the printer is shown in the device table as:

```
*PR => X'0DE3'
```

The device table entry shows the place in memory (X'0DE3') where the driver program that controls the printer is located. This memory address may vary.

Example

In this example we are going to link the printer to a file. That is, all data sent to the printer is also sent to the file.

To create a link between the printer (*PR) and the file PRINT/TXT:0:

1. Route the user-created device *DU to the file PRINT/TXT:0 by issuing the command:

```
ROUTE *DU TO PRINT/TXT:0 (ENTER)
```

The device table shows:

```
*DU <=> PRINT/TXT:0
```

The following link now exists:

```
*DU <-> PRINT/TXT
```

Everything that TRSDOS sends to *DU is sent to the file PRINT/TXT.

-
2. Link the printer to *DU, which in turn is routed to PRINT/TXT by issuing the command:

```
LINK *PR *DU ENTER
```

the device table shows:

```
*PR => *L0 : *DU & => X'0DE3'  
*DU <=> PRINT/TXT:0
```

The following link now exists:

```
*PR -> Printer Driver (at X'0DE3')  
*PR -> *DU <-> PRINT/TXT
```

Everything that TRSDOS sends to *PR is also sent to *DU and from there to PRINT/TXT on Drive 0.

Creating a Filtered Link

Creating a filtered link involves the SET and FILTER commands. A filtered link involves a device and a filter program which affects the data that flows to or from the device.

SET prepares a user-created device for the filter connection.

FILTER creates the "logical link" between two devices. The first device is usually a system device, and the second device is always a user-created filter device.

Example

To create a filter link you need a filter program. In this example we use the system filter program KSM/FLT.

Before you issue a SET or FILTER command, be sure to issue a DEVICE command to see the start-up conditions of the system devices. In this example, we are going to filter the keyboard device. On start-up, the keyboard is shown in the device table as:

```
*KI <= X'0893'
```

The device table entry shows the place in memory (X'0893') where the driver program that controls the keyboard is located. This memory address may vary.

To create a KSM filter link between *KI and a user-created device *DU:

1. Set *DU to the KSM filter by issuing the command:

```
SET *DU KSM/FLT PRINT/DAT ENTER
```

The device table shows:

```
*KI <= X'0893'  
*DU <# [Inactive] X'FF67'  
Options: Type, KSM
```

-
2. Now use the FILTER command to connect the KSM filter program to the keyboard by issuing the command:

```
FILTER *KI *DU (ENTER)
```

The device table shows:

```
*KI <# [*DU] X'FF67'  
*DU <= X'0893'  
Options: Type, KSM
```

The following link now exists:

```
Keyboard Driver -> *DU -> KSM/FLT -> *KI
```

That is, everything that you type into the keyboard is sent through *DU, filtered through the KSM filter and then the information is available at *KI to be read by TRSDOS or a program.

3. To return the keyboard to its start-up condition, issue the command:

```
RESET *KI (ENTER)
```

4. To remove *DU from the device table, issue the following commands:

```
RESET *DU (ENTER)  
REMOVE *DU (ENTER)
```

Using the RESET Command

You can use RESET with SET, FILTER, ROUTE, or LINK. In this example, we show you what happens when you break the link between —PR and PRINT/TXT.

Example

To break the link:

```
*PR -> Printer Driver (at X'0DE3')  
*PR -> *DU <-> PRINT/TXT
```

1. First, to remove the routing between *DU and PRINT/TXT, issue the command:

```
RESET *DU (ENTER)
```

The device table shows:

```
*PR => *L0 ! *DU & => X'0DE3'  
*DU <=> NIL
```

The following link now exists:

```
*PR -> Printer Driver (at X'0DE3')  
*PR -> *DU <-> NIL
```

All output sent to *PR is still sent to *DU, even though *DU is pointed NIL.

2. To remove the link between *PR and *DU, issue the command:

RESET *PR **ENTER**

The device table shows:

*PR => X'0DE3'
*DU <=> NIL

Now you have returned *PR to its original start-up condition, and the link between *PR and *DU no longer exists.

(You can type REMOVE *DU to remove *DU from the device table.)

Appendix L/ Set Up for 50 Hz AC power (non-USA users)

A utility (HERZ50) is provided for customers in areas where the AC power is 50 Hz rather than 60 Hz. It should not be used by any other customers. HERZ50 simply places a patch on the diskette that changes the clock speed for 50 Hz users.

HERZ50 is a DO-file that makes a change in the software of TRSDOS. Only the Drive 0 diskette is changed. Be sure it is write-enabled before you start the DO-file. Once the HERZ50 change is done, it will remain in effect for that diskette.

To perform the change, type:

```
DO HERZ50
```

Once the change has been made, you will need to reset the system to put the change into effect. This loads the new software into RAM.

Appendix M/ Backup Limited Diskettes

Some software products distributed by Radio Shack come on backup limited diskettes. This means that you can make only a fixed number of copies of the master diskette that you receive. You should use the master diskette to make only the backup copies that you will use, as you cannot make a backup copy of a backup that was made from a backup limited diskette.

These diskettes are clearly marked to indicate that they are backup limited. If you are uncertain, contact your Radio Shack Computer Center or the store where you purchased the diskette.

When you have exhausted the number of copies you are allowed to make or if the master diskette is write protected, the following message appears when you attempt to back up the diskette:

Protected source disk

Making a Backup Copy

Before you make a copy of a backup limited diskette, you must remove the write-protect tab from the diskette (if one is present). Because the diskette is not write-protected, you should be very careful that you do not accidentally format the master diskette or back up the blank diskette to the master diskette.

Follow the steps given below for systems with two or more floppy drives or systems with one floppy drive, as appropriate.

For systems with two or more floppy drives:

(If you have a hard disk system and two or more floppy drives, start up as a floppy disk system and use this procedure.)

1. Insert a TRSDOS system diskette into floppy Drive 0. Insert a blank diskette into floppy Drive 1.
2. Format the blank diskette, following the directions given with the FORMAT utility. (You can use the command `FORMAT :1 (Q=N) (ENTER)` to produce a default diskette.)

If the diskette has any flaws on it (that is, if an asterisk is displayed next to one or more cylinder numbers), repeat step 2 with another blank diskette. Remember that you can make only a fixed number of copies of this diskette, so you should try to use good media.

3. At TRSDOS Ready, type:

`BACKUP :0 :1 (X) (ENTER)`

4. When you see the prompt:

`Insert SOURCE disk <ENTER>`

remove the TRSDOS system diskette from Drive 0 and set it aside.

Remove the write-protect tab (if any) from the master backup limited diskette you want to copy. This will be the SOURCE diskette.

Place the backup limited diskette in Drive 0 and press **(ENTER)**.

5. The following message may appear:

```
Destination disk ID is different:
Name=diskname Date=mm/dd/yy
Are you sure you want to backup to
it <Y,N> ?
```

Respond by typing **(Y)** **(ENTER)**.

6. The computer now performs the backup. When you see the prompt:

```
Insert SYSTEM disk <ENTER>
```

remove the backup limited diskette from Drive 0 and place a write-protect tab on it.

Remove the new backup copy from Drive 1. Place a write-protect tab on it and place a label on the jacket to identify it.

Insert the TRSDOS system diskette in Drive 0 and press **(ENTER)**. A message is displayed telling you if the backup operation was successful or not. If there was an error, start over with step 1 using another blank diskette. Unsuccessful backups do not count against the number of backups you can make.

For systems with one floppy drive:

(If you have a hard disk system and one floppy drive, start up as a floppy disk system and use this procedure.)

1. Insert a TRSDOS system diskette in the drive.
2. At TRSDOS Ready, type the following command:

```
FORMAT :0 (Q=N) (ENTER)
```

3. When you see the prompt:

```
Load destination diskette <ENTER>
```

remove the TRSDOS system diskette from the drive and insert a blank diskette. Press **(ENTER)**.

4. When you see the prompt:

```
Load SYSTEM diskette <ENTER>
```

remove the formatted diskette and insert the TRSDOS system diskette. Then press **(ENTER)**.

If the disk has any flaws on it (that is, if an asterisk is displayed next to one or more cylinder numbers), repeat steps 2, 3, and 4 using another blank diskette. Remember that you can make only a fixed number of copies of this diskette, so you should try to use good media.

5. At TRSDOS Ready, type:

BACKUP :0 :0 **(ENTER)**

6. When you see the prompt:

Insert SOURCE disk <ENTER>

remove the TRSDOS system diskette from the drive and set it aside.

Remove the write-protect tab (if any) from the backup limited diskette you want to copy. This will be your SOURCE diskette.

Insert the backup limited diskette in the drive and press **(ENTER)**.

7. When you see the prompt:

Insert DESTINATION disk <ENTER>

remove the backup limited diskette from the drive and insert the blank diskette. Press **(ENTER)**.

8. The following message may appear:

```
Destination disk ID is different:
Name=diskname  Date=mm/dd/yy
Are you sure you want to backup to
it <Y,N> ?
```

Respond by typing **(Y)** **(ENTER)**.

9. You are asked to insert the SOURCE and DESTINATION disks several times. Be very careful that you do not mix them up! Simply follow the instructions in steps 6 and 7 each time you see one of the two messages.

10. When you see the prompt:

Insert SYSTEM disk <ENTER>

remove the limited backup diskette from the drive and place a write-protect tab on it. Place a write-protect tab on the new backup copy and place a label on the jacket to identify it.

Insert the TRSDOS system diskette in the drive and press **(ENTER)**. A message is displayed telling you if the backup operation was successful or not. If there was an error, start over

with step 1 using another blank diskette. Unsuccessful backups do not count against the number of backups you can make.

Backing up selected files

You can move the programs on a backup limited diskette to the hard disk using backup by class or backup reconstruct. (The latter occurs automatically when the target drive is a hard disk.) This is counted the same as making a diskette copy using the procedure described above.

Note that if you do a backup by class and move only selected files, and if any of the files that are moved are protected, it is counted as though you made a copy of the entire disk. For example, suppose that you are allowed to make three backups of a backup limited diskette. You do a backup by class to move visible files. If one of the visible files is protected, then that file is copied along with the other visible files. However, you can now make only two more copies of the files on the master disk.

For this reason, you should be careful that you do not cheat yourself out of a copy. When moving files to the hard disk from a backup limited diskette, ask for all of the files using the (SYS,INV) options in the BACKUP command. If this moves some unwanted material, it can be purged later.

You may use backup by class or backup reconstruct to move non-protected files to and from the hard disk or a backup of the backup limited diskette. However, the protected files are not backed up and will not be listed if you use the QUERY option.

SERVICE POLICY

Radio Shack's nationwide network of service facilities provides quick, convenient, and reliable repair services for all of its computer products, in most instances. Warranty service will be performed in accordance with Radio Shack's Limited Warranty. Non-warranty service will be provided at reasonable parts and labor costs.

Because of the sensitivity of computer equipment, and the problems which can result from improper servicing, the following limitations also apply to the services offered by Radio Shack:

1. If any of the warranty seals on any Radio Shack computer products are broken, Radio Shack reserves the right to refuse to service the equipment or to void any remaining warranty on the equipment.
2. If any Radio Shack computer equipment has been modified so that it is not within manufacturer's specifications, including, but not limited to, the installation of any non-Radio Shack parts, components, or replacement boards, then Radio Shack reserves the right to refuse to service the equipment, void any remaining warranty, remove and replace any non-Radio Shack part found in the equipment, and perform whatever modifications are necessary to return the equipment to original factory manufacturer's specifications.
3. The cost for the labor and parts required to return the Radio Shack computer equipment to original manufacturer's specifications will be charged to the customer in addition to the normal repair charge.

Index

b 2-3
 ; (Advance Memory) 1-60
 - (Decrement Memory) 1-60
 ! tag 2-33
 # tag 2-34
 *FR 1-35, 36, 37
 device 1-40
 "received Data" 1-40
 *FS 1-37, 1-44

— A —

A (Cancel and Restart) 2-20
 ABS 2-65
 Accessing Direct-Access File 2-56
 Action Keys 1-36
 CLEAR **7** 1-36
 Dump-to-disk 1-36, 44
 *FR 1-36
 CLEAR **8** 1-36
 CLEAR **9** 1-37
 CLEAR **0** 1-37
 CLEAR **:** 1-37
 CLEAR **-** 1-38
 CLEAR **SHIFT** **1** 1-38
 half-duplex 1-38
 full-duplex 1-38
 CLEAR **SHIFT** **"** 1-38
 "Echo"ing 1-38
 CLEAR **SHIFT** **#** 1-39
 carriage return 1-39
 CLEAR **SHIFT** **\$** 1-39
 CLEAR **SHIFT** **%** 1-39
 CLEAR **SHIFT** **&** 1-39
 CLEAR **SHIFT** **'** 1-39
 control characters 1-39
 CLEAR **SHIFT** **()** 1-39
 cursor 1-39
 CLEAR **SHIFT** **()** 1-39
 CLEAR **SHIFT** ***** 1-40
 handshaking 1-40
 CLEAR **SHIFT** **0** 1-40
 device 1-40
 library command 1-40
 CLEAR **SHIFT** **=** 1-41
 data received 1-41

Addition 2-41
 Advanced Information ii
 Advanced Programmer's Command 1-14
 Advanced Programmer's Utilities 1-14
 APPEND 1-17
 command 1-31
 Appendices A-1
 Application Keys 1-35
 CLEAR **1** 1-35
 CLEAR **2** 1-35
 CLEAR **3** 1-35
 CLEAR **4** 1-35
 CLEAR **5** 1-35
 CLEAR **6** 1-35
 *FR OFF 1-37
 [arguments] 2-4
 array 2-29
 ASC 2-66
 ASCII format 1-17
 ASCII Modify 1-57
 Assigning Protection Attributes 1-20
 to a disk 1-21
 to a file 1-20
 Owner passwords 1-20
 User passwords 1-20
 ATN 2-67
 ATTRIB 1-19, 1-49
 protection passwords 1-19
 AUTO 1-22, 2-67

— B —

B (Move Block of Memory) 1-57
 BACKUP 1-24
 by class 1-25, 1-28
 limited 1-47, A-109
 mirror image 1-27, 1-28
 non-limited 1-47
 reconstruct 1-27, 1-28, 1-29
 with the (X) parameter 1-25, 28
 BASIC 2-1
 Command Mode 2-13
 Concepts 2-25
 Execution Mode 2-14
 Functions 2-62, A-82
 Introduction 2-59

Keywords	2-59, A-76, A-80
Line Edit Mode	2-17
Loading	2-9
Notations	2-3
Operations	2-7
reserved words	A-79
Sample Session	2-9
Terms	2-4
Variable classification	2-34
BASIC Command Mode	2-13
Special Keys	2-14
BASIC Concepts	2-25
BASIC Execution Mode	2-14
Special Keys	2-14
BASIC Line Edit Mode	2-17
Special Keys	2-18
BOOT	1-30
(BREAK) Key Handling	A-35
Breakable AUTO commands	1-30
Buffer	2-4
BUILD	1-31
Built-in drives	i
Bulletin Board Systems	1-34, 42

— C —

C (Call Instruction)	1-58
PC register	1-58
single-step	1-58
CALL	2-68
CDBL	2-69
CHAIN	2-70
Character Set	A-46
Characters per line	A-75
CHR\$	2-72
CINT	2-73
CLEAR	2-74
CLICK/FLT	A-100
CLOSE	2-75
CLS	2-76
COM/DVR	1-34, 42, A-94
COMM	1-34
Command	1-13
A (Cancel and Restart)	2-20
APPEND	1-17
Auxiliary	1-13
Break	1-46
(CONTROL) (A)	1-46

Model II, 12, or 16	1-46
(CONTROL) (C)	1-46
Model I or III	1-46
breakable AUTO	1-30
BUILD	1-31
Device Handling	1-13
device related	A-103
Diskette Handling	1-13
DO	1-31
E (Save Changes and Exit)	2-20
File Handling	1-13
I (Insert)	2-19
Initialization	1-13
Machine Language File Handling	1-13
nC (Change)	2-21
nD (Delete)	2-21
nKc (Search and "Kill")	2-22
nSc (Search)	2-22
Q (Cancel and Exit)	2-21
RESET	A-105
X (Extend Line)	2-19
COMMON	2-76
COMMunicating	
between two TRS-80's	1-44
with other computers	1-42
with mainframe	1-42
Communications	A-43
Configuration	A-85
Console	A-39
constants	2-11
CONT	2-77
CONV (CONV/CMD)	1-47
Converting to Integers	A-75
COPY	1-49
COS	2-78
CREATE	1-52
Creating	
Direct-Access Files	2-54
filtered link	A-104
Sequential-access Files	2-51
unfiltered link	A-103
CSNG	2-79
CVD, CVI, CVS	2-80
Cylinder	1-27, 1-61

— D —

D (Display)	1-58
-------------------	------

D notation	2-34	Disk Files	1-7, 2-51, A-75
DATA	2-81	Disk ID's	1-27, 1-28
DATE	1-54	Disk Prompts	1-51
system	1-54	DESTINATION	1-51
today's	1-54	SOURCE	1-51
DATE\$	2-82	SYSTEM	1-51
DEBUG	1-55	Disk Read/Write Utility	1-61
activate	1-55	Division	2-40
extended	1-55	by zero	A-76
high memory	1-56	DO	1-31, 1-32, 1-72
microprocessor registers	1-56	Job Control Language	1-72
flag registers	1-56	@label	1-72
memory locations	1-57	Double Precision	2-31
PC register	1-56	:drive	A-85, 1-8
register pairs	1-56	Drivers	1-10
Debug Display	1-30	Dummy number	2-4
DEFDBL	2-83	Dummy string	2-4
DEFINT	2-83	DUMP	1-75
DEFSNG	2-83	Dump-To-Disk	1-36
DEFSTR	2-83		
DEF FN	2-84	— E —	
DEF USR	2-85	E (Save Changes and Exit)	2-20
DELETE	2-86	E notation	2-34
DEVICE	1-40, 1-65	EDIT	2-88
Delay time	1-66	Electronic Mail Services	1-34
Device section	1-65	END	2-89
Drive section	1-65	EOF	2-90
Driver	1-66	ERASE	2-91
Filter	1-66	ERL	2-92
Status section	1-65	ERR	2-93
Step rate	1-66	ERRS\$	2-93
Devices	1-10	ERROR	2-94
logical	1-10	Error Message	1-6, A-62, A-76
physical	1-10, A-85	Escape Code Sequence	1-46
devspec	1-10	EXP	2-95
*DO (Display Output (Video))	1-10	Exponentiation	2-40
*JL (Job Log)	1-10	Expressions	2-26, 2-47
*KI (Keyboard Input)	1-10	Extended Command Descriptions	1-61
*PR (Printer)	1-10	E (Enter Data)	1-61
*SI (Standard Input)	1-10	L (Locate)	1-62
*SO (Standard Output)	1-10	N (Next Load Block)	1-62
DIM	2-87	P (Print)	1-62
DIR	1-28, 1-68	T (Type ASCII)	1-63
<i>partspec</i>	1-68	V (Compare)	1-63
Direct-Access Files	2-54	W (Word)	1-63
Accessing	2-56	/extension	1-8
Creating	2-54		

— F —

F (Fill Memory) 1-58
FIELD **2-96**
file-for-file copy 1-28
File Handling Commands 1-13
filename 1-8
Files
 BASIC ASCII 1-47
 combining A-23
 data 1-47
 fragmented 1-28
Filespec. 1-7
FILTER **1-77**
 phantom devspec 1-77
Filters 1-10
FIX **2-97**
FLOPPY/DCT **A-99**
 Hard disk installations A-99
Floppy Disk Drive A-40
Floppy Drive 0 1-30
FOR/NEXT A-76, **2-98**
FORMAT 1-24, 1-31, **1-78**
 erase all data from disk 1-78
 prepare a new disk 1-78
Format Prompts 1-78
FORMS **1-82**
FORMS/FLT **A-95**
FRE **2-100**
FREE 1-28, **1-85**
Functions 2-27, 47, 62
 control A-45
 graphics A-45
 keys 1-35
 action 1-36
 applications 1-35
 text A-45

— G —

G (Go to an Address/Execute) 1-58
GET **2-100**
GOSUB **2-101**
GOTO **2-102**
Graphics Characters 1-42

— H —

H (Hex Modify) 1-58
 hexadecimal value 1-59

 vertical bars 1-58
HANDSHAKE 1-37, 40, 44
HERZ50 A-107
Hex byte representations 1-32
HEX\$ **2-103**
Hexadecimal value 1-34

— I —

I (Insert) 2-19
I (Single-Step Execution) 1-59
If **highlighted** 1-15
IF ... THEN ... ELSE A-77, **2-103**
Initialization commands 1-13
INKEY\$ **2-105**
INP **2-105**
INPUT **2-106**
INPUT# **2-107**
INPUT\$ **2-108**
INSTR **2-110**
INT **2-111**
Integer 2-4
Integers 2-30

— J —

J (Jump) 1-59
JCL Compiling A-12
 Advanced A-25
 description and terms A-13
 compile phase A-13
 execution A-13
 SYSTEM/JCL A-12
 label A-13
 logical operator A-14
 token A-13, A-16
 using logical operators A-26
Job Control Language **A-3**
 creating A-4
 restrictions A-4
 simple execution A-4
 using labels A-24
JOBLOG **A-91**

— K —

Keyboard A-40
KILL **2-112**
KSM file 1-32
KSM/FLT 1-31, **A-92**

building a file	A-92	//EXIT.....	A-7
— L —		//FLASH	A-7
LEFT\$	2-112	//INPUT	A-7
LEN	2-113	//KEYIN	A-7
LET	2-114	//number	A-11
LIB	1-87	//PAUSE	A-8
Technical Information	1-87	//SLEEP	A-8
Line	2-4	//STOP.....	A-8
logical	1-32	/// (triple slash).....	A-11
physical	1-32	//WAIT	A-9
LINE INPUT	2-115	keyboard	A-5
LINE INPUT#	2-116	nested //IF.....	A-27
LINK.....	1-88	//INCLUDE	A-28
device to a file	1-88	pause/delay	A-5
LIST.....	1-90, 2-117	Main memory usage.....	1-45
LLIST.....	2-118	FIFO storage compartment.....	1-45
LOAD.....	1-92, 2-119	HIGH\$.....	1-45
Load module format	1-17	Marker, end of file.....	1-31
Loading BASIC	2-9	MEM	2-125
Loading the Program	2-12	MEMDISK/DCT	A-96
LOC	2-120	disable.....	A-98
LOF	2-121	double density	A-97
LOG	2-122	installing	A-97
LOC/CMD	1-93	single density.....	A-97
hard disk installations.....	1-93	Technical Information.....	A-99
Logical device	1-10	MEMORY	1-94
Logical line	1-32	HIGH\$.....	1-94
LPOS.....	2-123	LOW\$	1-94
LPRINT, LPRINT USING.....	2-123	Memory Map	A-101
LRL	1-49, 1-52	MENU	1-36
LSET	2-124	MERGE.....	2-126
— M —		MID\$... (Function)	2-129
MACROS	A-5	MID\$... (Statement).....	2-128
alert	A-6	Mirror Image Backup	1-27, 1-28
comment.....	A-5	MKD\$, MKI\$, MKS\$.....	2-130
conditional.....	A-15	MOD flags.....	1-27
comment.....	A-15	Modem	1-42
higher order logical.....	A-15	Multiplication.....	2-40
logical	A-15	— N —	
merge	A-15	NAME	2-131
termination	A-15	nC (Change).....	2-21
execution.....	A-5	nD (Delete).....	2-21
//ABORT	A-6	Nested subroutines.....	A-76
//ALERT	A-6	NEW	2-131
//DELAY	A-6	News and Information System	1-34
		nKc (Search and "KILL").....	2-22

Non-ending Loops..... 1-50
 Notations (BASIC)..... 2-3
 nSc (Search) 2-22
 Number 2-4
 Numeric Operators 2-39, 2-42

— O —

O (Return to TRSDOS Ready)..... 1-59
 OCT\$..... **2-132**
 ON ERROR GOTO..... **2-132**
 ON ... GOSUB **2-133**
 ON ... GOTO **2-134**
 O'NNNN 2-3
 OPEN **2-135**
 Operating Temperature A-41
 Operators 2-39
 Logical..... 2-44
 Numeric..... 2-39, 2-42
 Relational 2-42
 String..... 2-42
 OPTION BASE **2-136**
 Options for Loading BASIC..... 2-9
 OUT..... **2-137**
 Owner passwords 1-19

— P —

Parameters..... 1-15
 [parameters]..... 2-4
 Parentheses..... 2-45
 Partspec 1-8, 1-28
 "wildcard" mask (\$) 1-8
partspec 1-24, 1-47
 .password 1-8
 Passwords 1-20
 Owner 1-20
 User 1-20
 PATCH **1-96**
 direct modify..... 1-99
 memory load location..... 1-97
 PATCH utility 1-31
 Pause Transmission..... 1-40
 PEEK..... **2-137**
 Peripheral Interfaces A-41
 Physical device 1-10
 Physical line 1-32
 POKE..... **2-138**
 Ports A-76

POS..... **2-138**
 Power Supply..... A-40
 Power-up configuration 1-30
 PRINT **2-139**
 PRINT TAB..... A-77, **2-145**
 PRINT USING **2-141**
 Print Zones..... A-75
 PRINT @ A-77, **2-144**
 PRINT#..... **2-146**
 Printing
 double-precision numbers..... A-76
 single-precision numbers..... A-76
 Protection passwords 1-19
 PURGE **1-100**
 PUT **2-147**

— Q —

Q (Cancel and Exit) 2-21
 Q (Port)..... 1-59
 Quick reference card 1-36
 Quick reference label 1-41

— R —

R (Register Pair) 1-60
 register pair codes 1-60
 RANDOM **2-148**
 READ..... **2-149**
 Receiving large files
 from another computer..... 1-46
 Relational Operators..... 2-42
 REM..... **2-150**
 REMOVE **1-102**
 user-created device 1-102
 RENAME..... **1-103**
 RENUM..... **2-151**
 REPAIR (REPAIR/CMD) **1-105**
 Reserved Words A-76, 2-29
 RESET 1-18, **1-106**
 improperly closed files 1-106
 RESTORE **2-152**
 RESUME..... **2-153**
 Resume transmission..... 1-40
 RETURN..... 2-154
 Reverse video A-46
 RIGHT\$..... 2-154
 RND 2-155
 ROM Subroutines A-75

ROUTE 1-108
 ROW **2-156**
 RS-232C i, 1-113
 communications line 1-34
 modem 1-113
 serial printer 1-113
 Technical Information 1-114
 RSET **2-157**
 RUN **1-110, 2-157**

— S —

S (Full Screen Mode) 1-60
 SAVE **2-158**
 Saving the Program 2-11
 Screen Print 1-7
 Sector 1-61
 Sequential-Access Files 2-51
 Creating 2-51
 Updating 2-53
 SET **1-111**
 driver program 1-111
 filter program 1-111
 SETCOM 1-42, **1-113**
 SETKI **1-116**
 SGN **2-159**
 Simple Variables 2-29
 SIN **2-160**
 SOUND **2-160**
 SPACES\$ **2-161**
 SPC **2-162**
 Special Characters A-58
 SPOOL **1-117**
 disk buffer 1-117
 memory buffer 1-117
 output buffer 1-117
 SQR 2-162
 Statements 2-26, **2-60**
 Static Electricity A-62
 STOP **2-163**
 String 2-4
 String Operator 2-42
 String Relations 2-43
 String Space A-76
 Strings 2-32
 STR\$ **2-164**
 STRING\$ **2-164**
 Subscripted Variables 2-29

Substitution Fields A-21
 Subtraction 2-41
 SWAP **2-165**

Symbol

DC1 1-40
 resume transmission 1-40
 DC2 1-40
 *FR device ON 1-40
 DC3 1-40
 pause transmission 1-40
 DC4 1-40
 *FR device OFF 1-40
 using % symbol A-29
 Syntax 1-15, 2-4
 SYSGEN **1-120**
 configuration file 1-120
 Sysgened configuration 1-29
 SYSTEM **1-122, 2-166**
 Alive 1-122
 Blink 1-122
 Date 1-123
 Drive 1-123
 SYSRES 1-124
 SYSTEM 1-125
 TIME 1-125
 TRACE 1-125
 TYPE[=switch] 1-125
 (SYSRES=number) 1-28
 System modules 1-28

— T —

TAB **2-167**
 TAN **2-167**
 TAPE100 **1-126**
 Model 100 Computer 1-126
 Technical Information ii
 TIME **1-127**
 clock 1-127
 TIMES\$ **2-168**
 Timesharing Systems 1-34
 TROFF, TRON **2-169**
 TRSDOS **1-1**
 Abbreviations 1-6
 application programs 1-6
 date 1-6
 Notations 1-5
 Terms 1-5

command 1-5
devspec 1-5
disk 1-5
disk.ID 1-6, 1-28
diskette 1-5
filespec 1-5
I/O 1-6
(parameters) 1-5
Type Declaration Tags 2-33, 2-35
! tag 2-33
tag 2-34
D notation 2-34
E notation 2-34

— U —
U (Update) 1-60
Updating Sequential-Access Files 2-53
User passwords 1-20
USING
//ASSIGN A-15
//. Comment and //QUIT A-19
//IF, //END, //ELSE A-15
//SET and // RESET A-15
USR 2-170

Utilities 1-14

— V —

VAL 1-173
Variable Names A-75, 2-29
Variables 2-28
VARPTR 2-174
VERIFY 1-128
Video Display A-39

— W —

WAIT 2-177
WHILE ... WEND 2-178
Wildcard mask (\$) 1-8
WRITE 2-179
WRITE# 2-180
Write-enabled 1-23

— X —

X (Extend Line) 2-19
X (Return) 1-60
X'NNNN 2-3